


# 380 Outrage

*Owner's Manual*



THE UNSINKABLE LEGEND

# ***380 Outrage***



**The mission of Boston Whaler® is to provide consumers with the safest, highest quality, most durable boats in the world.**



## **WARNING**

Operating, servicing and maintaining a recreational marine vessel can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, service your vessel in a well-ventilated area and wear gloves or wash your hands frequently when servicing this vessel. For more information go to **[www.P65warnings.ca.gov/marine](http://www.P65warnings.ca.gov/marine)**.

# Introduction

---



T H E U N S I N K A B L E L E G E N D™

Welcome to the Boston Whaler® family and congratulations on your purchase!

For over six decades, Boston Whaler has engineered the most reliable and forward-thinking boats on the water. Every chapter of our history starts with a belief in pushing the limits of what's possible, and this heritage is cause for both reflection and celebration.

Standing behind every Whaler is an extremely qualified network of dealers to provide you with a truly exceptional boating experience. Information and assistance is also available at [bostonwhaler.com](http://bostonwhaler.com), where you will find customer resources including how-to videos, maintenance tips, and other technical content. While there, don't forget to sign up to receive future issues of Boston Whaler's lifestyle magazine, Whaler.

Since Boston Whaler's inception in 1958, we are committed to providing customers with the safest, highest-quality, most durable boats in the world. We are confident that as a Whaler owner you will love the quality and pride that is built into every boat.

From all of us here at Whaler, thank you for selecting one of our a legendary and innovative boats. May that choice bring you a lifetime of boating enjoyment.

# Introduction

---

## History

Since our founding, Boston Whaler® has conceived and built peerless designs that meet boaters' diverse and changing needs. It all began in Braintree, Massachusetts with founder Richard Fisher's inspired new construction method featuring two significant innovations: first, a twin-sponson hull design that resulted in superior stability and a remarkably dry ride, and second, a unique foam-core construction that made the boat not only durable, but unsinkable as well. So for people whose livelihood and lives depend on their boat, Boston Whaler is the right choice because of our seaworthiness, dependability, and the inherent safety of a hull that won't sink even if severely damaged. Plain and simple, Boston Whaler boats are built to last.

In 1961, Fisher's demonstration of that unsinkability was captured by *Life* magazine in photos showing a Whaler® boat being sawed in half and Fisher then motoring away in the remaining half. True to Fisher's vision, Boston Whaler's world-class team has consistently pushed the envelope, furthering advances in manufacturing, design, navigation, and propulsion technologies.

On September 26, 1996, Richard Fisher was posthumously inducted into the National Marine Manufacturer's Association (NMMA) hall of fame for accomplishments made in marine engineering and construction.



*In 1958, the legend is born as company founder Dick Fisher demonstrates a Boston Whaler's total unsinkability.*

# Table of Contents

## Introduction

Welcome Letter .....	INTRO-1
History .....	INTRO-2
Preface .....	INTRO-7
Boston Whaler Limited Warranty .....	INTRO-8
Boston Whaler Limited Warranty Outside the U.S. or Canada .....	INTRO-13
California Evaporative Emissions Control System Warranty Statement .....	INTRO-17
Privacy Statement .....	INTRO-18
Owner's Manual .....	INTRO-19
Your Responsibilities .....	INTRO-19
Source of Information .....	INTRO-19
Warranties .....	INTRO-19
Contact Numbers and Internet Addresses .....	INTRO-19

## Chapter 1 • Safety

Explanation of Safety labels .....	1-1
Warning Labels .....	1-1
Safety Precautions .....	1-1
Safe Boating Means .....	1-2
To Obtain These Skills .....	1-2
In Addition .....	1-2
Safe Boating Checklist .....	1-2
Before Departure .....	1-2
Trailing (if applicable) .....	1-2
After Return .....	1-2
General Considerations .....	1-3
Maintain Control .....	1-3
Boarding .....	1-3
Impaired Operation .....	1-3
Operator's Responsibility .....	1-4
Legally Mandated Equipment (Minimum Required) .....	1-5
Personal Flotation Devices (PFD's) .....	1-5
Fire Extinguisher (Portable) .....	1-5
Whistle, Horn .....	1-5
Visual Distress Signal .....	1-5
Additional Recommended Equipment for Safe Operation .....	1-5
Carbon Monoxide (CO) .....	1-6
Carbon Monoxide Detector .....	1-6
End of Life Signal (EOL) .....	1-7
Carbon Monoxide accumulation Scenarios .....	1-7
Lifesaving Equipment .....	1-8

PFD Requirement .....	1-8
General Considerations .....	1-9
Emergency Situations .....	1-10
Medical Emergency .....	1-10
Water Rescue .....	1-10
Returning to the Victim .....	1-10
Making Contact .....	1-10
Getting Back on Board .....	1-10
Unassisted Reboarding .....	1-11
Fire .....	1-11
Lessening Fire Danger .....	1-11
Flooding, Swamping and Capsizing .....	1-11
Flooding .....	1-11
Swamping .....	1-11
Capsizing .....	1-12
Collision .....	1-12
Propulsion, Control or Steering Failure .....	1-12
Grounding .....	1-12
Distress Signals .....	1-13
Visual Distress Signals .....	1-13
Audible Distress Signals .....	1-13
Radio Communication .....	1-13
Weather .....	1-14
Swimming, Diving and Water Skiing .....	1-15
Swimming .....	1-15
Diving .....	1-15
Water Skiing .....	1-15
Towed Inflatables .....	1-17
Engine Emergency Stop Switch .....	1-17
1 <sup>st</sup> Mate™ Safety and Security System .....	1-17
Float Plan .....	1-18
Chart Your Course .....	1-18
Environmental Considerations .....	1-18
Fuel and Oil Spillage .....	1-18
Excessive Noise .....	1-18
Wake/Wash .....	1-18
Homeland Security Restrictions .....	1-19
America's Waterway Watch .....	1-19
Warning Label Locations .....	1-19
Key to Symbols Used on Controls .....	1-25

## Chapter 2 • General Information

Construction Standards .....	2-1
Our Hull .....	2-1
Hull Identification Number .....	2-1
Servicing Your Boston Whaler .....	2-1
Manufacturer's Certification .....	2-2
Certification Design Category .....	2-4

# Table of Contents

Power Capacity .....	2-4	Bilge Pumps.....	3-9
Specifications and Dimensions.....	2-5	Access to the Pumps.....	3-10
Passenger Areas.....	2-6	Maintenance .....	3-10
Recommended Passenger Locations .....	2-7	Bilge Pump Maintenance.....	3-10
Location of Thru-Hull Fittings .....	2-8	Float Switch .....	3-10
General Layout, Exterior .....	2-10	Emergency High Water Bilge Pump.....	3-10
General layout, Bilge .....	2-11	Fuel and Oil Spillage.....	3-10
General Layout, Forward Bilge.....	2-12	Gray Water Sump.....	3-11
General Layout, Control Station .....	2-13	Maintenance .....	3-11
General Layout, Port Aft Cockpit.....	2-14	Fuel System.....	3-12
General Layout, Starboard Aft Cockpit.....	2-15	Fuel Tank .....	3-12
General Layout, Control Station Seating ..	2-16	Fuel Vent .....	3-13
General Layout, Aft Facing Couch .....	2-17	Fuel Distribution System.....	3-13
General Layout, Deluxe Leaning Post .....	2-18	Filling the Tank .....	3-13
General Layout, Port Interior .....	2-19	Static Electricity and the Fuel System.....	3-14
General Layout, Starboard Interior.....	2-20	Ethanol-Blended Fuel.....	3-15
General layout, Head Interior .....	2-21	Filling the Tank.....	3-15
General Layout, Console Lounge.....	2-22	Phase Separation.....	3-15
General Layout, Hardtop .....	2-23	Additives .....	3-15
Seating.....	2-24	Fuel Filters.....	3-15
Notable Options .....	2-25	Fuel/Water Separator .....	3-15
Helm Switch Panel.....	2-26	Maintenance .....	3-15
Navigation Lighting.....	2-27	Storage .....	3-15
Operating the Navigation Lighting.....	2-27	Power Steering.....	3-16
Canvas (Option) .....	2-28	Filling and Maintenance .....	3-16
Installation.....	2-28	Fresh Water System .....	3-18
To Remove Canvas .....	2-29	Filling the tank.....	3-18
Towing, Docking and Lifting .....	2-30	Freshwater Pump.....	3-19
Bow Tow Eye (Option) .....	2-30	Deck Showers.....	3-19
Docking .....	2-31	Anchor Locker Washdown.....	3-20
Lifting.....	2-31	Water Heater .....	3-20
Yacht Tender Package.....	2-32	Operation.....	3-20
Operating with Tender in Tow .....	2-33	Maintenance .....	3-21
Out of Water Storage.....	2-33	Tempering Valve.....	3-21
		Fresh Water System Maintenance .....	3-21
		Raw Water System .....	3-22
		Full-Fill Livewell .....	3-22
		Full-Fill Livewell Operation .....	3-22
		Leaning Post Livewell (Option) .....	3-23
		Maintenance .....	3-23
		Raw Water Washdown.....	3-24
		Maintenance .....	3-24
		Head System .....	3-25
		Environmental Considerations.....	3-25
		VacuFlush Head.....	3-25
		Operation.....	3-25
		Macerator and Dockside Discharge.....	3-26
		Overboard Discharge .....	3-27
		Maintenance .....	3-27

## Chapter 3 • Overview & Operation

Theft Deterrent System (WhalerWatch).....	3-1
Starting the Engines .....	3-1
Engine(s) Warm Up .....	3-2
Stopping the Engines.....	3-3
Throttle and Shift Control.....	3-3
Engine Trim .....	3-4
Active Trim .....	3-4
Dynamic Running Surface™ (Trim Tabs)....	3-4
Joystick Piloting.....	3-6
Helm to Upper Helm Station Transfer .....	3-6
VesselView.....	3-7
Bow Thruster (Option).....	3-7

## Table of Contents

Dockside Pump-Out .....	3-27	Bow Table (Option) .....	3-48
Waste System Vent.....	3-27	Leaning Post Refrigerator/freezer .....	3-48
Air Conditioning .....	3-28	Leaning Post Refrigerator/ freezer (Option) .....	3-49
Operation.....	3-28	Electric Grill (Option) .....	3-49
Starting the System .....	3-28	To Remove the Grease Pan.....	3-49
Maintenance .....	3-28	Automatic Shut-Off .....	3-49
Helm Deck Air Conditioning (Option).....	3-28	Fold Down Visibility Platform .....	3-50
Automatic Engine Flushing\ System (Option) .....	3-30	Radial Outriggers (Option) .....	3-50
Operation.....	3-30	Operation.....	3-50
Generator .....	3-31	Maintenance .....	3-51
Starting the Generator .....	3-32	Gemlux® Radial Ouriggers (Option).....	3-51
Stopping the Generator .....	3-33	Operation.....	3-51
Maintenance .....	3-33	Maintenance .....	3-52
Operating the Generator in EU		Hardtop Access .....	3-52
Member Countries .....	3-34	Spotlight (Option) .....	3-52
Raw Water Strainer Maintenance.....	3-34	Thermal Night Vision (Option) .....	3-52
Diesel Generator (Option) .....	3-35	Electric Windshield Vent.....	3-53
Fuel.....	3-35	Windshield Wiper/Washer .....	3-53
Starting the Diesel Generator .....	3-36	Electric Sun Shade (Option) .....	3-53
Stopping the Diesel Generator .....	3-37	Stereo .....	3-54
Maintenance .....	3-37	Cockpit Lighting .....	3-56
Generator Fuel Filter .....	3-37	Hardtop Lighting .....	3-56
Fuel Filter Maintenance .....	3-38	Map Lights .....	3-56
Operating the Generator in EU		Flood Lights .....	3-56
Member Countries .....	3-38	Cabin Lights.....	3-57
Raw Water Strainer Maintenance .....	3-38	Underwater Lights (Option).....	3-57
Shore Power .....	3-39	Sun Lounge Storage Garage.....	3-57
ELCI (Equipment Leakage Circuit Interrupter)...	3-39	Dive Tank Racks (Option) .....	3-57
Shore Power Operation .....	3-40	Seakeeper Gyro Stabilizer (Option) .....	3-58
Single Cord Shore Power .....	3-41	Propeller.....	3-59
Battery Charging .....	3-42	Trimming the Engines .....	3-59
Shore Power Load Management .....	3-42	Changing Propellers.....	3-59
Isolation Transformer.....	3-35	Anchor Windlass .....	3-60
Maintenance .....	3-42	Operation.....	3-61
Fire Suppression System (Option).....	3-42	Operating From the Helm .....	3-61
In the Event of Discharge.....	3-43	Operating From the Bow .....	3-61
Manual Override System .....	3-43	Operating Windlass Manually .....	3-62
Dive Door .....	3-44	Anchoring .....	3-63
Dive Ladder .....	3-44	Considerations .....	3-63
Collapsible Swim Ladder .....	3-44	Lowering the Anchor .....	3-63
Fishboxes with Pump Out Discharge .....	3-45	Setting the Anchor .....	3-64
Cockpit Fishbox Freezer Plates (Option) ..	3-45	Weighing the Anchor .....	3-64
Electric Downrigger Receptacles (Option) 3-46			
Foldaway Trolling Seats (Option) .....	3-47		
Foldaway Aft bench Seat.....	3-47		
Foldaway Cockpit Bench Seat (Option)....	3-47		
Stowable Cockpit Tables (Option) .....	3-47		
To Setup the Tables .....	3-48		
		<b>Chapter 4 • Electrical</b>	
		Electrical System .....	4-1
		DC Electrical System .....	4-1
		Batteries.....	4-1



## Table of Contents

<ul style="list-style-type: none"> <li>Battery Trays..... 4-1</li> <li>Battery Charger..... 4-2</li> <li>Charge Rate..... 4-2</li> <li>Overload Protection ..... 4-2</li> <li>Maintenance ..... 4-2</li> <li>Battery Switches ..... 4-2</li> <li>  Engine battery Switches..... 4-2</li> <li>  Remote Battery Switches ..... 4-3</li> <li>  Automatic Charging Relays (ACR) ..... 4-3</li> <li>    Manual Control Override..... 4-3</li> <li>  House/Thruster Battery Switches..... 4-5</li> <li>Bow Batteries..... 4-5</li> <li>  Battery Maintenance..... 4-5</li> <li>12 Volt Accessory receptacle ..... 4-5</li> <li>  120 Volt Receptacles..... 4-6</li> <li>DC Distribution Panel..... 4-7</li> <li>Main DC Breaker Panel ..... 4-8</li> <li>DC Distribution Panel w/Joystick Piloting ... 4-9</li> <li>AC Electrical System ..... 4-10</li> <li>Component Breakers ..... 4-10</li> <li>Main AC Breaker Panel..... 4-11</li> <li>Main AC Breaker Panel (230V) (Option) .. 4-12</li> <li>Fuse Blocks..... 4-13</li> <li>Ground Fault Interrupter</li> <li>  Receptacle (GFI) ..... 4-13</li> <li>  Testing..... 4-13</li> <li>Helm Display..... 3-13</li> <li>  Display Apps ..... 3-13</li> <li>Transducer Mounting Location..... 4-16</li> <li>Electrical Schematics and Harnesses..... 4-17</li> </ul> <p><b>Chapter 5 • Care &amp; Maintenance</b></p> <ul style="list-style-type: none"> <li>Routine Care and Maintenance..... 5-1</li> <li>  Hull ..... 5-1</li> <li>  Aquatic Invasive Species (AIS)..... 5-1</li> <li>  Waxing the Gel Coat Surfaces..... 5-2</li> <li>  Hull Maintenance..... 5-2</li> <li>  Hull Blistering..... 5-2</li> <li>  Prevention ..... 5-2</li> <li>Bottom Painting ..... 5-3</li> <li>  Sacrificial Anodes..... 5-3</li> <li>  Bottom Painting a Bare Hull..... 5-3</li> <li>  Bottom Painting a Pre-Painted Hull..... 5-4</li> <li>Rubrail care ..... 5-4</li> <li>Cleaning Fiberglass and Non-Skid ..... 5-4</li> <li>Stainless Steel Care ..... 5-5</li> <li>Teak Maintenance ..... 5-5</li> <li>Seats (Mechanical Parts)..... 5-5</li> </ul>	<ul style="list-style-type: none"> <li>Aluminum Care ..... 5-6</li> <li>Standard Vinyl Cushions ..... 5-6</li> <li>Cool Technology Vinyl Cushions (Option)... 5-6</li> <li>Cleaning Your Instrument Gauges ..... 5-6</li> <li>Powder Coated Surfaces ..... 5-6</li> <li>  Powder Coating Touch-Up ..... 5-7</li> <li>  Touch-Up Procedure..... 5-7</li> <li>Canvas Care and Maintenance..... 5-7</li> <li>  Maintaining a Good Appearance..... 5-8</li> <li>Cleaning stubborn Stains ..... 5-8</li> <li>Maintaining Zippers and Hardware..... 5-8</li> <li>Maintaining Your Vinyl Windows ..... 5-8</li> <li>Storing Clear Vinyl..... 5-9</li> <li>Cleaning Tempered Glass Windshield ..... 5-9</li> <li>Corian® Solid Surface Counter Tops ..... 5-9</li> <li>  Routine Care ..... 5-9</li> <li>  Minor Cuts And Scratches..... 5-9</li> <li>  Heat Damage..... 5-10</li> <li>  Other Damage..... 5-10</li> <li>  Refurbishing..... 5-10</li> <li>Long-term Storage and Winterization..... 5-10</li> <li>  Engine ..... 5-10</li> <li>  Fuel System ..... 5-11</li> <li>  Battery ..... 5-11</li> <li>    Mixing Fresh/New and Used/Dead</li> <li>    Batteries ..... 5-11</li> <li>    Mixing Battery Types..... 5-11</li> <li>    Mixing Battery Brands ..... 5-11</li> <li>    Battery Storage ..... 5-11</li> <li>Livewell/Raw Water System ..... 5-11</li> <li>Fresh Water System ..... 5-11</li> <li>  After Long Term Storage ..... 5-12</li> <li>Head System ..... 5-12</li> <li>Air handling System..... 5-12</li> <li>Sump ..... 5-12</li> <li>Electrical System ..... 5-12</li> <li>Deck ..... 5-12</li> <li>Drainage..... 5-12</li> <li>Avoid Loss ..... 5-12</li> <li>Cover ..... 5-12</li> <li>Environment ..... 5-13</li> <li>Reinforcement Locations..... 5-13</li> <li>Reinforcement Location Diagram ..... 5-14</li> </ul> <p><b>Attachments</b></p> <ul style="list-style-type: none"> <li>  Commissioning Checklist</li> </ul>
--	---

# Introduction

---

## Preface

**READ AND RETAIN this manual. If the boat is sold, ensure all documentation is transferred to the new owner.**

Information in this publication is based on the latest product specifications available at the time of printing. Boston Whaler reserves the right to make changes at any time without prior notice. Boston Whaler is not responsible for specification changes to parts or accessories manufactured by other companies.

*NOTE: Equipment may vary depending on options selected.*

If needed in connection with selling your boat, service history or warranty records on vessels should be requested from the original selling dealer, the servicing dealer and/or the previous owner (where applicable). Information regarding open safety recalls is maintained by the United States Coast Guard, and can be obtained by visiting [uscgboating.org](http://uscgboating.org).

Brunswick Corporation registered trademarks: Mercury Marine, Mercury Racing, Optimax, Nautic-On, Skyhook, SmartCraft, Verado, Vantage, VesselView, VesselView Mobile.

Boston Whaler, Inc. registered trademarks: Boston Whaler, Boston Whaler with harpoon and hull logo, Conquest, Dauntless, Montauk, Outrage, Realm, Unibond, Whaler.

All other trademarks listed in this publication are the property of their respective owners.

**BOSTON WHALER® • A BRUNSWICK COMPANY**

© June 2016 Brunswick Corporation



## **BOSTON WHALER LIMITED MANUFACTURER WARRANTY (US AND CANADA)**

Boston Whaler, Inc. (“Boston Whaler”) provides the following Limited Manufacturer Warranty to the original retail owner of its 2024 model year Boats, if purchased from an authorized Boston Whaler Dealer and operated under normal, non-commercial use, subject to the remedies, exclusions, and limitations set out below.

- 1. Ten-Year Structural Hull Limited Warranty:** Any Structural Hull Defect in material or workmanship which is reported within ten (10) years from the date of sale to the original retail owner will be repaired or replaced at Boston Whaler’s sole discretion. The “Hull” shall mean the single fiberglass molded shell and integral structural components. A Structural Hull Defect shall mean a substantial defect in the Boat’s Hull which causes the Boat to be unfit or unsafe for general use as a pleasure craft under normal operating conditions.
- 2. Three-Year Limited Warranty on Components Manufactured or Installed By Boston Whaler: (not applicable to 13 Super Sport or 16 Super Sport models):** Boston Whaler will repair or replace, at its sole discretion, any components manufactured or installed by Boston Whaler that are defective in factory materials and/or workmanship, which are reported within three (3) years from the date of delivery to the first retail purchaser, and are not addressed in the specific warranties listed in paragraphs 1 or 4 or set out in the Exclusions paragraph below.
- 3. One-Year Limited Warranty on Accessory Components for the 13 Super Sport and 16 Super Sport Models:** Boston Whaler provides the following Limited Warranty to the original retail owner of any factory-authorized accessory for the 2024 model year 13 Super Sport and 16 Super Sport, if purchased from an authorized Boston Whaler Dealer, authorized Boston Whaler website or any Boston Whaler affiliate and utilized under normal, non-commercial use (“Accessory”), subject to the remedies, exclusions, and limitations set out below. Boston Whaler will repair or replace, at its sole discretion, any Accessory that is defective in material or workmanship, which is reported within one (1) year from the date of delivery to the first retail purchaser. Boston Whaler is not responsible for any defect and/or damage to the Accessory and/or the Boat caused by improper installation, whether performed by the retail owner, dealer or any other third party.
- 4. One-Year Limited Warranty on Upholstered Items, Canvas, Teak, and Powder Coating:** Boston Whaler will repair or replace, at its sole discretion, any upholstered items, canvas, teak, and powder coating manufactured or installed by Boston Whaler that are defective in factory materials and/or workmanship and are reported within one (1) year from the date of delivery to the first retail purchaser.
- 5. Limited Engine Warranty:** Retail owners will be entitled to the limited engine warranty as provided in the warranty manual from the engine manufacturer that was delivered to the retail owner with his or her Boston Whaler Boat.

### **EXCLUSIONS**

This Limited Manufacturer Warranty does not apply to any Boat which has been salvaged or declared a total loss or constructive total loss for any reason not covered in this limited warranty. This Warranty also does not apply to the following items:

- 1) Expenses for hauling out or transportation to and from the dealer or Boston Whaler factory for warranty service.
- 2) Equipment or accessories which are not installed by Boston Whaler or which carry their own individual warranties, including but not limited to engines, engine components, batteries, propellers, controls, steering mechanisms, and electronics.
- 3) Damage, deterioration, discoloration or mold of cushions or cosmetic surface finishes, including scratches, gouges, chips, chalking, blistering, cracking, crazing, fading or oxidation of gel coat, stress lines, plated or

painted metal and stainless steel finishes, plastics or acrylic materials, or anti-fouling bottom paint.

4) Windshield breakage and leakage.

5) Any Boat initially sold at retail by a party other than an authorized Boston Whaler dealer.

6) Damage resulting from abuse, misuse, improper rigging and installation by an owner or any other person or entity that is not an authorized dealer, accidents, or overloading or powering in excess of the recommended maximum horsepower.

7) Failure of the owner to use, maintain, or store the Boat as specified in the Boston Whaler owner's manual; and any other failure to provide reasonable care and maintenance. Normal wear and tear maintenance items are excluded from warranty coverage including but not limited to filters, bulbs, batteries, bungees, wiper blades, anchor rope, trailer finishes, tires, brakes, bearings, and lights.

8) Any Boston Whaler Boat which has been altered or modified from Boston Whaler factory specifications, including penetration of the hull by anyone other than Boston Whaler factory personnel or Boston Whaler authorized dealer service personnel following factory specified procedures.

9) Damages resulting from use of improper trailer, improperly placed supporting bunks or slings, incorrect bunks placement, or improper boat lift or sling.

10) Damages due to failure to properly tow the Boat. For those Boats for which Boston Whaler offers a yacht tender package, damages due to towing when the package has not been installed.

11) Any Boston Whaler Boat used for commercial purposes, which includes, but is not limited to, any for-profit or other revenue-generating uses.

12) Any representation or implication relating to speed, range, fuel consumption or estimated performance characteristics.

13) Any failure or defect caused by an act of nature resulting in damage, cost, or expense.

14) Any failure or defect arising from a previous repair made by a non-authorized service provider.

15) Any item exceeding the expressed coverage limits specified in any Boston Whaler Limited Manufacturer Warranty.

16) Failure of the owner to use, maintain, or store an Accessory in reasonable fashion; and any other failure to provide reasonable care and maintenance.

17) Any accessory which has been altered or modified from Boston Whaler factory specifications.

18) Any accessory not purchased from an authorized Boston Whaler Dealer, authorized Boston Whaler website, or authorized Boston Whaler affiliate. For a list of Boston Whaler's affiliates, please refer to [www.brunswick.com](http://www.brunswick.com).

19) Any accessory used for commercial purposes, which includes but is not limited to, any for-profit or other revenue generating uses.

20) Any defect or repair requiring redesign of the Boat, except pursuant to the recall provisions of the United States Federal Boat Safety Act of 1971 or the recall laws of any other foreign jurisdiction.

#### **SOLE REMEDY**

THE REMEDY OF REPAIR OR REPLACEMENT OF PARTS OR MATERIALS THAT ARE FOUND TO BE DEFECTIVE IN FACTORY MATERIALS OR WORKMANSHIP COVERED BY THIS LIMITED MANUFACTURER WARRANTY SHALL CONSTITUTE THE OWNER'S SOLE AND EXCLUSIVE REMEDY AGAINST BOSTON WHALER FOR ANY CLAIMS WHATSOEVER OF ECONOMIC LOSS RESULTING FROM PRODUCT FAILURE.

#### **ENVIRONMENTAL POLICIES**

In keeping with environmental policies and practices, Boston Whaler reserves the right to utilize reconditioned,

refurbished, repaired or remanufactured products or parts in the warranty repair or replacement process. Such products and parts will be comparable in function and performance to an original product or part and warranted for the remainder of the original warranty period. In no event shall any repair or replacement under this Limited Manufacturer Warranty exceed the fair market value of the product as of the date of the owner's claim. Acceptance of any product returned or any refund provided by Boston Whaler shall not be deemed an admission that the product is defective. Products that are replaced become the property of Boston Whaler.

#### **OTHER LIMITATIONS**

EXCEPT AS SET FORTH HEREIN, THERE ARE NO OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, PROVIDED BY BOSTON WHALER ON THIS BOAT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE EXPRESSLY EXCLUDED. BOSTON WHALER FURTHER DISCLAIMS ANY LIABILITY FOR ECONOMIC LOSS ARISING FROM CLAIMS OF PRODUCT FAILURE, NEGLIGENCE, DEFECTIVE DESIGN, MANUFACTURING DEFECT, FAILURE TO WARN AND/OR INSTRUCT, LACK OF SEAWORTHINESS, AND ANY OTHER THEORY OF LIABILITY NOT EXPRESSLY COVERED UNDER THE TERMS OF THIS LIMITED MANUFACTURER WARRANTY.

ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS DISCLAIMED. TO THE EXTENT THE IMPLIED WARRANTY CANNOT BE DISCLAIMED, IT IS LIMITED TO THE SHORTER OF ONE YEAR FROM THE DATE OF DELIVERY TO THE FIRST RETAIL OWNER OR THE DURATION OF THE RESPECTIVE EXPRESS LIMITED WARRANTIES STATED HEREIN. TO THE EXTENT ALLOWED BY LAW, NEITHER BOSTON WHALER, NOR THE SELLING DEALER, SHALL HAVE ANY RESPONSIBILITY FOR LOSS OF THE BOAT, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT BE APPLICABLE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT BE APPLICABLE. THIS WARRANTY GIVES THE OWNER SPECIFIC LEGAL RIGHTS, AND THE OWNER MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE OR COUNTRY TO COUNTRY.

#### **STATUTE OF LIMITATIONS**

Any action for rescission or revocation against Boston Whaler shall be barred unless it is commenced within one (1) year from the date of accrual of such cause of action. This provision does not grant any consumer a right of rescission or revocation against Boston Whaler, where such right does not otherwise exist under applicable law. Some states may not allow the applicable statute of limitations for rescission or revocation to be reduced, so this provision may not apply to each retail owner.

#### **OWNER'S OBLIGATIONS**

To initiate a warranty claim, it is the responsibility of the owner to contact an authorized Boston Whaler dealer immediately after discovery of any defect, describe the nature of the problem, and provide a hull serial number, date of purchase, and name of selling dealer. The authorized dealer will notify Boston Whaler, who is solely responsible for determining and authorizing in writing the remedial action(s) to be performed at either an authorized Boston Whaler dealership chosen by Boston Whaler or at the Boston Whaler factory. The owner should notify Boston Whaler of any Boat being repaired by an authorized Boston Whaler dealer which has been at the dealership for fifteen (15) days, or of any claimed defect which was not corrected after one repair attempt. The owner must provide Boston Whaler with a reasonable opportunity to repair,

and reasonable access to the Boston Whaler Boat for warranty service and the owner shall pay for all related transportation charges and/or travel time. If the owner cannot deliver the product to such a dealer, written notice must be given to Boston Whaler. Boston Whaler will then arrange for the inspection and any covered repair and the owner shall pay for all related transportation charges and/or travel time. Our privacy policies are available at [www.bostonwhaler.com](http://www.bostonwhaler.com).

#### **ASSIGNMENT OF COMPONENT WARRANTIES**

Except as expressly set out herein, all warranties provided by the manufacturers and distributors of components, equipment, and parts on the Boat (collectively “Component Manufacturers”) are hereby assigned to the owner to the extent permitted by the Component Manufacturers, as the owner’s sole and exclusive remedy with respect to such items.

#### **REGISTRATION & WARRANTY TRANSFER POLICY**

The limited warranty coverage is activated by the authorized selling dealer registering the sale of a new Boat with Boston Whaler.

The Ten-Year, Three-Year, and One-Year limited warranties are transferable to a subsequent owner, except the one-year Accessory warranty which is not transferrable and this Limited Manufacturer Warranty will not transfer to any new owner of a Boat which has been salvaged and resold, or resold after a declaration of a total loss or a constructive total loss, i.e., the cost of repair exceeds the value of the Boat. The new owner must fill out and submit the online Boston Whaler warranty transfer form, accessible from [www.bostonwhaler.com](http://www.bostonwhaler.com). A copy of the bill of sale will be required to submit with the form. The warranty transfer must be completed within 30 days of purchase. Notwithstanding anything in this Limited Manufacturer Warranty to the contrary, Boston Whaler reserves the right to reject any warranty transfer request for a Boston Whaler Boat that has been damaged, neglected, or otherwise previously excluded from warranty.

#### **MODIFICATIONS & SEVERABILITY**


**The terms and conditions contained herein, as well as those of any documents prepared in conjunction with the sale of this vessel may not be modified, altered or waived by any action, inaction, or representations, whether oral or in writing, except upon the expressed, written authority of a management level employee of Boston Whaler. The invalidity or unenforceability of any one or more of the provisions herein shall not affect the validity and enforceability of the other provisions.**

#### **GOVERNING LAW AND VENUE**

This Warranty shall be interpreted and construed according to and governed by the laws of the State of Tennessee, without regard to conflict of law principles. Venue for any and all disputes arising out of or related to this Warranty, including without limitation the interpretation, performance or breach of this Warranty, shall be solely and exclusively before the United States District Court for the Eastern District of the State of Tennessee. The parties consent to the in *personam* jurisdiction of said court for the purposes of any such litigation and waive, fully and completely, any right to dismiss and/or transfer any action pursuant to 28 U.S.C. Section 1404 or 1406 (or any successor statutes) or the doctrine of *forum non conveniens*. If the United States District Court does not have subject matter jurisdiction of said matter, then such matter shall be litigated solely and exclusively before the appropriate state court of competent jurisdiction located in Knox County, Tennessee, and the parties consent to the personal jurisdiction of such court for the purpose of such litigation.

#### **SAFETY**

It is your responsibility (as well as the responsibility of any other operator of this Boat) to be familiar with and observe all local, state and federal laws, rules and regulations regarding boating, navigation and boating safety. You and any other operator of this Boat should take a course in boating and boating safety before



operation of this Boat and should be completely familiar with all systems regarding safe operation of this Boat. Personal flotation devices should be worn by each passenger in accordance with U.S. Coast Guard standards and state and federal law.

**World Headquarters**  
**100 Whaler Way, Edgewater, FL 32141**  
**(386) 428-0057**  
**[bostonwhaler.com](http://bostonwhaler.com)**

## **BOSTON WHALER LIMITED MANUFACTURER WARRANTY (Outside the U.S. or Canada)**

Boston Whaler, Inc. (“Boston Whaler”) provides the following Limited Manufacturer Warranty to the original retail owner of its 2024 model year Boats, that if purchased from an authorized Boston Whaler dealer and operated under normal, non-commercial use, the authorized dealer will repair or replace, at its sole discretion, any defect in material or workmanship in the Boston Whaler Boat that is reported within the applicable Limited Manufacturer Warranty periods and within the scope as set out below.

Mandatory warranty rights, including a consumer’s mandatory statutory rights, by law are not affected by this Limited Manufacturer Warranty and in particular not limited or excluded. These mandatory legal rights exist regardless of whether a warranty claim occurs or rights are asserted under this Limited Manufacturer Warranty.

### **SCOPE**

This Limited Manufacturer Warranty applies only to Boston Whaler Boats purchased outside of the US and Canada, including the territory of the European Union and Australia, and to recreational use customers only (not commercial users). Commercial use, which voids the Limited Manufacturer Warranty, is defined as any use of the product which generates income, even if the product is only occasionally used for such purposes.

Routine maintenance outlined in the Operation and Maintenance Manual must be timely performed in order to maintain Limited Manufacturer Warranty coverage.

This Limited Manufacturer Warranty applies to the following items:

- 1. Ten-Year Structural Hull Limited Warranty:** Any Structural Hull Defect in material or workmanship which is reported within ten (10) years from the date of sale to the original retail owner will be repaired or replaced at Boston Whaler’s sole discretion. The “Hull” shall mean the single fiberglass molded shell and integral structural components. A Structural Hull Defect shall mean a substantial defect in the Boat’s Hull which causes the Boat to be unfit or unsafe for general use as a pleasure craft under normal operating conditions.
- 2. Three-Year Limited Warranty on Components Manufactured or Installed By Boston Whaler (not applicable to 13 Super Sport or 16 Super Sport models):** Boston Whaler will repair or replace, at its sole discretion, any components manufactured or installed by Boston Whaler that are defective in factory materials and/or workmanship, which are reported within three (3) years from the date of sale to the original retail owner, and are not addressed in the specific warranties listed in paragraphs 1 or 4 or set out in the Exclusions paragraph below.
- 3. One-Year Limited Warranty on Accessory Components for the 13 Super Sport and 16 Super Sport Models:** Boston Whaler provides the following Limited Warranty to the original retail owner of any factory-authorized accessory for the 2024 model year 13 Super Sport and 16 Super Sport, if purchased from an authorized Boston Whaler Dealer, authorized Boston Whaler website or any Boston Whaler affiliate and utilized under normal, non-commercial use (“Accessory”), subject to the remedies, exclusions, and limitations set out below. Boston Whaler will repair or replace, at its sole discretion, any Accessory that is defective in material or workmanship, which is reported within one (1) year from the date of sale to the original retail owner. Boston Whaler is not responsible for any defect and/or damage to the Accessory and/or the Boat caused by improper installation, whether performed by the retail consumer, dealer or any other third party.
- 4. One-Year Limited Warranty on Upholstered Items, Canvas, Teak, and Powder Coating:** Boston Whaler will repair or replace, at its sole discretion, any upholstered items, canvas, teak, and powder coating manufactured or installed by Boston Whaler that are defective in factory materials and/or workmanship and are reported within one (1) year from the date of sale to the original retail owner.



5. Limited Engine Warranty: Retail owners will be entitled to the limited engine warranty as provided in the warranty manual from the engine manufacturer that was delivered to the original retail owner with his or her Boston Whaler Boat.

### EXCLUSIONS

This Limited Manufacturer Warranty does not apply to any Boat which has been salvaged or declared a total loss or constructive total loss for any reason not covered in this limited warranty. This warranty also does not apply to the following items:

- 1) Expenses for hauling out, transportation to and from the dealer or the Boston Whaler factory for warranty service.
- 2) Equipment or accessories which are not installed by Boston Whaler or which carry their own individual warranties, including but not limited to engines, engine components, batteries, propellers, controls, steering mechanisms, and electronics.
- 3) Damage, deterioration, discoloration or mold of cushions or cosmetic surface finishes, including scratches, gouges, chips, chalking, blistering, cracking, crazing, fading or oxidation of gel coat, stress lines, plated or painted metal and stainless steel finishes, plastics or acrylic materials, or anti-fouling bottom paint.
- 4) Windshield breakage and leakage.
- 5) Any Boston Whaler Boat initially sold at retail by a party other than an authorized Boston Whaler dealer.
- 6) Damage resulting from abuse, misuse, improper rigging and installation by an owner or any other person or entity not being an authorized dealer, accidents, overloading or powering in excess of the recommended maximum horsepower.
- 7) Failure of the owner to use, maintain, or store the Boat as specified in the Boston Whaler owner's manual; and any other failure to provide reasonable care and maintenance. Normal wear and tear maintenance items are excluded from warranty coverage including but not limited to filters, bulbs, batteries, bungees, wiper blades, anchor rope, trailer finishes, tires, brakes, bearings and lights.
- 8) Damages due to failure to properly tow the Boat. For those Boats for which Boston Whaler offers a yacht tender package, damage due to towing when the package has not been installed.
- 9) Any Boston Whaler Boat which has been altered or modified from Boston Whaler factory specifications, including penetration of the hull by anyone other than Boston Whaler factory personnel or Boston Whaler authorized dealer service personnel following factory specified procedures.
- 10) Damage resulting from use of improper trailer, improperly placed supporting bunks or slings, incorrect bunks placement and improper Boat lift or sling.
- 11) Any Boston Whaler Boat used for commercial purposes, which includes, but is not limited to, any for-profit or other revenue-generating uses.
- 12) Any representation or implication relating to speed, range, fuel consumption or estimated performance characteristics.
- 13) Any failure or defect caused by an act of nature resulting in damage, cost, or expense;
- 14) Any failure or defect arising from a previous repair made by a non-authorized service provider.
- 15) Any item exceeding the expressed coverage limits specified in any Boston Whaler Limited Manufacturer Warranty.
- 16) Failure of the owner to use, maintain, or store an Accessory in reasonable fashion; and any other failure to provide reasonable care and maintenance.
- 17) Any Accessory which has been altered or modified from Boston Whaler factory specifications.
- 18) Any Accessory not purchased from an authorized Boston Whaler Dealer, authorized Boston Whaler

website, or authorized Boston Whaler affiliate. For a list of Boston Whaler's affiliates, please refer to [www.brunswick.com](http://www.brunswick.com).

19) Any Accessory used for commercial purposes, which includes but is not limited to, any for-profit or other revenue generating uses.

20) Any defect or repair requiring redesign of the Boat, except pursuant to the recall provisions of the United States Federal Boat Safety Act of 1971 or the recall laws of any other foreign jurisdiction.

#### **ENVIRONMENTAL POLICIES**

In keeping with environmental policies and practices, Boston Whaler reserves the right to utilize reconditioned, refurbished, repaired or remanufactured products or parts in the warranty repair or replacement process. Such products and parts will be comparable in function and performance to an original product or part and warranted for the remainder of the original warranty period.

#### **ACCESS FOR SERVICE**

The owner must provide Boston Whaler with a reasonable opportunity to repair, and reasonable access to the Boston Whaler Boat for warranty service. Warranty claims shall be made by delivering the Boston Whaler Boat for inspection to a Boston Whaler dealer authorized to service the product. If the owner cannot deliver the product to such a dealer, written notice must be given to Boston Whaler. Boston Whaler will then arrange for the inspection and any covered repair and the owner shall pay for all related transportation charges and/or travel time.

#### **STATUTE OF LIMITATIONS**

Without prejudice to your mandatory statutory rights, any action for rescission or revocation against Boston Whaler shall be barred unless it is commenced within one (1) year from the date of accrual of such cause of action, unless a longer period is prescribed by local law. This section shall not apply to Boston Whaler Boats purchased in Australia.

#### **ASSIGNMENT OF COMPONENT WARRANTIES**

Except as expressly set out herein, all warranties provided by the manufacturers and distributors of components, equipment, and parts on the Boat (collectively "Component Manufacturers") are hereby assigned to the owner to the extent permitted by the Component Manufacturers, as the owner's sole and exclusive remedy with respect to such items.

#### **OWNER'S OBLIGATIONS**

To initiate a warranty claim, it is the responsibility of the owner to contact an authorized Boston Whaler dealer immediately after discovery of any defect, describe the nature of the problem, and provide a hull serial number, date of purchase, and name of selling dealer. The authorized dealer will notify Boston Whaler, who is solely responsible for determining and authorizing in writing the remedial action(s) to be performed at either an authorized Boston Whaler dealership chosen by Boston Whaler or at the Boston Whaler factory. The owner should notify Boston Whaler of any Boat being repaired by an authorized Boston Whaler dealer which has been at the dealership for fifteen (15) days, or of any claimed defect which was not corrected after one repair attempt. Our privacy policies are available at [www.bostonwhaler.com](http://www.bostonwhaler.com).

#### **REGISTRATION & WARRANTY TRANSFER POLICY**

The limited warranty coverage is activated by the authorized selling dealer registering the sale of a new Boat with Boston Whaler.

The Ten-year, Three-year, and One-year Limited Warranties are transferable to a subsequent owner, except

the One-year Accessory Warranty which is not transferrable, and this Limited Manufacturer Warranty will not transfer to any new owner of a Boat which has been salvaged and resold, or resold after a declaration of a total loss or a constructive total loss, i.e., the cost of repair exceeds the value of the Boat. The new owner must fill out and submit the online Boston Whaler warranty transfer form, accessible from [www.bostonwhaler.com](http://www.bostonwhaler.com). A copy of the bill of sale will be required to submit with the form. The warranty transfer must be completed within 30 days of purchase. Notwithstanding anything in this Limited Manufacturer Warranty to the contrary, Boston Whaler reserves the right to reject any warranty transfer request for a Boston Whaler Boat that has been damaged, neglected, or otherwise previously excluded from warranty.

#### **MODIFICATIONS & SEVERABILITY**

The terms and conditions contained herein, as well as those of any documents prepared in conjunction with the sale of this vessel may not be modified, altered or waived by any action, inaction, or representations, whether oral or in writing, except upon the expressed, written authority of a management level employee of Boston Whaler. The invalidity or unenforceability of any one or more of the provisions herein shall not affect the validity and enforceability of the other provisions.

#### **SAFETY**

It is your responsibility (as well as the responsibility of any other operator of this Boat) to be familiar with and observe all local, state and federal laws, rules and regulations regarding Boating, navigation and Boating safety. You and any other operator of this Boat should take a course in Boating and Boating safety before operation of this Boat and should be completely familiar with all systems regarding safe operation of this Boat. Personal flotation devices should be worn by each passenger in accordance with applicable standards and state and federal law.

#### **THE FOLLOWING SECTION IS APPLICABLE TO EMEA CONSUMERS ONLY**

Boston Whaler Boats come with guarantees that cannot be excluded under EU and/or local Consumer Law. For the avoidance of doubt, the Boston Whaler Limited Manufacturer Warranty does not in any way adversely affect any possible right and/or protection the retail owner may have under said applicable legislation.

#### **THE FOLLOWING SECTION IS APPLICABLE TO AUSTRALIAN CONSUMERS ONLY**

Boston Whaler Boats come with guarantees that cannot be excluded under the Australian Consumer Law. Retail owners are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. Retail owners are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This Limited Manufacturer Warranty does not cover any expenses that retail owners may incur claiming the warranty.

The benefits to retail owners given by this Limited Manufacturer Warranty are in addition to other rights and remedies of the consumer under a law in relation to the goods or services to which the Limited Manufacturer Warranty relates.

**World Headquarters**  
**100 Whaler Way, Edgewater, FL 32141**  
**011 1 (386) 428-0057**  
**[bostonwhaler.com](http://bostonwhaler.com)**

**CALIFORNIA EVAPORATIVE EMISSIONS  
CONTROL SYSTEM WARRANTY STATEMENT**

**YOUR WARRANTY RIGHTS AND OBLIGATIONS**

The California Air Resources Board and Boston Whaler, Inc. are pleased to explain the evaporative emission control system's warranty on your 2024 MY spark-ignition marine watercraft (SIMW). In California, new spark-ignition marine watercraft must be designed, built, and equipped to meet the State's stringent anti-smog standards. Boston Whaler, Inc. must warrant the evaporative emission control system on your spark ignition marine watercraft for the period listed below provided there has been no abuse, neglect, or improper maintenance of your spark-ignition marine watercraft.

Your evaporative emission control system may include parts such as: carburetors, fuel tanks, fuel lines, fuel caps, valves, canisters, filters, vapor hoses, clamps, connectors, and other associated components.

**MANUFACTURER'S WARRANTY COVERAGE:**

This evaporative emission control system is warranted for three years. If any evaporative emission-related part on your spark-ignition marine watercraft is defective, the part will be repaired or replaced by Boston Whaler, Inc.

**OWNER'S WARRANTY RESPONSIBILITIES:**

- As the spark ignition marine watercraft owner, you are responsible for performance of the required maintenance listed in your owner's manual. Boston Whaler, Inc. recommends that you retain all receipts covering maintenance on your SIMW, but Boston Whaler, Inc. cannot deny warranty solely for the lack of receipts.
- As the SIMW owner, you should however be aware that the Boston Whaler, Inc. may deny you warranty coverage if your spark-ignition marine watercraft or a part has failed due to abuse, neglect, or improper maintenance or unapproved modifications.
- You are responsible for presenting your spark-ignition marine watercraft to a Boston Whaler, Inc. distribution center or service center as soon as the problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days. If you have a question regarding your warranty coverage, you should contact Boston Whaler, Inc. at 877-294-5645.

**SIMW EVAPORATIVE EMISSIONS WARRANTY PARTS:**

Fuel tank	Grade Valves
Fuel feed hoses	Fuel Fill Deck Plate w/Cap and Pressure Relief Valve
Fuel Line Fittings	Hose Clamps on Fuel System Components
Fuel Demand Valves	Fuel Level Vent Valve

All other parts not listed that may affect the evaporative emissions control system.

---

---

# Introduction

---

---

## Privacy Statement

Thank you for purchasing a boat or requesting information from Boston Whaler. This Privacy Statement is to inform you how we collect, use, disclose, and safeguard the personal information you provide to us through your purchases, requests for brochures, product registration cards, promotions, surveys, call centers, or other customer contacts. To see our full Privacy Policy and any updates, please visit [www.bostonwhaler.com](http://www.bostonwhaler.com) and select the Privacy Statement link. "Personal information" may include your name, age, mailing address, residential phone number, or e-mail address. It may also include income ranges, marital status, product or lifestyle preferences, and information concerning dealer service.

**How we collect personal information:** Our authorized dealer provided Boston Whaler or our company in the European Union with personal information collected at the time of your boat order/purchase with other product registration data and will continue to provide warranty and servicing information on your boat. We will send you customer satisfaction surveys which you may elect to return to provide us with information on your boat purchase and your servicing needs. Your personal information may be gathered by or shared with Boston Whaler's marketing providers and affiliated companies, who have comparable levels of privacy protection, for the purposes described in this statement. Boston Whaler, your dealer, and our marketing providers collect personal information when your request information about our companies and from surveys, promotions, contests, correspondence, your e-mails, telephone inquiries, web forms, and other communications. **How We Use and Disclose Personal Information:** Unless you advise us otherwise, Boston Whaler, our authorized dealers, affiliated companies, and our marketing providers may generally collect, use, disclose, hold, and file your personal information for the following purposes: (1) Providing goods, brochures, information, incentives, and/or services to you or on your behalf; (2) Fulfilling the terms of our limited warranty or other service obligation; (3) Facilitating recalls or service campaigns if necessary; (4) Reviewing goods and/or services provided to you in product, services, and marketing analyses; (5) Ensuring your satisfaction through surveys or other contacts; (6) Administration, billing, accounting, and collections; and protecting against fraud and error; and (7) Investigating a breach or a contravention of a law, complying with a subpoena, warrant, court order, or as required or otherwise permitted by law. Boston whaler will not sell your personal information or subject you to telemarketing or unsolicited e-mail.

**Safeguards:** We use security safeguards appropriate to the sensitivity of personal information to protect it from loss or theft, as well as prohibiting unauthorized access, disclosure, copying, use or modification of your personal information. These safeguards include restricted access to offices and equipment, security clearances, the use of passwords and/or encryption, publishing our privacy policy to appropriate personnel with instructions to act in accordance with its principles, and contractual provisions with our marketing agents and authorized dealers to follow the principles of our privacy policy.

**Access and correction to your personal information:** Subject to the exceptions provided by applicable law, we will provide, upon written request, your specific personal information collected in a form which is generally understandable. Your Personal Information is held by us and for us by our marketing agency, Rollick Company, who has contractually agreed to protect your information according to our privacy policies at the following addresses: Boston Whaler Inc., 100 Whaler Way, Edgewater, FL 32141. Please direct corrections, withdrawal of consent for specific purpose, complaints or other inquiries regarding personal information to: Rollick Company, 1078 Headquarters Park Drive, Fenton, MO, 63026; phone: (636) 343-9988, fax: (636) 326-3282. You can withdraw consent for us to use your personal information at any time or provide corrections upon providing to us a 30-day notice, unless withdrawing consent would impede the performance of legal obligations. We are required by law to provide you with information for product recall and other product safety relates purposes. The withdrawal of your consent may also adversely affect our ability to provide products and services to you and to maintain our relationship. Please note, notifying us will not result in withdrawing consent from your dealer, who should be contacted separately.

**Obtaining consent:** If any supplementary disclosure is required, we will obtain your consent for disclosure to other persons or organizations and for other purposes than stated herein, unless otherwise permitted by law.

Thank you for your business. We hope you have many years of wonderful boating experiences!

# Introduction

## Owner's Packet

The owner's packet is a large, zippered bag that contains all the manuals and instructional information for non-Boston Whaler equipment and systems on your boat. Read and retain this information.

## Owner's Manual

The contents of this manual:

• Provides basic boating safety information	• Details the boat's features and equipment
• Outlines the fundamentals of boat use	• Contains maintenance information

You must learn to operate this boat as well as read, understand and use this manual. This manual does not give you a course in boating safety or how to navigate, anchor or dock your boat. Operating a power boat safely requires more skills, knowledge, and awareness than is necessary for a motor vehicle.

## Your Responsibilities

For the safety of you and your passengers, other boaters as well as people in the water, you must:

• Take a boating safety course	• Understand and follow the <i>rules of the road</i>
• Get instruction in proper boat handling	• Learn how to navigate

## Contact Us

**Boston Whaler, Inc.**

877-294-5645

[www.bostonwhaler.com](http://www.bostonwhaler.com)

## Warranties

In addition to the Boston Whaler® Limited Warranty, each component and/or system on your boat has its own warranty that can be found with the specific information and manual for that component. These are included with your owner's information packet. Please locate, read, and retain the individual warranties.

## Boating Information\*

A comprehensive background in boating can be found in the book, *Chapman Piloting: Seamanship & Small Boat Handling*, by Elbert Maloney. For boating courses in North America, contact one of the following organizations:

Organization	Website	Phone
BoatU.S. Foundation	<a href="http://boatus.org">boatus.org</a>	800-336-2628
U.S. Coast Guard	<a href="http://uscgboating.org">uscgboating.org</a>	—
U.S. Coast Guard Auxiliary	<a href="http://cgaux.org">cgaux.org</a>	877-875-6296
US Power Squadron	<a href="http://usps.org">usps.org</a>	888 367-8777
Canadian Coast Guard	<a href="http://cgc-gcc.gc.ca">cgc-gcc.gc.ca</a>	800-267-6687
Canadian Power and Sail Squadrons	<a href="http://cps-ecp.ca">cps-ecp.ca</a>	888-277-2628
Red Cross	<a href="http://redcross.org">redcross.org</a>	800-733-2767

State boating offices

Yacht clubs

\*Outside of North America, contact your dealer or your governmental boating agency for assistance.

THIS PAGE INTENTIONALLY LEFT BLANK

## Explanation of Safety Labels

The most important aspect of boating is safety. Although every effort is made to address the numerous issues regarding the safe usage of your boat, it is strongly recommended that you avail yourself of the training and knowledge available through boating safety courses, etc.

### Warning Labels

Mounted at key locations throughout your boat are warning labels which advise the owner/operator of imperative safety precautions to follow when operating and/or servicing equipment.

The examples below indicate the level of hazard by color and explanation.

#### **DANGER**

Denotes an immediate hazard exists that **WILL** result in severe personal injury or death.

#### **WARNING**

Denotes hazards or unsafe practices that **MAY** result in severe personal injury or death.

#### **CAUTION**

Denotes hazards or unsafe practices that **COULD** result in minor personal injury, product or property damage.

#### **NOTICE**

Denotes information that is important to know prior to operation and/or maintenance, but is not hazard related.

## Safety Precautions

The precautions below appear throughout this manual and must be observed when operating or servicing your boat. Learn to recognize the degree of precaution and understand the explanations of safety prior to reading this manual. These precautions are not all-inclusive. Always use common sense in the operation of your boat.

#### **DANGER**

Denotes an immediate hazard exists that **WILL** result in severe personal injury or death.

#### **WARNING**

Denotes hazards or unsafe practices that **MAY** result in severe personal injury or death.

#### **CAUTION**

Denotes hazards or unsafe practices that **COULD** result in minor personal injury, product or property damage.

#### **NOTICE**

Denotes information that is important to know prior to operation and/or maintenance, but is not hazard related.

#### **ATTENTION**

Denotes information found in the owner's manual to call attention to the safe operation or certain features of this vessel.



## SAFE Boating means:

- Knowing the limitations of your boat
- Following the “RULES of the ROAD”
- Keeping a sharp lookout for people and objects in the water.
- Not boating in water or weather conditions that are beyond the boat’s and operator’s capability.
- Never operate the boat while under the influence of drugs or alcohol.
- Being aware of your passengers safety at all times.
- Reducing speed when there is limited visibility, rough water, people in the water nearby, boats or structures.

Boating in beautiful weather and calm water conditions can be a wonderful experience. Boating however requires considerably greater skills than operating a land vehicle.

## To obtain these skills:

- Take a Coast Guard, U.S. Power Squadron or equivalent boating safety course. (Call the Boat/U.S. Foundation at 1-800 336-2628 for information on available courses, or go to: “[www.boatus.com/foundation](http://www.boatus.com/foundation)” on the internet.)
- Get hands-on training on how to operate your boat properly.

## In Addition:

- Maintain your boat and its safety and other systems as recommended in this manual.
- Have the boat inspected by a qualified mechanic or dealer, at least annually.
- Ensure that the Coast Guard required safety equipment is on board and functioning.

## Safe Boating Checklist

### Before Departure

- Update checklists when equipment is added or modified.
- Weather-forecast safe
- Required documents-on board
- Navigation charts & equipment-on board
- Safety equipment-on board
- Safety training-passengers & crew instructed on procedures, location, and use of safety equipment.
- Drain plugs-installed
- Bilge pumps-working & clean
- Blower-working
- Navigation lights-working
- Horn-working
- Fuel system-no leaks or fumes
- Fuel filter-tight & clean
- Power steering fluid-filled(if applicable)
- Steering system-working smoothly & properly
- Battery-electrolyte level within range
- Float plan-filed with friend or relative

### Trailer (if applicable)

- Boat position-secure on trailer
- Tiedowns tight
- Winch-locked
- Trailer hitch-connected
- Engine clearance-in trailering position
- Safety chains-attached
- Electrical-Lights, brake lights, turn signals working
- Mirrors-adjusted for trailering

### After Return

- PFD’s and other safety gear stowed for next use
- Fuel tanks-filled (allow for expansion) to prevent condensation
- Fuel system-no leaks
- Bilge pump-operating properly
- Bilge-clean, no leaks
- Float plan-notify person with whom you filed plan

## General Considerations

- Know how your boat handles under different conditions. Recognize your limitations and the boat's limitations. Modify speed in keeping with weather, sea and traffic conditions.
- Instruct passengers on location and use of safety equipment and procedures.
- Instruct passengers on the fundamentals of operating your boat in case you are unable to do so.
- You are responsible for passenger's actions. If they place themselves or the boat in danger, immediately correct them.
- **Remember the "Rule of Thirds"**: Use one third of the fuel for the trip outbound, one third for the return trip, and keep one third for reserve.

## Maintain Control

High performance boats require intimate knowledge of their handling characteristics for safe high speed operation.

- Learn the effects of trim, steering and throttle changes at gradually increasing levels of speed.
- Approach full throttle while adjusting trim for safe handling of the vessel.

On the water there are no marked traffic lanes, no traffic signs or lights, and boats have no turn signals. The boat operator must keep her or his attention focused not only on what's ahead but what's on the left, right and behind the boat. The operator must always be alert to approaching boats (from the rear, right and left sides, as well as those ahead). There can be people in the water, partially submerged debris, and other navigational hazards such as rocks, sand bars or dangerous currents, to name a few.

Your passengers are relying on you to operate and maneuver the boat safely so they are not thrown overboard. If you turn too quickly, increase or decrease speed abruptly, your passengers are at risk of being thrown overboard or thrown about the boat.

When visibility becomes impaired because of weather or time of day, use navigational lights to ensure other boats can see you. In addition, if high bow angle causes reduced visibility, slow down to allow sufficient time to react if an emergency occurs.

## Boarding

- Board only one person at a time.
- Never jump into boat. Step or climb into cockpit.
- Load gear after you are aboard. Carrying gear while boarding can cause you to lose balance.
- Distribute weight evenly.
- Instruct passengers where to sit during on-plane operation to reduce the possibility of falling overboard during high speed maneuvers.
- If gear is not immediately needed, stow it in secure areas.
- Safety gear must be immediately accessible at all times.

## Impaired Operation

### **WARNING**

**CONTROL HAZARD-Federal laws prohibit operating a boat while under the influence of alcohol or drugs. These laws are vigorously enforced.**

The detrimental effects of alcohol and drugs are increased by wind, waves and sun, and will decrease your response time and ability to act in critical situations. Give special attention to the effects of alcohol and drugs while boating. No other single factor causes as many marine accidents and deaths. Death or serious injury and damage to personal and private property can result from being impaired while operating a boat.

## Operator's Responsibility

Your degree of enjoyment on the water depends on you, your equipment and other people who, like yourself boat responsibly. As a boat operator you should:

- Make sure that all occupants always wear a U.S. Coast Guard-approved life jacket while on the water.
- All boat operators should complete a boating safety course (a requirement in many states).
- All boat operators must become familiar with the proper operation of all vessel features prior to departure.
- Always maintain a safe speed.
- Be aware of conditions in every direction always when underway.
- Mind your wake. It can capsize a small boat or damage moored boats or other property. You are responsible for damage caused by your wake.
- Reduce speed and post a lookout to identify hazards when:
  - Visibility is impaired
  - In rough water
  - In congested waterways
- Display navigation lights between sunset and sunrise and during periods of restricted visibility, such as rain, fog, etc.

### **WARNING**

**A qualified operator must be in control of the boat at all times. Do not operate the boat while under the influence of alcohol or drugs. Never operate your boat at speeds which exceed the operator's ability to react if an emergency develops. At night, turn on the appropriate navigation lights and cruise at a reduced speed that will allow you plenty of time to avoid dangerous situations.**

### **WARNING**

#### **STABILITY HAZARD**

- **Load boat properly. The manufacturer's load rating is the maximum allowed under normal conditions. Adjust downward if weather, water or other conditions are adverse.**
- **Allow passengers to ride only in areas that do not pose a hazard to themselves or the boat.**

**DO NOT allow passengers to ride on the bow of a closed bow boat.**

**DO NOT allow several passengers to ride in the bow of a small open-bow boat, causing the boat to "plow" into the water.**

**DO NOT allow passengers to ride on the stern cushion or gunwales.**

**DO NOT overload the stern.**

- **Observe manufacturer's recommended on-plane seating locations.**
- **Passengers should remain seated while boat is moving.**

**PERSONAL INJURY HAZARD-Stay alert. Use of drugs, alcohol, or other substances which impair judgement poses a serious threat to yourself and others. The boat operator is responsible for the behavior of passengers.**

**DROWNING HAZARD-Boats must carry one wearable personal flotation device (PFD) for every passenger on board. Boats must have at least one throwable life preserver.**

**SLIPPING HAZARD-Wet decks are slippery. Wear proper footwear and use extreme caution on wet surfaces.**

## Legally Mandated Equipment (Minimum Required)

Consult your National Boating Law Enforcement Agency. The following equipment is the minimum required by the U.S. Coast Guard for a boat which is more than 26 ft. (7.9 M) in length but less than 40 ft. (12.2M) in length.

### Personal Flotation Devices (PFD's)

One (1) Coast Guard approved Type I, II, III is mandatory for each person aboard.

One (1) throwable Type IV device is also required to be onboard.

A Type V device is acceptable (See page 1.8) if worn for approved use.

### ALWAYS WEAR A PFD WHEN BOATING.

#### **WARNING**

**There is rarely time to reach stowed life jackets in time of emergency. Boaters should always wear a properly fitting, approved life jacket when on the water.**

**Children and non-swimmers MUST wear PFD's at all times when aboard.**

#### **NOTICE**

**Depending on the state or country of operation, the operator of a vessel may be fined for failure to comply with local or national rules regarding PFD usage.**

### Fire Extinguishers

If there is no fixed fire extinguishing system installed, two size 5-B or one 20-B portable fire extinguisher(s) must be on board. If a fixed system is installed one 5-B portable fire extinguisher is required.

The American Boat & Yacht Council (ABYC) recommends three 5-B type ABC portable fire extinguishers be on board and located within easy reach of helm, outside of engine compartment, and galley or passenger area.

### Whistle, Horn

You must have on board, some means of making a loud sound signal. Navigation rules require that a sound made by any audible device be capable of a four (4) second blast, and be audible for 1/2 mi. (.80 km).

### Visual Distress Signals

If you operate your boat in coastal waters or on the Great Lakes, you must have a visual distress signals for day and night use on board. At least three U.S.C.G. approved pyrotechnic devices marked with date showing service life must be carried, be readily accessible, in serviceable condition and not be expired.

**Store all pyrotechnic signals in a well marked, waterproof container.**

### Additional Recommended equipment for safe operation

In addition to the legally mandated equipment, the following items are necessary for safe boating, especially if your boat is out of sight of land.

- First Aid kit
- Charts/Maps
- Visual distress signals (for day or night use)
- Marine VHF radio
- Moisture repellent
- Mooring Lines
- Fenders
- Waterproof flashlights
- High power spotlight
- Spare propeller
- Tool kit:
  - Screwdrivers, (Phillips & flat)
  - Pliers, (regular, vise-grip, tongue & groove)
  - Wrenches, (box, open end, Allen & adjustable)
  - Socket set, (metric or U.S.)
  - Electrical tape and duct tape
  - Hammer
  - Spare parts kit, (spark plugs, fuses, etc.)
- Compass
- Manual bilge pump
- GPS or LORAN
- Spare keys
- EPIRB-Emergency positioning-indicating radio beacon
- Boat hook
- Extra batteries
- Instruction manuals
- Lubricating oil
- Anchor

## Carbon Monoxide (CO)

### **DANGER**

- **Fumes from the engine(s), Generator(s) and other equipment and appliances that burn fuel contain Carbon Monoxide. Carbon Monoxide can kill you. Open all doors, hatches, curtains and windows to allow fresh air to circulate and dissipate the amounts of Carbon Monoxide present in enclosed spaces, especially when the boat is moored or anchored.**
- **Proper ventilation must be maintained, even during inclement weather to prevent dangerous levels of Carbon Monoxide build-up.**
- **Sleeping aboard a boat will require a working Carbon monoxide detection system, preferably in each sleeping quarter.**

Carbon Monoxide (CO) is an odorless, colorless, and tasteless, extremely toxic gas produced by engines, heaters, stoves or generators. When inhaled it combines with hemoglobin in the blood, preventing absorption of oxygen and is unlikely to be noticed until the person is overcome.

Prolonged exposure to low concentration or very short exposure to high concentrations can result in asphyxiation and death.

Symptoms of Carbon Monoxide poisoning include:

- Dizziness
- Headaches
- Ringing in the ears
- Nausea
- Unconsciousness

**GET MEDICAL ATTENTION AS SOON AS POSSIBLE.**

Symptoms of CO poisoning are often confused with seasickness or intoxication, so those affected may not receive the medical attention they need.

The poisoning victim's skin often turns cherry red. If CO poisoning is suspected, have the victim breathe fresh air deeply. If breathing stops, resuscitate. A victim often revives, then relapses because organs are damaged by lack of oxygen.

Carbon Monoxide can accumulate in dangerous concentrations anywhere in or around your boat including on back decks, swim platforms, or in water around generator exhausts. CO can remain in or around your boat at dangerous levels even if your engine is no longer running.

#### **Remember:**

- If you can smell engine exhaust, you are inhaling CO.
- Changing course and speed to place boat heading into the wind can improve ventilation.

To minimize the danger of Carbon Monoxide accumulation when the Engine is running (or by use of fuel burning equipment.):

- Do not idle the engine without moving the boat for more than 15 minutes at a time.
- Inspect the exhaust system regularly.
- Operate all fuel burning appliances, such as charcoal, propane, LPG, CNG or alcohol cooking devices in areas where fresh air can circulate.

#### **Carbon Monoxide Detector**

The Carbon Monoxide Detector located on the forward galley cabinet will sound an alarm when dangerous levels of CO are detected. The detector is very sensitive and will notify you before dangerous amounts of Carbon Monoxide can accumulate which will allow you to take measures to dissipate the gas from the affected areas. Read and understand the warnings and recommendations presented in this section to help keep yourself and your passengers safe from carbon monoxide.

#### **Testing:**

**At least once a week** depress the "Test/Mute" button until the green LED turns on and release to determine if the detector is working properly.

The alarm will simulate 2 alarm cycles (2 sets of 4 beeps, 5 sec. silence between). The Red LED will flash once every 5 seconds.


## Maintenance:

Avoid spraying liquids directly on alarm.

## End Of Life signal (EOL)

Your CO detector is equipped with an End Of Life signal indicating the sensor used in the unit has reached the end of its service life and must be replaced. The detector contains an electro-chemical sensor that will last approximately 7 years. Refer to your unit's operation manual for End Of Life signal indication and further information and instructions.

The End Of Life signal can be deactivated so that it does not sound an alarm. **DEACTIVATING THE CO ALARM IS PERMANENT. REACTIVATING IS NOT POSSIBLE. DO NOT DEACTIVATE UNLESS YOU HAVE A REPLACEMENT ALARM AVAILABLE TO INSTALL!**



**⚠ DANGER**

Even in rainy cold weather, ventilation must be maintained to avoid Carbon Monoxide poisoning. You will get wet and/or cold.

**⚠ DANGER**

Never ignore an alarm.


## In the event the CO alarm activates:

- Evacuate enclosed areas immediately.
- Shut OFF any fuel burning equipment or appliances.


- Open hatches, doors, portlights, etc. to improve ventilation.
- If making way, head boat into the wind.

## Carbon Monoxide Accumulation Scenarios


Examples of accumulation of Carbon Monoxide  
Figure 1.7.2




EXHAUST FROM OTHER BOATS




BLOCKAGE OF EXHAUST BY OBSTRUCTION




OPERATING AT A HIGH BOW ANGLE



OPERATING AT SLOW SPEED OR WHILE IDLING  
(STATION WAGON EFFECT)



RUNNING OR AT IDLE  
WITH CANVAS INSTALLED



GOOD AIR FLOW

## Lifesaving Equipment

### PFD Requirement

Even strong swimmers can tire quickly in the water and drown due to exhaustion, hypothermia, or both. The buoyancy provided by a personal flotation device (PFD) will allow the person who has fallen overboard to remain afloat with far less effort and body heat loss, extending survival time necessary to find and retrieve them.

One (1) wearable personal flotation device (PFD, Type I, II, III or V) for every person onboard and at least one (1) throwable device, (Type IV).


The law requires that PFD's must be readily accessible, if not worn. "Readily Accessible" means removed from storage bags and unbuckled. **Children and non-swimmers must wear PFD's at all times when aboard.**

Before purchasing PFD's, ensure that there is an attached tag indicating they are approved by the U.S. Coast Guard or by your National Boating Law Enforcement Agency.


The operator is responsible for instructing everyone onboard on the location and use of the PFD. **The best precaution is to wear the PFD at all times while on the boat.**

**Children and non-swimmers must wear a PFD at all times when aboard.** All passengers and crew should wear them since an unworn PFD is often useless. The law requires that PFD's, if not worn must be readily accessible, that is, removed from storage bags and unbuckled. Throwable devices must be readily available, that is, right at hand.


Listed below are the several different types of PFD's, each life jacket has different purposes, choose one that will suit your purpose.




**Type I**, Off-shore Life Jacket is considered the most buoyant, it is designed to turn an unconscious person face up. Use in all types of waters where rescue may be slow, particularly in cold or rough water conditions.




**Type II**, Near-shore Life Vest, "keyhole" vest with flotation filled head and neck support is also designed to turn a person face up, but the turning action is not as pronounced. Use in calm inland waters or where quick rescue is likely.



**Type III**, Flotation-aid Life vest is designed so that conscious wearers can turn face-up. Designed for comfort while engaged in water skiing or other forms of water activities.



**Type IV**, Throwable Devices, horseshoe buoys, ring buoys and buoyant cushions are designed to be grasped, not worn.



**Type V**, Special-Use devices, sailboat harnesses, white water vests, float coats, and hybrid vests which have minimum inherent buoyancy and an inflatable chamber.

## General Considerations

- Know how your boat handles under different conditions. Recognize your limitations and the boat's limitations. Modify speed in keeping with weather, sea and traffic conditions.
- Instruct passengers on location and use of safety equipment and procedures.
- Instruct passengers on the fundamentals of operating your boat in case you are unable to do so.
- You are responsible for passenger's actions. If they place themselves or the boat in danger, immediately correct them.

### **WARNING**

**A qualified operator must be in control of the boat at all times. Do not operate the boat while under the influence of alcohol or drugs. Never operate your boat at speeds which exceed the operator's ability to react if an emergency develops. At night, turn on the appropriate navigation lights and cruise at a reduced speed that will allow you plenty of time to avoid dangerous situations.**

### **WARNING**

#### **STABILITY HAZARD**

- **Load boat properly. The manufacturer's load rating is the maximum allowed under normal conditions. Adjust downward if weather, water or other conditions are adverse.**
- **Allow passengers to ride only in areas that do not pose a hazard to themselves or the boat.**

**DO NOT allow passengers to ride on the bow of a closed bow boat at speeds over 5 mph.**

**DO NOT allow several passengers to ride in the bow of a small open-bow boat, causing the boat to "plow" into the water.**

**DO NOT allow passengers to ride on the stern cushion or gunwales.**

**DO NOT overload the stern.**

- **Passengers should remain seated while boat is moving.**

**PERSONAL INJURY HAZARD-Stay alert. Use of drugs, alcohol, or other substances which impair judgement poses a serious threat to yourself and others. The boat operator is responsible for the behavior of passengers.**

**DROWNING HAZARD-Boats must carry one wearable personal flotation device (PFD) for every passenger on board. Boats must have at least one throwable life preserver.**

**SLIPPING HAZARD-Wet decks are slippery. Wear proper footwear and use extreme caution on wet surfaces.**





## WARNING

**Death or serious injury can result if you fail to observe these safety rules:**

- **Anyone who controls the boat must have taken a boating safety course and have trained in the proper operation of the boat.**
- **Always operate the boat at speeds that will not put people or property in danger.**
- **Be constantly aware of conditions in all directions when underway and before turning.**
- **Reduce speed, use a lookout to identify possible hazards or difficulties, and turn on navigation lights when:**
  - **visibility is impaired;**
  - **in rough water; and**
  - **in congested waterways.**
- **Watch your wake. It can capsize a small boat or damage moored boats or other property. You are responsible for damage caused by your wake.**

## Emergency Situations

### NOTICE

**The law requires the owner/operator to assist any person or boat in distress as long as rendering assistance does not endanger the owner/operator, the passengers or the boat.**

Prevention is the safest approach. We hope that you are never involved in an emergency situation, but if you are it is imperative that you react.

### Medical Emergency

You may be far from professional medical help when you are boating. At least two (2) persons on board your boat should be CPR certified, and should have taken a first aid course. Your boat should have a well

stocked first aid kit on board. In many situations your radio will be your only link to reaching medical assistance. Keep the radio in working order and understand which channels are used for emergencies, these channels are constantly monitored and will be useful when situations arise. Cell phones are becoming more common and can help in some areas, but they are limited and unreliable and should not be used in the place of a good VHF radio.

### Water Rescue

In most situations a person that has fallen overboard will succumb to hypothermia if not rescued immediately. Life expectancy decreases as rescue time increases in water temperatures below 70° (21.1°C).

There are three (3) steps that must be taken when a person has fallen overboard:

#### Returning to the victim:

- Immediately make everyone onboard aware that someone is overboard and keep the victim in sight.
- Slow the boat and keep pointing toward the person overboard. At night or in low light, point the best available light source at the person.
- Throw a life ring/preserver to the victim, even if they are wearing one it will serve as another marker.

#### Making contact

- Stop or slow the boat and circle toward the person overboard.
- Try to approach heading into the wind or into the waves.
- Keep person overboard constantly in sight.
- When almost alongside, turn off the engine in gear to prevent propeller “windmilling”.

#### Getting back aboard

- Try to reach the person overboard with a pole, or by throwing a life preserver. NEVER swim to them except as a last resort.
- Assist the person in boarding. Boarding should be done at the stern of the boat.

- If the person is injured or incapable of boarding by themselves, a rescuer should don a life preserver with a safety line and enter the water to assist the person onto the boat.
- Handle the person carefully, spinal injuries might have occurred and could be worsened by rough handling.
- Check for other injuries, render medical assistance immediately.

## Unassisted Re-boarding

The transom ladder, see chapter 2 *General Information* can be deployed to accommodate a person re-boarding the boat without assistance.

## Fire

Fire is a serious boating hazard. Boats will burn quickly. Do not remain onboard and fight a fire for more than a few minutes. If the fire is out of control and cannot be put out with the fire suppression equipment onboard, abandon ship immediately.

The fumes released during a fire are toxic and should be avoided. Even after the fire has been extinguished, proper ventilation of the area is required to minimize exposure to harmful fumes.



## WARNING

**NEVER operate a boat at a speed at which you do not feel in control.**



## DANGER

- **Fires can spread quickly. Your reaction to the fire is important. Have the proper fire fighting equipment close at hand, and in good working order to respond quickly.**
- **Small fire extinguishers have small discharge times. Aim at the base of the fire with a sweeping motion to maximize the use of the fire extinguisher contents.**

## Lesseninf Fire Danger

- Extinguish all smoking materials, shut off blowers, stoves, engine(s) and generator(s).

- Keep bilge area clean, oil and fuel spills should be cleaned immediately.
- If possible throw burning materials overboard.
- If fire is accessible, release the contents of the fire extinguisher(s) into the base of the fire.
- If the fire is in an enclosed compartment, and you have an automatic extinguisher for the compartment, wait 15 min. before opening the compartment. Have an extinguisher handy in case of a flare up.
- If possible, signal for help. Radio, visual, and audible signal should be used as needed. You must render assistance to any boater requesting help.
- If fire is out of control, grab all necessary survival gear, distress signals, don your PFD's and prepare to abandon ship.
- If you do abandon ship, make sure the passengers have PFD's. Take a head count before entering the water and take another head count when in the water. **STAY TOGETHER.**

## Flooding, Swamping and Capsizing

In the event of Flooding, Swamping or Capsizing:

### Flooding

- Always wear your PFD, or have it within reach.
- If the bilge pump(s) have not automatically turned ON, switch them ON immediately.
- Find the source of the flooding and determine the best fix.
- Keep the bilge pumps running until the flooding is under control.
- Call for assistance if the source of the flooding cannot be controlled.
- Head back to port if possible.

### Swamping

- Always wear your PFD, or have it within reach.

- Swamping is usually a result of wave action, immediately get control of the helm and turn the boat into the waves.
- Swamping can also be caused by an overloaded boat.
- If the bilge pump(s) have not automatically turned ON, switch them ON immediately.
- The deck scuppers on your boat are designed to drain the deck of water.
- Keep the bilge pumps running until the flooding is under control.
- Take a head count of all passengers.

### Capsizing

- “Capsized” is when a boat is on its side or completely upside-down (usually as a result of wave action, improper loading or load shifting).
- Always wear your PFD, or have it within reach.
- If the boat will not right itself, get out of the water and climb onto the exposed hull.
- Do a head count for all passengers
- **STAY TOGETHER**
- Usually a capsizing will happen quickly and without warning.
- Use whatever is at hand to signal for help.

The chances of flooding, swamping or capsizing can be reduced by being aware of:

- Weather
- Water Conditions
- Proper boat handling techniques
- Proper loading of the boat

### Collision

In the event of collision:

- Cut the engine(s)
- Always wear your PFD, or have it within reach.
- Check on passengers

- If the bilge pump(s) have not automatically turned ON, switch them ON immediately.
- Determine the amount of damage to your boats structure.
- Call for assistance
- In the event of collision you are required to file an accident report. Contact a state enforcement agency or the nearest U.S. Coast Guard office. If you are boating outside U.S. waters, consult the nation you are visiting for accident reporting requirements.

### Propulsion, Control or Steering failure

If there is a propulsion, control or steering failure:

- Stop the engine, (shut off at Ignition or pull on the Engine Emergency Stop Switch.)
- Drop anchor to prevent drifting.
- Determine if the problem can be fixed or will assistance be needed.
- Call for assistance if needed.

When loss of propulsion or steering is noticed, your quick reaction is required to prevent further damage to your boat or injuries to your passengers. Outboard engines require propulsion to control the direction the boat will take. Without propulsion, the steering is virtually useless. If you are in a congested waterway you will need to react quickly to warn others that you have lost power, propulsion or steering control and that assistance will be needed.

### Grounding

Running aground may be avoided by paying attention to marker buoys or indicated by waves as they form into breakers when passing over a sand bar.

If you do run aground, the course of action depends on how hard the boat hits bottom and whether the boat remains stranded. If it is a simple touch, you may need only to inspect the lower drive of the engine and the hull of the boat. If possible do a thorough inspection before trying to get loose, throwing the boat into reverse before this is done may do more damage.

## Distress Signals

### Visual Distress Signals, (VDS)

- U.S. Coast Guard regulations require boats in coastal waters and the Great Lakes to carry a Visual Distress Signal (VDS) for day and night use, as well as appropriate for the time of operation. Exempt from the day signals requirement, but not night signals, are boats less than 4.8 meters (16 feet), open sailboats less than 7.9 meters (26 feet), boats participating in organized events and manually propelled boats.
- If you are required to have visual distress signals, at least three safety approved pyrotechnic devices in serviceable condition must be readily accessible. They must be marked with a date showing the service life which must not be expired.
- Carry three signals for day use and three for night use. Some pyrotechnic devices such as red flares, meet both day and night use requirements.
- Store pyrotechnic signals in a cool, dry location. An orange or red watertight container prominently marked “DISTRESS SIGNALS” is recommended.

Other recognized visual distress signals include:

- Flames in a bucket
- Code flags November and Charlie
- Black square and ball on orange background flag
- Orange flag (certified)
- Electric distress light (certified)-for night use
- Dye marker (any color)
- Person waving arms (slowly)
- U.S. ensign flown upside down

### Audible Distress Signals, (ADS)

U.S. Coast Guard regulations require one hand, mouth or power operated whistle or horn, audible for at least 1/2 mile.

Other recognized audible distress signals include:

- Radio communication (see Radio Communication below)
- Radio-telegraph alarm
- Position indicating radio beacon
- Morse Code S-O-S (3 short 3 long 3 short) sounded by any means.
- Fog horn sounded continuously.

## Radio Communication

A radio is the boat operator’s main method of receiving safety information and summoning aid. VHF-FM radio is the primary means of short range communication. Single sideband radio (SSB) is used for longer range communication.

VHF-FM channel 16 and SSB 2182 kHz are designated for emergency use. Such situations can be categorized as:

- **EMERGENCY-**  
“MAYDAY, MAYDAY, MAYDAY,”- used when life or vessel is in imminent danger.
- **URGENCY-**  
“PAN-PAN, PAN-PAN, PAN-PAN” (pronounced PAHN-PAHN)-used when a person or vessel is in some jeopardy less than indicated by a “MAYDAY” call.
- **SAFETY-**  
“SECURITY, SECURITY, SECURITY” (pronounced SAY-CURE-IT-AY)-used for navigational safety or weather warning.

An emergency situation will be hectic and there will not be time to learn proper radio procedure. **LEARN WHAT TO DO BEFORE YOU NEED TO DO IT.**

If you hear a distress call, stop all radio transmissions. If you can directly assist, respond on the emergency frequency. If you cannot assist, do not transmit on that frequency. However, continue to monitor until it is obvious that help is being provided.

## Weather

### **⚠ DANGER**

**DO NOT attempt to boat in severe weather conditions. Death or serious injury can occur. Get to shore before the weather turns bad.**

Getting caught in severe weather is hazardous. Bad weather and/or rough sea or water conditions can cause an unsafe situation. Consult local weather services for up-to-date forecasts on weather and sea conditions. Television, Radio, and the Internet can give you access to NOAA weather reports that will help you make a determination on where and when to get underway.

Following are some weather related rules:

- Understand the design limitations of your boat.
- Check the weather forecast and water conditions before leaving and while underway.
- Wear a Personal Flotation Device (PFD)
- If a storm approaches, immediately seek a safe harbor.
- If a storm hits have everyone sit in the cabin or cockpit deck in the boat. Head the bow into the wind with enough power to maintain slow headway.
- If you encounter fog, determine your position, set a safe course, slow down and alert other boats of your presence using the appropriate sound signal for your situation at intervals of not more than 2 minutes apart.
- If a lightning storm approaches, the safest action is to dock and disembark. If you cannot return to shore, have passengers go inside the cabin and remain there until the storm passes.

- Stay out of the water during a lightning storm. If caught swimming during a storm, get back into the boat and remain there until the storm passes. Remember that lightning can strike several miles away from the storm itself. Be aware of the storms' location relative to your location and the direction the storm is moving.

### **⚠ WARNING**


**A sudden change in wind direction or speed or an increase in wave height indicates deteriorating weather.**

### **NOTICE**

**Check the weather forecast and water conditions before leaving and while underway**

#### Weather Warning Pennants

Figure 1.14.1




## Swimming, Diving & Water Skiing

### Swimming

- Do not swim from a moving boat.
- Many areas prohibit swimming from a boat except in designated areas.
- Turn off engine in gear (to prevent propeller windmilling) before picking up swimmer.

### Diving

Recognize and respect diving flags. Keep at least 30 meters (100 ft.) away.



**SPORT DIVERS FLAG**-Red flag with diagonal white stripe marks a diver in the water.


**CODE ALPHA FLAG**-Blue and white pennant designates boat being used in dive operations.

### Water Skiing

- Always have two persons in the boat, one at the controls and one who can easily and continuously look at the skier.
- Insist that anyone who water skis must know how to swim.
- Insist that skiers wear approved Personal Flotation Devices (PFD's)
- Ski only in daylight when visibility is good.
- Never drive the boat directly behind a water skier. At 22 knots (25 m.p.h.), it takes only 5 seconds to overtake a fallen skier who was 60 meters (200 feet) in front.
- Ski only in areas where skiing is permitted.

### Water Skiing Signals

Figure 1.15.2



**Turn** – Arm raised, circle with index finger extended.

**Turn Right** – Extend arm out from body to the right.

**Turn Left** – Extend arm out from body to the left.

**Stop** – Raise arm with palm vertical and facing forward.

**Faster** – Thumb pointed up or palm up, move hand up and down.

**Speed OK** – Raise arm and form a circle with thumb and index finger.

**Slow Down** – Thumb pointed down or palm down, move hand up and down.

**OK After a Fall** – Clasp hands together overhead.

**Skier in Water** – Extend one ski vertically out of water.

**Cut Motor** – Draw finger across throat.

**Back to Dock** – Pat top of head.

- Observe local restrictions on length of tow line.
- Learn the signals to communicate with a skier. The skier is to control the boat through hand signals (Figure 1.15.2).
- Your boat will handle differently while towing a skier. Experiment carefully to learn the difference.

- Skiers may start from the shore or dock, if boat traffic allows. When returning, pick up skiers from water. Do not ski back to shore or dock.
- Give immediate attention to fallen skiers.
- Keep a downed skier in sight and on the operator's side of the boat when approaching the skier. **Never back up to anyone in the water.**
- Turn off engine in gear (to prevent propeller "windmilling") before picking up skier.
- If the skier suddenly releases the tow rope, it can backlash into cockpit. Spotters who are watching the skier must be aware of this fact and be prepared to take appropriate action to avoid injury.

## **DANGER**

### **PROPELLER SAFETY**

- **Before starting your boat, walk to the stern and look in the water to assure there is no one near your propeller.**  
**People near propeller may not be visible from helm.**
- **NEVER allow passengers to board or exit your boat from the water when engines are on.**
- **Educate passengers about the dangers of propellers**
- **Be especially alert when operating in congested areas. NEVER enter swimming zones.**
- **Take extra precautions near boats that are towing skiers or tubers.**
- **NEVER permit passengers to ride on the bow, gunwale, transom, seatbacks, or other locations where they may fall overboard.**
- **STOP! if someone falls overboard. Slowly turn the boat around, and keep the person in sight as you approach. Turn your engine off FIRST and then bring the person aboard.**
- **NEVER reverse your boat to pick someone up out of the water.**

## **WARNING**

### **SWIMMING/DIVING HAZARD**

- **Keep clear of areas designated only for swimmers and skin divers. Recognize markers used for such areas.**
- **Never swim when there is lightning in the area.**

### **SKIING HAZARDS**

- **Skiers must use a safety approved Personal Flotation Device (PFD).**
- **Ski only during daylight and in good visibility.**
- **Avoid shallow water, other boats, navigational aids and other obstructions.**
- **Keep at least 30 meters (100 ft.) from other objects.**
- **Never drive directly behind a water skier.**
- **A competent observer must watch the skier at all times. A competent observer is a person that has the ability to assess when a skier is in trouble, knows or understands water skiing hand signals and is capable of helping a skier.**
- **Keep a downed skier in constant sight.**
- **Turn off engine in gear before you get close to person in the water.**
- **Never back up to anyone in the water.**
- **Use caution in boat when skier is being towed. Sudden release of tow rope can cause it to backlash into the cockpit.**

### **PERSONAL INJURY HAZARD**

**Use transom tow ring only to pull water skiers. Unless specified by the manufacturer, any other use, such as parasailing, kite flying, towing other boats, etc. may create too much stress on the tow ring, resulting in personal injury and/or equipment damage.**

## Towed Inflatables

Towed inflatable types, aka tubes, produce tremendous stress on the tow point and rope, far greater than devices like water skis, knee boards or wake boards. When pulling a tube use both stern eye strong points in combination with a proper tube harness and tow rope. Parasails and kites should never be used with a recreational boat.

### ATTENTION

#### Personal Injury/Equipment Damage

**Ski tow pylons/tower/hardtop/ski eye tow points are not designed for use with tubes. The added stress of the tube may cause a dangerous recoil or damage the equipment. Damage to the pylon/tower/hardtop/ski tow eye is not covered by the boat or equipment manufacturer's warranty. When towing inflatables/tubes, use both stern eye strong points with a tube tow harness to attach the tube tow rope.**

## Engine Emergency Stop Switch

### ! WARNING

**Wear the lanyard at all times when operating the boat. Use it to stop only in an emergency. DO NOT use it to shut off the engine during normal operation**


Your boat is equipped with an engine emergency stop switch. The switch is located on the console, below the shift/throttle control. The ignition shut down safety switch incorporates a shut-off switch, switch clip, lanyard and lanyard clip, which is clipped to the operator when running.

If an emergency arises and the engine must be shut down, a pull on the cord to release the clip from the shut-off will shut off the engine.

This switch is designed to shut the engine off when the operator of the boat leaves the control station, either accidentally by falling into the boat, or by being ejected overboard. This would most likely occur as a result of poor operating practices.

The lanyard should be long enough to prevent inadvertent activation. Do not let the lanyard become entangled.

Engine Emergency Stop Switch  
Figure 1.17.1



### NOTICE

**This switch only works when used properly. The decision of whether to use an ignition safety switch or not rests with you, the operator.**

Accidental loss of power can be hazardous, particularly while docking or in heavy seas, strong current or high winds. Passengers and crew may lose balance and the boat may lose steering control.

Should the operator fall out of the boat at planing speed, it may take several seconds for the engine and propeller to stop turning. The boat may continue to coast for several hundred feet, causing injury to anyone in its path.

## 1<sup>st</sup> Mate™ Safety and Security System

The 1<sup>st</sup> Mate™ mobile app and wearable device integrate with Mercury systems to provide alerts, alarms, and distress communications designed to keep the captain and passengers safe. The system accommodates a captain and up to seven passengers. Features includes:

- Captain overboard event turns engine(s) off.
- Captain or passenger overboard event sounds alarm on the boat and via the app.
- Distress message capabilities to alert emergency contact(s) including location, heading, date and time of incident.



- Theft deterrent against boat-and-engine theft.

REFER TO THE OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.

### Float Plan

Float plans are important to you should you encounter problems on the water. A float plan should contain a description of your boat along with any distinguishing features. It should describe where you will be boating, your departure time and estimated return. The number and names of passengers, and destination should also be noted.

The float plan should be given to a friend or relative, so they can give the information to a national boating agency like the U.S. Coast Guard, in the event you do not return at the time specified on the float plan.

If there are any changes to the float plan they should be conveyed to the person holding the float plan. Once you return you should contact the person holding the float plan to let them know you are back.

### Chart Your Course

To avoid boating in unsafe areas where there are underwater obstructions, shallow water, unnavigable conditions such as dangerous currents, and others, you must chart a course. This means having and using National Oceanic and Atmospheric Administration (NOAA) charts for coastal waters, observing and understanding all navigational aids, using the knowledge and guidance of experienced boaters, and being aware of the tides and times where appropriate. If you are boating in an area you are unfamiliar with, proceed with caution and post a lookout to watch for hazards.

### Environmental Considerations

#### Fuel and Oil Spillage

Regulations prohibit discharging fuel or oily waste in navigable waters. Discharge is defined as any action which causes a film, sheen or discoloration on the water surface, or causes a sludge or emulsion beneath the water surface. A common violation is bilge discharge. Use rags or sponges to soak up fuel or oily waste, then dispose of it properly ashore.

## WARNING

**Hitting an object in or under the water or boating in dangerous currents can cause serious injury or death to occupants in the boat.**

**You must know where the hazards are and avoid them. In uncharted waters, boat very slowly and post a lookout.**

**If an object is struck or if you run aground:**

- **Shut the engine OFF**
- **Check the hull for damage**
- **Check propeller for damage**
- **If aground, consider the bottom grade before moving off, (damage to the hull and propellers could be worsened).**
- **Determine the tides and whether it will help or hinder you from the grounding.**
- **Do not have anyone other than a trained and competent service tow your boat.**

If there is much fuel or oil in the bilge, contact a knowledgeable marine service to remove it. Never pump contaminated bilge overboard. Help protect your waters.

#### Excessive Noise

Many areas regulate noise limits. Even if there are no laws, courtesy demands that boats operate quietly.

#### Wake / Wash

Power boat wakes can endanger people and vessels. Each power boat operator is responsible for injury or damage caused by the boat's wake. Be especially careful in confined areas such as channels or marinas. Observe "no wake" warnings.

## WARNING

**SPEED HAZARD - Watch your wake. It might capsize a smaller craft. You are responsible for damage caused by your wake.**

## CAUTION

**Reduce speed in congested waterway. Be alert for No Wake markers.**

### Homeland Security Restrictions

#### **DANGER**

**DO NOT approach within 100 yards of any U.S. Naval vessel without first contacting the vessel on VHF-FM channel 16. To do so will result in a quick and severe response.**

Recreational boaters have a role in keeping our waterways safe and secure. Violators of the restrictions below can expect a quick and severe response.

- **DO NOT** approach within 100 yards, and slow to minimum speed within 500 yards of any U.S. Naval vessel. If you need to pass within 100 yards of a U.S. Naval vessel for safe passage, you must contact the U.S. Naval vessel or the Coast Guard escort vessel on VHF-FM channel 16.
- Observe and avoid all security zones. Avoid commercial port areas, especially those that involve military, cruise line or petroleum facilities. Observe and avoid other restricted areas near dams, power plants, etc.
- **DO NOT** stop or anchor beneath bridges or in channels.

### America's Waterway Watch

In March, 2005, the U.S. Coast Guard officially launched *America's Waterway Watch* to encourage the boating public to report suspicious activities in our nation's ports and waterways. *America's Waterway Watch* simply asks anyone who works, lives, or recreates on the water to keep an eye out for suspicious activities. Anyone who spots such activity is asked to call the National Response Center's 24-hour hotline, 800-424-8802 or 877-24WATCH (877-249-2824).

### Warning Label Locations

Mounted at key locations throughout the boat (see figures 1.19.1 - 1.24.1), warning labels advise the owner/operator of imperative safety precautions to follow when operating and/or servicing equipment. **DO NOT REMOVE OR OBSTRUCT ANY WARNING LABEL.** Replace any label which becomes illegible.

## Warning Label Locations

Warning Label Locations  
Figure 1.20.1

**1** **WARNING**

Operating, servicing and maintaining a recreational marine vessel can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, service your vessel in a well-ventilated area and wear gloves or wash your hands frequently when servicing this vessel. For more information go to [www.P65warnings.ca.gov/marine](http://www.P65warnings.ca.gov/marine).


**2** **CAUTION**

**REMOVE ENGINE STEERING BRACKET BEFORE STARTING ENGINES**

**3**

- The joystick is for boat docking and low speed maneuvers.
- Use the joystick only when the ERC controls are in neutral.
- When the ERC controls are shifted into gear, the joystick disengages.
- To limit engine power during docking and maneuvering, engage the dock feature by pressing the DOCK button.
- To prevent the boat from being shifted into gear during operation and to disengage the joystick, engage the throttle-only feature by pressing the THROTTLE ONLY button.
- For complete details of features and operation, please refer to the operation, maintenance, and warranty manual.

90-879288287



**7** **LOOK BEFORE YOU PUMP!**

**USE E10 FUEL**

Do not use any fuel containing greater than 10 percent ethanol (E10) in this equipment. It may cause damage or failure and is prohibited by Federal Law. For more information, visit [www.epa.gov/e10fuel](http://www.epa.gov/e10fuel).

Ethanol Percentage

E10 10% E15 15% E85 85%

**6** **CAUTION**

**BRIDGE CLEARANCE UPPER TOWER = 16' 4"**

**4** **DANGER**

- CONTACT WITH A SPINNING PROPELLER WILL CAUSE SERIOUS INJURY OR DEATH.
- SHUT OFF ENGINES while people are in the water near the boat, on the swim platform, or on the boarding ladder.
- NEVER OPERATE IN REVERSE TOWARD A PERSON in the water.

**5** **WARNING**

**Carbon monoxide (CO) can cause brain damage or death.**

Carbon monoxide can be present in the cabin

Signs of carbon monoxide poisoning include nausea, headache, dizziness, drowsiness, and lack of consciousness.

Get fresh air if anyone shows signs of carbon monoxide poisoning.

Get fresh air if carbon monoxide detector alarm sounds

Carbon monoxide detector must be functioning at all times.

NW 205-05

**NOTICE**


**It is important to replace any damaged or unreadable label. Call your Boston Whaler dealer for replacement labels.**

**Replacement Part No.**

<b>1</b>	PROP 65 HANG TAG.....	1795087
<b>2</b>	CAUTION, REMOVE STEERING BRACKET.....	2166526
<b>3</b>	HANG TAG W/JOYSTICK LABEL KIT .....	2121785
<b>4</b>	WARNING, ROTATING PROPELLER.....	2417275
<b>5</b>	DANGER, CO HELM .....	1811368
<b>6</b>	BRIDGE CLEARANCE.....	2243584
<b>7</b>	E10 FUEL WARNING HANG TAG .....	2304853

## Warning Label Locations

Warning Label Locations  
Figure 1.21.1




### Replacement Part No.

- 1 VESSEL CERTIFICATION/CAPACITY ..... SEE FIGURE 2.2.1
- 2 LABEL, CALIFORNIA ARB COMPLIANCE ..... 2418954
- 3 MAXIMUM ENGINE WEIGHT 3000 LBS/1361 KG ..... 2410805
- 4 DANGER, CO TRANSOM ..... 1811367
- 5 WARNING DOCKSIDE WATER ..... 2028931
- 6 ENGINE FLUSH (OPTION) ..... 2258106
- 7 WARNING, ROTATING PROPELLER ..... 2417276
- 8 WARNING W/JOYSTICK LABEL KIT ..... 2121785
- 9 DANGER, TRANSOM DOOR ..... 2063385

### NOTICE

It is important to replace any damaged or unreadable label. Call your Boston Whaler dealer for replacement labels.

Warning Label Locations (Cont'd)  
Figure 1.22.1




**Replacement Part No.**

<b>1</b>	WARNING, LEAKING FUEL (CANADA OPTION).....	2175077
<b>2</b>	WARNING FUEL HAZARD .....	2096004
<b>3</b>	FUEL RECOMMENDATION.....	2038447
<b>4</b>	DANGER, STAY CLEAR OF MOVING PARTS.....	2028932
<b>5</b>	CAUTION, AVOID PROPERTY DAMAGE .....	2147835
<b>6</b>	CAUTION, AVOID INJURY, BOAT MOVEMENT .....	1836858
<b>7</b>	CANADIAN, DO NOT STORE FUEL (OPTION).....	2175076
<b>8</b>	WARNING, DO NOT STORE FUEL .....	1691003

**NOTICE**

It is important to replace any damaged or unreadable label. Call your Boston Whaler dealer for replacement labels.

Warning Label Locations (Cont'd)  
Figure 1.23.1






### Replacement Part No.

- 1** WARNING INTERMEDIATE BREAKER .....2029122
- 2** WARNING, DOOR SECURED..... 2063402
- 3** WARNING, RUNNING BOAT WITH DOOR..... 2028922
- 4** DANGER, CO CABIN ..... 1812911
- 5** PATENT NOTICE..... 2088481
- 6** PATENT, BOW THRUSTER (OPTION) ..... 2063996
- 7** PATENT, HAWSE PIPE/DRINK HOLDER..... 2063995
- 8** SOS, DISPOSAL OF GARBAGE..... 2029125

**NOTICE**  
It is important to replace any damaged or unreadable label. Call your Boston Whaler dealer for replacement labels.

Warning Label Locations (Cont'd)  
Figure 1.24.1

**DISCHARGE OF OIL PROHIBITED**  
THE FEDERAL WATER POLLUTION CONTROL ACT PROHIBITS THE DISCHARGE OF OIL OR OILY WASTE INTO OR UPON THE NAVIGABLE WATERS OF THE UNITED STATES OR THE WATERS OF THE CONTIGUOUS ZONE IF SUCH DISCHARGE CAUSES A FILM OR SHEEN UPON OR A DISCOLORATION OF THE SURFACE OF THE WATER OR CAUSES A SLUDGE OR EMULSION BENEATH THE SURFACE OF THE WATER.  
VIOLATORS ARE SUBJECT TO A PENALTY OF \$5,000.



**CAUTION**  
AVOID INJURY  
BOAT MOVEMENT MAY CAUSE LID TO FALL  
KEEP HANDS AND FEET CLEAR OF EDGES WHEN  
HATCH IS OPEN  
MRP# 1836858

**NOTICE**  
THIS BOAT IS EQUIPPED WITH  
AN OPTIONAL DIRECT OVERBOARD  
DISCHARGE VALVE. DISCHARGING OF  
SEWAGE DIRECTLY OVERBOARD  
IS FOR USE WHERE APPROVED ONLY  
MRP# 1745156

**NOTICE**  
Fixed fire extinguisher system must  
be suitable for gross compartment  
volume of 200 cu ft.  
MRP# 2201910

**Replacement  
Part No.**

- 1 DISCHARGE OF OIL.....2063375
- 2 BATTERY LOCATION PLATE.....2243783
- 3 SEACOCK LOCATIONS PLATE.....2243785
- 4 CAUTION, AVOID INJURY, BOAT MOVEMENT ..... 1836858
- 5 NOTICE, FIRE EXT. SYSTEM.....2201910
- 6 NOTICE, OVERBOARD DISCHARGE.....2063381

**NOTICE**  
It is important to replace any damaged or unreadable label. Call your Boston Whaler dealer for replacement labels.

## Key to Symbols on Controls

Although not used in this manual, some of these symbols may be found on the controls, gauges, and hardware on this vessel. This page is to help you understand what the symbols mean.



 ENGINE EXHAUST CONTROL	 ENGINE	 ENGINE START	 ENGINE STOP	 ENGINE COOLANT WATER JACKET TEMPERATURE	 ENGINE OIL PRESSURE
 FUEL GENERAL	 FUEL LEVEL	 LEADED FUEL	 UNLEADED FUEL	 FUEL FILTER	 ENGINE ROTATIONAL SPEED
 BILGE PUMP	 OUTBOARD DRIVE	 OUTBOARD DRIVE TILT	 PROPELLER	 SEAWATER	 SEWAGE
 BILGE BLOWER	 SINGLE LEVER CONTROL	 LIFT POINT / SLING LOCATION	 LIFT POINT	 RUNNING LIGHTS UNDER POWER	 ROTARY CONTROL (WIDTH OF SYMBOL INDICATES INCREASE)
 ANCHOR	 ANCHOR LIGHT	 INTERIOR LIGHT	 HORN	 WINDSHIELD WIPER AND WASHER	 MAGNETIC COMPASS
 PROPULSION SYSTEM TRIM BOW UP	 PROPULSION SYSTEM TRIM BOW DOWN	 PROPULSION SYSTEM TRIM	 TRIM TAB TRIMMING OPERATION	 FRESH WATER	 GRAY WATER
 OIL	 BATTERY	 CONTROL LEVEL OPERATION DIRECTIONS	 WATER PUMP	 ACCESSORY	 NO OPEN FLAME NO SMOKING



THIS PAGE INTENTIONALLY LEFT BLANK

### Construction Standards

Boston Whaler® is dedicated to creating a superior product which will provide comfort, performance, safety and dependability. All of our boats comply with the safety standards set by the United States Coast Guard and are designed, engineered and manufactured in accordance with applicable recommendations and guidelines of the American Boat and Yacht Council (ABYC) and certified by the National Marine Manufacturers Association (NMMA).

### Our Hull

Boston Whaler hulls are constructed with our patented Unibond™ construction process. This involves foam injection into a closed mold system where the foam expands to fill all voids in the hull. When the finished product is pulled from the mold, the hull and deck are chemically bonded to form a solid, inseparable unit.

**Hull Construction**  
Figure 2.1.1

- 1 NO AIR VOIDS
- 2 HIGH DENSITY CLOSED CELL NON-ABSORBENT FOAM
- 3 HIGH QUALITY RESINS AND GELCOATS
- 4 WOVEN GLASS MATTING


### Hull Identification Number

The hull identification number (HIN) is located on the starboard side of the transom.

This is the most important identifying factor and must be included in all correspondence related to your vessel. Also of vital importance are the engine serial numbers, part numbers, etc. when writing about or ordering parts for your engine.

### Hull Identification Number (HIN)

Figure 2.1.2



Record your HIN here:

### Servicing Your Boston Whaler

When your Whaler requires service or maintenance work, it should be taken to an authorized Boston Whaler dealer.

To find a Boston Whaler dealer in your area call **800-942-5379** (domestic/international).

In the unlikely event that a problem is not handled to your satisfaction, discuss any warranty related problems directly with the service manager of the dealership or your sales person. Give the dealership an opportunity to help the service department resolve the matter for you.

### Manufacturer's Certification

All boats must comply with federal regulations regarding maximum capacities. The *Specifications and Dimensions* table, listed later in this chapter, indicates the maximum weight, number of persons, and maximum horsepower this vessel is rated to handle. Do not exceed these specifications. The information on the certification plate does not relieve the operator of responsibility. Use common sense and sound judgement when placing equipment and/or passengers in this vessel. Do not load to capacity in poor weather/rough water. The number of seats does not indicate passenger capacity in poor weather/rough water. At speeds above idle, all passengers should be seated on the seats provided.

**DANGER**

Never carry more weight or passengers than indicated on the certification plate, regardless of weather or water conditions.

### Certification Plates

*NOTE: The type of capacity plate will vary dependent on the local governing authority.*

#### NMMA Plate

An NMMA Certification indicates that your boat has been verified by the National Marine Manufacturers Association (NMMA) to be in compliance with applicable federal regulations and American Boat and Yacht Council (ABYC) standards. Recreational vessels up to 20 feet (6.1 meters) have passenger and cargo weight capacities compliant with USCG regulations. Vessels 26 feet (7.9 meters) and under have passenger and cargo weight capacities compliant with ABYC standards. Vessels over 26 feet have NMMA yacht certification.



#### Canadian Conformity Plate

A Canada Compliance Notice indicates that your boat has been certified to comply with construction standards for small vessels by Transport Canada (TC). Recreational vessels up to 6 meters (19.7 feet) have passenger and cargo weight capacities compliant with TC regulations. Vessels over 6 meters are also compliant with TC regulations, but do not state capacities on the plate.

**CANADIAN COMPLIANCE NOTICE**  
**AVIS DE CONFORMITE CAÑADIEN**

Boston Whaler (BWC) Edgewater, FL, USA
MODEL / MODLÈ: 380 OUTRAGE
DESIGN CATEGORY: B

THE MANUFACTURER DECLARES THAT THIS VESSEL COMPLIES WITH THE PLEASURE CRAFT CONSTRUCTION REQUIREMENTS OF THE SMALL VESSEL REGULATIONS, AS THEY READ ON THE DAY ON WHICH THE CONSTRUCTION OF THE VESSEL WAS STARTED OR ON THE DAY ON WHICH THE VESSEL WAS IMPORTED.


LE FABRICANT ATTESTE QUE CE BÂTIMENT EST CONFORME AUX EXIGENCES DE CONSTRUCTION DES EMBARCATIONS DE PLAISANCE DU RÉGLEMENT SUR LES PETITS BÂTIMENTS, EN VIGUEUR À LA DATE DU DÉBUT DE SA CONSTRUCTION OU À LA DATE DE SON IMPORTATION.

2243958

## Chapter 2 • General Information

### CE Mark Builder's Plate

A CE mark indicates that your boat has been certified for the EU and the passenger and cargo weight capacities comply with the International Organization for Standardization (ISO) regulations.



2399399

### Australian Builder's Plate

An Australian Builder's Plate indicates that your boat has been certified and the passenger and cargo weight capacities comply with either the International Organization for Standardization (ISO) regulations or American Boat and Yacht Council (ABYC) standards as noted on the capacity plate.

#### Standard Boat



2410447



#### Standard Boat, Upper Station



2410448

### Emission Control System Plate

An Emissions Control System Information plate indicates that your boat is compliant with California emissions regulations.



2418954

### Certification Design Category

**A:** A recreational craft given design category A is considered to be designed for winds that may exceed wind force 8 (Beaufort scale) and significant wave heights of four meters and above but excluding abnormal conditions, such as storm, violent storm, hurricane, tornado and extreme sea conditions or rogue waves.

**B:** A recreational craft given design category B is considered to be designed for a wind force up to, and including, 8 and significant wave heights up to, and including 4 m.

**C:** A watercraft given design category C is considered to be designed a wind force up to, and including six and significant wave heights up to, and including, 2 m.

**D:** A watercraft given design category D is considered to be designed for a wind force up to, and including 4 and significant wave heights up to, and including, 0,3 m, with occasional waves of 0,5 m maximum height.

The significant wave height is considered to be the primary factor for determining design category. Other parameters (e.g. meteorological) are descriptions of when these wave heights may be expected to occur.

### NOTICE

**The 380 OUTRAGE is category B**

### Power Capacity

The certification plate, as well as “Specifications & Dimensions” on the following page has the maximum rated power listed for your boat. Do not exceed this rating. The various engine types offered today are more powerful and require constant maintenance to stay at optimal performance. It is required of the owner/operator to read all information regarding safety features, warning notices and maintenance schedules for continued safe operation of the engine.

The engines on the 380 Outrage have been tested

and proven to be best suited for general use under normal conditions and load.

If you are re-powering your Boston Whaler, you should pay particular attention to the maximum/minimum horsepower and maximum safe engine weight load for which your boat is rated.

### NOTICE

**The 380 Outrage is designed for a maximum outboard engine weight of 3000 LBS (1361 kg).**

### WARNING

**Do not exceed the maximum engine power rating for your boat.**


**Use caution while accelerating. Ensure passengers are safely seated in designated areas of the boat and all gear is stowed securely.**

### NOTICE

**Always adjust the speed and direction of the craft to the varying sea conditions.**

### Dimensions & Clearances

Figure 2.5.1



### Specifications & Dimensions

(Specified measurements are approximations and are subject to variance.)

Overall Length	38'	11.58 m	Maximum Engine Weight	2,800 lbs. 1270 kg
Bridge Clearance			Maximum Weight,	
- with hardtop	9'	2.70 m	(passengers, engines, gear <sup>2</sup> )	5,214 lbs 3146 kg
- with optional radar	10' 4"	2.8 m	(passengers, gear <sup>2</sup> )	3,146 lbs 1427 kg
- w/optional upper control	16' 4"	4.98 m	Persons	16
Beam	11'8"	3.56 m	Maximum Horsepower	1,600 HP 1193 kw
Draft, (boat only <sup>1</sup> )	23.5"	0.6 m	Minimum Horsepower	900 HP 671 kw
Weight (dry, no engine)	14,500 lbs. 6577 kg		Fuel Capacity:	445 gal. 1685 L
Weight (fuel, water, engine)	19,715 lbs. 8942 kg		Water Capacity	60 gal. 227 L
Swamped Capacity	5,000 lbs 2268 kg		Waste Capacity	10 gal. 37.8 L

<sup>1</sup> Optional equipment and loading of the boat will affect the draft measurements. Follow the recommendations regarding the maximum amount of weight your boat can safely carry.


<sup>2</sup> Exceeding this weight will affect the boat's performance. **DO NOT** Exceed the weight listed.

*NOTE: Equipment may vary depending on options selected.*


## Passenger Areas


Deck Occupancy  
Figure 2.6.1



### Working deck:

 This area is intended for occupation ONLY while mooring, anchoring, loading/unloading or when the boat is at rest.

### Accommodation deck:

 Movement in this area should be done with extreme caution while the boat is underway. A sudden shift in boat direction can cause a loss of balance and lead to injury or death.

 Do Not stand or walk on this area while underway. Serious injury could result. If necessary, stand or walk only where non-skid is applied.



NOTE: Hardtop removed for clarity

### WARNING

- Gelcoat surfaces are slippery when wet. Use extreme caution when walking on wet surfaces.
- Never occupy the working decks while the boat is underway.
- Use care when waxing to ensure that walkways are not made dangerously slippery.

### DANGER

To avoid risk of injury or death, shut off engines when near swimmers or prior to using swim ladder.

### DANGER

Be aware of your footing while the boat is underway, slipping or falling could result in serious injury or death, especially if the boat is in motion or in rough seas. Keep the accommodation deck clean, so if movement is necessary it will be free of obstruction.


## Recommended Passenger Locations

Recommended Seating & On-Plane Locations


Figure 2.7.1

**! WARNING**

**NEVER** allow passengers to ride in an area (i.e. bow, gunnels, transom, etc. that will pose a hazard to themselves or the boat.



NOTE: Hardtop removed for clarity




**RECOMMENDED SEATING**  
While moored, at idle or at speed under 5 mph

**RECOMMENDED ON-PLANE LOCATIONS**



## Location of Thru-Hull Fittings

Thru-Hull Fittings  
Figure 2.8.1



- |  |  |
|--|--|
| ① PORT ANCHOR LOCKER DRAIN   | ⑩ PORT FISHBOX PUMP OUT  |
| ② PORT BOW STORAGE DRAIN   | ⑪ BILGE PUMP DISCHARGE   |
| ③ FORWARD BILGE PUMP DISCHARGE   | ⑫ LIVWELL DRAIN  |
| ④ FORWARD FISHBOX GUTTER DRAIN   | ⑬ STARBOARD ANCHOR LOCKER DRAIN  |
| ⑤ A/C DISCHARGE  | ⑭ STARBOARD BOW STORAGE DRAIN  |
| ⑥ LEANING POST LIVWELL (OPTION)<br>DELUXE LEANING POST                   | ⑮ SHOWER SUMP DRAIN, BUCKET DRAIN,<br>HOT WATER DISTILL  |
| ⑦ AFT LIVWELL INTAKE   | ⑯ FORWARD FISHBOX PUMPOUT  |
| ⑧ MACERATOR DISCHARGE  | ⑰ FREEZER PLATES DRAIN (OPTION)  |
| ⑨ A/C DISCHARGE (OPTION),<br>GYROSCOPIC STABILIZER<br>DISCHARGE (OPTION) | ⑱ A/C SYSTEM,<br>FREEZER PLATES INTAKE (OPTION),<br>HELM A/C (OPTION)                                  |
| ⑩ PORT FISHBOX PUMP OUT  | ⑲ GENERATOR INTAKE   |
| ⑪ BILGE PUMP DISCHARGE   | ⑳ GYROSCOPE STABILIZER INTAKE (OPTION)   |
| ⑫ LIVWELL DRAIN  | ㉑ HIGH WATER BILGE PUMP DISCHARGE  |
| ⑬ STARBOARD ANCHOR LOCKER DRAIN  | ㉒ STARBOARD FISHBOX PUMP OUT   |
| ⑭ STARBOARD BOW STORAGE DRAIN  | ㉓ GENERATOR EXHAUST OUTLET   |
| ⑮ SHOWER SUMP DRAIN, BUCKET DRAIN,<br>HOT WATER DISTILL                  | ㉔ GYROSCOPIC STABILIZER DRAIN (OPTION)   |
|  | ㉕ BILGE VENT   |
|  | ㉖ DECK DRAIN   |
|  | ㉗ COCKPIT A/C DRAIN (OPTION),<br>GYROSCOPIC BUCKET DRAIN (OPTION),<br>BAIT STATION SINK DRAIN (OPTION) |
|  | ㉘ GARBOARD DRAIN   |

### NOTICE


- **The deck drains provide self-bailing capabilities while the boat is static in the water and no passengers on board. This feature prevents the accumulation of water in the cockpit.**
- **Depending on the type of boat you have, you may have underwater fittings that need drain plugs. Garboard drain plugs and fishbox drain plugs need to be in place before the boat goes into the water. Any fitting that will be underwater needs to be plugged or the seacock needs to be closed.**
- **Through hull fittings and deck drain scupper flaps should be checked for proper seal annually. When the boat is in the water the underwater fittings can be checked for dripping. It is recommended that the underwater fittings be removed, cleaned and resealed every other year.**
- **If the through hull fittings need to be replaced, it is recommended that an authorized Boston Whaler® dealer perform this type of repair. Through hull fittings that are improperly installed can cause premature hull failure and may void the Boston Whaler® limited warranty.**
- **A standard 1" "Snap-Tite" plug can be used to replace the garboard drain plug in your boat. It is recommended that you carry spare plugs to be used in the event that the garboard drain plug becomes lost or damaged.**

## General Layout

General Layout, Exterior (Hardtop removed for clarity)


Figure 2.10.1

- 1 ANCHOR LOCKER W/THRU HULL ANCHOR ROLLER
- 2 STAINLESS STEEL BOW RAIL (OPTION)
- 3 BOW PULL UP CLEATS (P&S)
- 4 BOW ROD HOLDERS (P&S)
- 5 BOW, UNDER SEAT STORAGE
- 6 FORWARD SEATING W/FOLDING BACKREST (P&S)
- 7 INSULATED FORWARD FISHBOX W/PUMP OUT
- 8 INTEGRATED CUP HOLDERS (P&S)
- 9 STEREO SPEAKERS (P&S)
- 10 GUNNEL MOUNTED ROD HOLDERS (10 P&S)
- 11 LOW PROFILE INTERIOR STAINLESS STEEL RAILS
- 12 SUN LOUNGE BACKREST W/FOLDING ARMREST
- 13 MAGNETIC COMPASS
- 14 FOLD-DOWN TROLLING SEATS (P&S) (OPTION)
- 15 MID-SHIP PULL UP CLEATS (P&S)
- 16 CABIN ENTRY DOOR
- 17 FUEL FILL
- 18 PORT HELM COMPANION SEAT
- 19 EXPANDABLE FRESH WATER SHOWER
- 20 IN-DECK FISHBOX W/PUMP OUT (P&S)
- 21 DIVE/BOARDING DOOR W/REMOVABLE LADDER
- 22 DIVE DOOR LADDER BRACKET
- 23 FOLD AWAY GRAB RAIL FOR DIVE/BOARDING ACCESS
- 24 HAWSE PIPE W/AFT CLEAT UNDER (P&S)
- 25 TRANSOM MOUNTED ROD HOLDERS (2)
- 26 WASTE DOCKSIDE PUMP OUT
- 27 PULL-UP CROSS TIE CLEAT (P&S)
- 28 PRESSURIZED, 60 GALLON TRANSOM LIVEWELL
- 29 MERCURY 4-STROKE ENGINE
- 30 EXPANDABLE SWIM LADDER WITH COVER
- 31 FOLDAWAY STERN BENCH SEAT
- 32 STAINLESS STEEL GRAB RAIL
- 33 TRANSOM DOOR W/STAINLESS STEEL LATCH
- 34 MECHANICAL EQUIPMENT HATCH
- 35 AFT COCKPIT TABLE BRACKETS (OPTION)
- 36 FOLDAWAY STARBOARD COCKPIT SEAT (OPTION)
- 37 AFT FACING COUCH W/INSULATED STORAGE
- 38 STARBOARD HELM COMPANION SEAT
- 39 FRESH WATER FILL
- 40 ADJUSTABLE CAPTAIN'S SEAT
- 41 CONSOLE



- 42 DC DISTRIBUTION PANEL
- 43 ACRYLIC WINDSHIELD
- 44 WINDSHIELD WIPER
- 45 FWD CONSOLE LOUNGE W/STORAGE
- 46 STEREO REMOTE, BOW TABLE SWITCH, FWD FISHBOX PUMP OUT SWITCH
- 47 BOW TABLE (OPTION)


General Layout, Bilge  
Figure 2.11.1



- |  |   |
|--|---|
| ① ENGINE FLUSH PUMP (OPTION)                   | ⑱ BATTERY SWITCH                        |
| ② AUTOMATIC FIXED FIRE EXTINGUISHER            | ⑲ AUTOMATIC CHARGING RELAY (ACR)        |
| ③ PORT FISHBOX PUMP OUT PUMP                   | ⑳ STARBOARD ENGINE BATTERY              |
| ④ WASTE MACERATOR PUMP                         | ㉑ FLOAT SWITCH                          |
| ⑤ AFT LIVEWELL INTAKE PUMP                     | ㉒ EMERGENCY HIGH WATER FLOAT SWITCH     |
| ⑥ POWER STEERING PUMP (OPTION)                 | ㉓ RAW WATER WASHDOWN INTAKE             |
| ⑦ DELUXE LEANING POST LIVEWELL INTAKE (OPTION) | ㉔ POWER STEERING PUMP                   |
| ⑧ POWER STEERING PUMP (OPTION)                 | ㉕ GENERATOR INTAKE                      |
| ⑨ RAW WATER WASHDOWN PUMP                      | ㉖ GYROSCOPIC STABILIZER INTAKE (OPTION) |
| ⑩ BATTERY CHARGER                              | ㉗ STARBOARD FISHBOX PUMP OUT PUMP       |
| ⑪ FRESH WATER PUMP                             | ㉘ A/C PUMP                              |
| ⑫ 60 GAL (227 L) FRESH WATER TANK              | ㉙ GENERATOR MUFFLER                     |
| ⑬ THRUST VECTOR MODULE                         | ㉚ BILGE BLOWER                          |
| ⑭ 445 GAL (1,684.5 L) FUEL TANK                | ㉛ HIGH WATER (2000 GPH) BILGE PUMP      |
| ⑮ PORT ENGINE BATTERY                          | ㉜ 7.5KW GENERATOR                       |
| ⑯ FRESH WATER DISTRIBUTION MANIFOLD            | ㉝ 10 GAL (32.8 L) HOLDING TANK          |
| ⑰ CENTER ENGINE BATTERY                        | ㉞ BILGE PUMP (2000 GPH)                 |
|  | ㉟ OVERBOARD DISCHARGE                   |


*NOTE: When equipped with optional V12 engines, equipment configuration varies.*

General Layout, Forward Bilge  
Figure 2.12.1



- |                                 |                                      |
|---------------------------------|--------------------------------------|
| ① 12,000 BTU CABIN AIR HANDLER  | ⑭ BATTERY CHARGER                    |
| ② SHOWER SUMP                   | ⑮ BOW THRUSTER (OPTION)              |
| ③ FORWARD BILGE PUMP (1100 GPH) | ⑯ FORWARD FISHBOX PUMP OUT PUMP      |
| ④ FUSE BLOCK                    | ⑰ BOW THRUSTER FUSE                  |
| ⑤ DEPTH SOUNDER (OPTION)        | ⑱ BATTERY SWITCH (BOW THRUSTER)      |
| ⑥ DOWN VISION SOUNDER (OPTION)  | ⑲ STEREO AMPS                        |
| ⑦ CZONE MODULE                  | ⑳ FREEZER PLATE RELAY (OPTION)       |
| ⑧ DISPLAY MODULE                | ㉑ A/C COMPRESSOR PUMP RELAY (OPTION) |
| ⑨ SIRIUS RECEIVER (OPTION)      | ㉒ FREEZER PLATE COMPRESSOR (OPTION)  |
| ⑩ BATTERY SWITCH (HOUSE)        | ㉓ STEREO RECEIVER                    |
| ⑪ 6 GAL (22.7 L) WATER HEATER   | ㉔ DISPLAY MODULE                     |
| ⑫ BATTERY TRAYS*                |                                      |
| ⑬ ISOLATION TRANSFORMER         |                                      |

General Layout, Helm and upper Helm Station  
Figure 2.13.1




- |                                  |                                    |
|----------------------------------|------------------------------------|
| ① MAGNETIC COMPASS               | ⑭ ENGINE DIAGNOSTIC PORT           |
| ② 12V ACCESSORY RECEPTACLE       | ⑮ CONSOLE DRAIN                    |
| ③ STORAGE TRAY                   | ⑯ TRIM TAB CONTROL PAD             |
| ④ USB INPUT                      | ⑰ ENGINE EMERGENCY STOP SWITCH     |
| ⑤ A/C VENTS (OPTION)             | ⑱ FIRE SUPPRESSION INDICATOR LIGHT |
| ⑥ CONSOLE SWITCH PANEL           | ⑲ VHF RADIO (OPTION)               |
| ⑦ STEREO REMOTE                  | ⑳ STAINLESS STEEL STEERING WHEEL   |
| ⑧ HELM DISPLAY                   | ㉑ STAINLESS STEEL GRAB RAIL        |
| ⑨ SPOTLIGHT REMOTE (OPTION)      | ㉒ HORN SWITCH                      |
| ⑩ BOW THRUSTER JOYSTICK (OPTION) | ㉓ VHF SPEAKER                      |
| ⑪ JOYSTICK PILOTING              |                                    |
| ⑫ THROTTLE AND SHIFT CONTROL     |                                    |
| ⑬ HELM DISPLAY CARD READER       |                                    |

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY ON THE ELECTRONIC EQUIPMENT INSTALLED ON YOUR BOAT.

## Chapter 2 • General Information


General Layout, Port Aft Cockpit  
Figure 2.14.1



- |  |  |
|--|--|
| ① WATERPROOF STEREO SPEAKER (P&S)  | ⑫ DIVE LADDER BRACKET                          |
| ② ENGINE FLUSH SWITCH (OPTION)   | ⑬ DIVE DOOR FRESH WATER SHOWER                 |
| ③ RAW WATER WASHDOWN   | ⑭ GRAB RAIL                                    |
| ④ 12V/30AMP DC RECEPTACLE FOR ELECTRIC REELS AND/OR DOWNRIGGERS (P&S) (OPTION) | ⑮ TRANSOM MOUNTED ROD HOLDER                   |
| ⑤ AFT CLEAT (P&S)  | ⑯ BILGE VENT                                   |
| ⑥ GUNWALE MOUNTED ROD HOLDER (P&S)   | ⑰ 60 GAL (227 L) LIVEWELL                      |
| ⑦ SWING AWAY GRAB RAIL FOR DIVE DOOR   | ⑱ DOCKSIDE PUMPOUT DECK FITTING                |
| ⑧ DOWNRIGGER WEIGHT CRADLE (P&S)   | ⑲ STERN POP-UP CLEAT                           |
| ⑨ STAINLESS STEEL TOE RAIL   | ⑳ DECK DRAIN                                   |
| ⑩ STAINLESS STEEL LATCH  | ㉑ AUTOMATIC ENGINE FLUSH HOSE FITTING (OPTION) |
| ⑪ DIVE/BOARDING DOOR   | ㉒ DOCKSIDE WATER HOSE FITTING                  |

## Chapter 2 • General Information

General Layout, Starboard Aft Cockpit  
Figure 2.15.1




- |  |                                      |
|--|--------------------------------------|
| ① FRESH WATER FAUCET   | ⑫ STAINLESS STEEL GRAB RAIL          |
| ② MANUAL AUTOMATIC FIRE SUPPRESSION SYSTEM                                     | ⑬ LED LIGHT                          |
| ③ GUNNEL MOUNTED ROD HOLDER  | ⑭ WATERPROOF STEREO SPEAKER (P&S)    |
| ④ LINE 1 SHORE POWER BREAKER   | ⑮ AFT CLEAT                          |
| ⑤ LINE 2 SHORE POWER BREAKER   | ⑯ UNDER GUNNEL ROD HOLDER            |
| ⑥ LINE 2 SHORE POWER ELCI (EQUIPMENT LEAKAGE CIRCUIT INTERRUPTER)              | ⑰ STAINLESS STEEL TOE RAIL           |
| ⑦ LINE 1 SHORE POWER ELCI (EQUIPMENT LEAKAGE CIRCUIT INTERRUPTER)              | ⑱ DOWNRIGGER WEIGHT HOLDER (P&S)     |
| ⑧ 12V/30AMP DC RECEPTACLE FOR ELECTRIC REELS AND/OR DOWNRIGGERS (P&S) (OPTION) | ⑲ TRANSOM DOOR                       |
| ⑨ LINE 2 SHORE POWER RECEPTACLE  | ⑳ STAINLESS STEEL LATCH              |
| ⑩ LINE 1 SHORE POWER RECEPTACLE  | ㉑ FOLDAWAY STERN BENCH SEAT          |
| ⑪ TRANSOM SHOWER   | ㉒ DIVE DOOR BOARDING LADDER (STOWED) |
|  | ㉓ AFT STORAGE                        |
|  | ㉔ RAW WATER WASHDOWN                 |



## Chapter 2 • General Information

General Layout, Helm Station Seating  
Figure 2.16.1




- |  |                                    |
|--|------------------------------------|
| ① AFT FACING LOUNGE SEAT   | ⑨ CENTER SEAT ACTUATOR SWITCH      |
| ② SUMMER KITCHEN (OPTION)  | ⑩ STAINLESS STEEL LATCH            |
| ③ DELUXE LEANING POST (OPTION)   | ⑪ ACCESS HATCH (OPTION)*           |
| ④ ADJUSTABLE STARBOARD HELM COMPANION SEAT<br>W/ FLIP UP THIGH RISE AND FOLD DOWN<br>ARM RESTS | ⑫ FOLD DOWN VISIBILITY PLATFORM    |
| ⑤ ROD HOLDERS (5)  | ⑬ STORAGE POCKET                   |
| ⑥ ELECTRICALLY ADJUSTABLE CAPTAINS<br>CHAIR W/ FLIP UP THIGH RISE AND FOLD<br>DOWN ARM RESTS   | ⑭ 120 VOLT RECEPTACLE              |
| ⑦ ADJUSTABLE PORT HELM COMPANION SEAT<br>W/ FLIP UP THIGH RISE AND FOLD DOWN<br>ARM RESTS      | ⑮ CUP HOLDERS                      |
| ⑧ FOLD DOWN FOOTREST   | ⑯ 3-DRAWER TACKLE STORAGE (OPTION) |
|  | ⑰ REFRIGERATOR/FREEZER (OPTION)    |

\*Behind visibility platform

## Chapter 2 • General Information

General Layout, Aft Facing Couch  
Figure 2.17.1




- ① AFT FACING COUCH W/INSULATED COOLER UNDER SEAT  
40 GAL (151.4) PRESSURIZED AERATED LIVEWELL REPLACES COOLER (OPTION)
- ② CUP HOLDERS
- ③ STAINLESS STEEL GRAB RAIL
- ④ 120V OUTLET
- ⑤ PORT PULL -OUT REFRIGERATOR / FREEZER
- ⑥ ACCESS HATCH\*
- ⑦ FOLD-DOWN WORK TABLE DEPLOYED
- ⑧ STORAGE DRAWERS

\*Behind visibility platform

## Chapter 2 • General Information


General Layout, Deluxe Leaning Post/Bait Prep Center  
Figure 2.18.1



- ① DELUXE LEANING POST
- ② STORAGE LID W/TOOL HOLDERS, STORAGE NETS, AND LEADER REELS
- ③ STORAGE LID W/STORAGE SHELF, PAPER TOWEL HOLDER, AND STORAGE NETS (OPTION)\*
- ④ 3-DRAWER STORAGE FOR SUMMER KITCHEN (OPTION)
- ⑤ 12V/120V REFRIGERATOR/FREEZER
- ⑥ 120V OUTLET
- ⑦ STORAGE
- ⑧ SINK WITH FRESH WATER FAUCET / REMOVABLE COVER
- ⑨ 30 GAL (113.6) PRESSURIZED AERATED LIVWELL (OPTION)
- ⑩ ELECTRIC GRILL


\*Must choose summer kitchen option

General Layout, Port Interior  
Figure 2.19.1




- |                            |                                     |
|----------------------------|-------------------------------------|
| ① STEREO REMOTE            | ⑨ PORT SETTEE W/FOLD DOWN SEAT BACK |
| ② USB DUAL CHARGING DOCK   | ⑩ ROD SUPPORT RACK                  |
| ③ A/C TOUCH SCREEN DISPLAY | ⑪ ROD TIP SUPPORT                   |
| ④ INTERIOR LIGHT SWITCH    | ⑫ OPENING PORT LIGHT                |
| ⑤ AC DISTRIBUTION PANEL    | ⑬ STEREO SPEAKER                    |
| ⑥ ENTRY STEPS              | ⑭ REEL HOLDER                       |
| ⑦ A/C COMPRESSOR ACCESS    | ⑮ A/C VENT                          |
| ⑧ CO MONITOR               | ⑯ STORAGE                           |

General Layout, Starboard Interior  
Figure 2.20.1



- |                          |  |
|--------------------------|--|
| ① 12V GFI RECEPTACLE     | ⑦ GALLEY FAUCET                          |
| ② USB DUAL CHARGING DOCK | ⑧ HEAD ENTRY                             |
| ③ STEREO SPEAKER         | ⑨ CABIN ENTRY STEPS                      |
| ④ GRAB RAIL              | ⑩ STORAGE                                |
| ⑤ MICROWAVE              | ⑪ ACCENT LIGHT                           |
| ⑥ OPENING PORT LIGHT     | ⑫ STARBOARD SETTEE W/FOLD DOWN SEAT BACK |


General Layout, Head Interior  
Figure 2.21.1



- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>① TEAK SHELF</li> <li>② FOLD AWAY TEAK SEAT</li> <li>③ SHOWER SPRAYER WAND</li> <li>④ A/C VENT</li> <li>⑤ FOLD AWAY HOOK (3)</li> <li>⑥ HELM ACCESS PANEL</li> <li>⑦ TOILET PAPER HOLDER</li> <li>⑧ LIGHT SWITCH</li> </ul> | <ul style="list-style-type: none"> <li>⑨ VACUFLUSH TOILET</li> <li>⑩ VACUFLUSH/ OVERBOARD DISCHARGE PANEL*</li> <li>⑪ ACCESS PANEL (FREEZER PLATE COMPRESSOR) (OPTION)</li> <li>⑫ THRU HULL ACCESS</li> <li>⑬ OPENING PORT LIGHT</li> <li>⑭ MIRROR</li> </ul> |
|--|---|

\*See page 3-19 for operation

General Layout, Console Lounge  
Figure 2.22.1




- ① LOCKABLE STORAGE GARAGE/LOUNGE
- ② ADJUSTABLE ARM REST (P&S)
- ③ CENTER FOLD DOWN ARM REST
- ④ DUAL USB CHARGING DOCK
- ⑤ SMALL ITEM STORAGE
- ⑥ CUP HOLDERS
- ⑦ DIVE TANK RACKS (4) (OPTION)

- ⑧ 120V RECEPTACLE
- ⑨ COURTESY LIGHT (P&S)
- ⑩ 5 GAL BUCKETS (2)
- ⑪ 36 QUART (34 L) COOLER

## Chapter 2 • General Information

General Layout, Hardtop  
Figure 2.23.1

**CAUTION**  
Accent lights are not to be used when navigational lights are in use as this may interfere with the effectiveness of the navigational lights.




- ① RADIAL OUTRIGGERS (P&S) (OPTION)
- ② VHF RADIO ANTENNA (OPTION)
- ③ GPS ANTENNA (OPTION)
- ④ SIRIUS/XM® SATELLITE RADIO ANTENNA (OPTION)
- ⑤ ANCHOR LIGHT
- ⑥ MERCURY GPS (JOYSTICK OPTION)
- ⑦ ACCESS HATCH TO HARDTOP SURFACE
- ⑧ RAYDAR ANTENNA (OPTION)
- ⑨ NAVIGATION LIGHT (P&S)
- ⑩ THERMAL NIGHT VISION (OPTION)
- ⑪ SPOTLIGHT WITH REMOTE (OPTION)
- ⑫ ELECTRIC HORN
- ⑬ LED LIGHTING
- ⑭ A/C VENT
- ⑮ AFT COCKPIT FLOOD LIGHT
- ⑯ CANVAS STORAGE
- ⑰ VHF RADIO SPEAKER (OPTION)
- ⑱ GYRO CONTROL DISPLAY (OPTION)

- ⑲ FORWARD COCKPIT FLOOD LIGHT
- ⑳ WINDSHIELD VENT ACTUATOR
- ㉑ DEFROSTER SWITCH
- ㉒ LOCKABLE ELECTRONICS BOX
- ㉓ LED CHART LIGHTING (RED & WHITE)
- ㉔ RETRACTABLE SUNSHADE (OPTION)



Seating

Seating  
Figure 2.24.1



- ① HELM SEATING
- ② FOLD AWAY GUNNEL TROLLING SEAT (OPTION) (P&S)
- ③ BOW SEATING
- ④ BOW TABLE/CUSHION (OPTION)
- ⑤ FORWARD CONSOLE LOUNGE
- ⑥ FOLDAWAY STARBOARD AFT SEAT (OPTION)
- ⑦ FOLDAWAY AFT BENCH SEAT


**NOTICE**

**SEAT MAINTENANCE**

- Always wash metallic parts with soap and water and rinse thoroughly with fresh water. Once dry, apply a light coating of lubricant to protect moving parts.
- Check for loose or damaged hardware and tighten or replace as necessary.

## Notable Options

Notable Options  
Figure 2.25.1




- ① GYROSCOPIC STABILIZER
- ② AFT COCKPIT SHADE
- ③ FORWARD COCKPIT SHADE
- ④ UPPER CONSOLE
- ⑤ DIVE TANK RACKS (4) (OPTION)\*
- ⑥ BOW TABLE
- ⑦ COCKPIT TABLES (DUAL)
- ⑧ LEANING POST LIVEWELL

\*DOES NOT INCLUDE DIVE TANKS

## Helm Switch Panel

Helm Switch Panel  
Figure 2.26.1



- |                          |                              |
|--------------------------|------------------------------|
| ① CONTROL STATION        | ⑫ ACCESSORY 1                |
| ② HORN                   | ⑬ NAVIGATION/ANCHOR LIGHTS   |
| ③ FORWARD BILGE PUMP     | ⑭ COURTESY LIGHTS            |
| ④ AFT BILGE PUMP         | ⑮ MAP LIGHTS                 |
| ⑤ HIGH WATER ALARM       | ⑯ FLOOD LIGHTS               |
| ⑥ AUXILIARY BILGE PUMP   | ⑰ UNDERWATER LIGHTS (OPTION) |
| ⑦ VENT                   | ⑱ PORT FISHBOX PUMPOUT       |
| ⑧ WINDSHIELD WASHER      | ⑲ STARBOARD FISHBOX PUMPOUT  |
| ⑨ WINDSHIELD WIPER       | ⑳ WINDLASS POWER             |
| ⑩ COCKPIT SHADE (OPTION) | ㉑ WINDLASS CONTROL           |
| ⑪ AFT LIVEWELL           | ㉒ ACCESSORY 2                |

## Navigation Lighting

### NOTICE

**Regulations state that all boats, no matter the size, must display navigation lights.**

Your boat comes equipped with navigation lighting for your safety. Regulations state that all boats must display navigation lights between sunset and sunrise and during periods of restricted visibility, such as rain, fog, haze, etc. If operating in reduced visibility or between sunset and sunrise it is necessary to maintain a safe speed and post a lookout.

It is the responsibility of the operator to ensure that the navigation lights are in good working order and that the proper lighting is shown and not obstructed in its intended arc of visibility. Do not modify navigation lights. This vessel's navigation lights may include an expiration date on the housing. If one is located, replace light before expiration date, even if light is functional, as lighting quality may be compromised.

Do not add lights that interfere with required navigation lights. Some lights, such as blue colored lights, may be illegal to display on a boat. It is the owner's responsibility to ensure that displayed lights are also compliant with local regulations.

### Operating the Navigation Lighting


A three-position switch, located on the console switch panel marked "NAV ANC" (Figure 2.27.2), controls the navigation and anchor lighting. In the "Navigation Lights" position (See below), the port (red) and starboard (green) and mast (white) lights will illuminate. These lights let other vessels know the approximate size and direction of travel of your boat, depending on which lights they can see. In the "Anchor Lights" position, the white, 360-degree light will illuminate, showing other boaters your location while at anchor.

### ! CAUTION

**Accent lights are not to be used when navigational lights are in use as this may interfere with the effectiveness of the navigational lights.**


### Navigation/Anchor Lighting

Figure 2.27.1



### Navigation/Anchor Lighting

Figure 2.27.2



### ! CAUTION

**The improper sequence of navigation lighting may be as dangerous as no lighting at all.**

### Canvas (Option)

#### ⚠ DANGER

##### CARBON MONOXIDE DANGER

**Prolonged exposure can cause serious injury or death. To reduce CARBON MONOXIDE accumulation, increase air movement by opening windows or adjusting the canvas to allow for more air circulation**

The 380 Outrage optional canvas set consists of helm side enclosures with aft drop curtain, wing curtains, helm seat cover, console cover, storage garage cover, forward cushion cover and generator.


Your canvas weather curtain set will keep its appearance and maintain proper working order provided you follow a few simple steps for cleaning and maintenance (See “*Canvas Care & Maintenance*”, chapter 5 of this manual).

The canvas can be stored on the underside of the hardtop.

Removing or installing canvas on the open water can be difficult since rough water or wakes can cause you or your passengers to lose their balance while attempting to install or remove canvas panels.

For your safety and ease of installation or removal of the canvas, use two (2) people to perform the operation. Remove or install canvas before leaving the boat slip.

Canvas Storage  
Figure 2.28.1




Looking up under hardtop

### Installation


To install your canvas (for the first time):

Insert the zipper track into the canvas rail around the underside of the hardtop.




Once installed, it is not necessary to remove the zipper tracks each time you remove the canvas


Zip the canvas panel section(s) to the zipper track to secure the canvas panel. Zip only partially (approx. 4”) at first.




Attach the bottom of the canvas section(s) to the snaps where appropriate.



Secure the corners of the canvas with the bungee style fasteners where appropriate.



Finish zipping the canvas section(s) carefully without forcing.



When zippers are new they can be a little difficult to zip. A zipper lubricant may be used to help new zippers as well as maintaining trouble-free service. Use care when starting a zipper to prevent damage.

When all canvas is zipped, secure the overlapping edges by pressing them together, thus engaging the hook and loop fabric.

## Chapter 2 • General Information

Never remove canvas by pulling roughly on one edge. To prevent damage to the fabric, fasteners should be unsnapped as close to the button as possible. If the snaps become difficult to unsnap use a lubricant for snaps or zippers or Vaseline, ChapStick, etc. Take care that the lubricant will not stain the fabric.

### To Remove Canvas

- Unzip each piece of canvas leaving approximately 4" attached. This will relieve the tension on the snaps.
- Unsnap the remaining sides of the canvas pieces.
- Remove one piece at a time and store per manufacturers recommendations.

## ▲ DANGER

Exhaust fumes from engines contain deadly Carbon Monoxide gas (CO). Boats enclosed with canvas or with poor ventilation are most likely to collect fumes.


CO sickness symptoms include headache, nausea and dizziness. DO NOT mistake these symptoms for sea sickness.

Even in rainy and/or cold weather, fresh air must circulate through the boat to avoid Carbon Monoxide poisoning.

See page 1-6 of this manual for additional important information regarding Carbon Monoxide.

REFER TO THE CANVAS MANUFACTURER'S INSTRUCTIONS FOR COMPLETE CARE AND MAINTENANCE OF YOUR CANVAS SET.

Canvas (Option)  
Figure 2.29.1



- 1 FORWARD LOUNGE COVER
- 2 AFT FACING SEAT COVER
- 3 BOW SEATING COVER
- 4 BOW TABLE COVER
- 5 AFT BOLSTER COVER
- 6 HARDTOP ENCLOSURE
- 7 CONSOLE COVER
- 8 HELM SEATING COVER

Available, not shown:

- Full boat canvas cover from hardtop to fore and aft deck
- Upper console cover
- Full mooring cover, not compatible with bow rail
- Hardtop aft curtain, full beam enclosure
- Hardtop wing curtains

### Towing, Docking and lifting

#### Bow Tow Eye (Option)

#### WARNING

##### PERSONAL INJURY HAZARD

**Towing or being towed stresses the boat(s), hardware and lines. Failure of any part can seriously injure people or damage the boat(s).**

**DO NOT stand directly in line with the tow line. If it were to break, it would “snap Back” causing injury or damage to everything in its path.**

The optional bow tow eye which is located on the hull, extreme front of the boat, is reinforced with a stainless steel backing plate located in the anchor locker.

In the event that it becomes necessary for you to have your boat towed, the U.S. Coast Guard or a private salvage company experienced in this type of operation are better equipped to perform the service.


Use another recreational boat only as a last resort. Doing so may cause damage to one or both boats due to operator inexperience or other conditions such as weather and/or current.

In addition, the pitch of most propellers on average recreational vessels is geared toward maximizing the speed of the vessel, not torque, thus making towing inefficient and stressful on the engine.

Another recreational boat may assist by standing by, and possibly keeping the disabled boat's bow at a proper angle until help arrives.

#### Bow Tow Eye (Option)

Figure 2.30.1



#### If it becomes necessary to tow your boat:


If possible, create a bridle with a line around the hull or superstructure or use spring lines to secure the towed vessel to the towing vessel (See below).

Either of these methods will distribute the load over a wide area. Be sure to use fenders or other chafe protection at the pressure points.


#### Methods of Towing

Figure 2.30.2

##### BRIDLE



##### SPRING LINE



#### If using the bow eye to tow is the only option:

- Use double-braided or braid-on-braid line. NEVER use three-stranded twisted nylon; it has too much elasticity, can break and “snap back” causing severe injury or damage.
- Attach the tow line to the bow tow eye only. DO NOT attach the tow line to a cleat or deck rail.
- Have towing vessel move slowly to prevent strain on a slack line.
- Keep someone at the helm of the towed vessel to steer.
- Keep lines clear of propellers on both boats.
- Keep hands and feet clear of the other boat.
- NEVER hold a towline after it is pulled taut.

### Docking

Your boat has nine, 10 inch cleats, one located in the anchor locker, two located at the bow (P&S), two located midship under the gunnel (P&S), two located in the aft cockpit under the gunnel (P&S) and two at the stern (P&S). The cleats are used to secure the boat to the dock. While loading/unloading or mooring, please learn the proper way to secure the boat and how best to use the mooring points of your boat.

### ⚠ WARNING

**DO NOT use cleats to tow another boat.**

### Lifting

**DO NOT** use the bow eye for lifting the boat.

### ⚠ DANGER

**Use only flat, wide belt-type slings and spreaders to lift the boat.**

**Lifting with bow and stern eyes will cause stress on the fiberglass & gel coat and may cause injury or death.**

Whether you are lifting your boat out of the water for routine maintenance or long term storage, consider the following:

- If you are using a professional lifting service, it is prudent to check all credentials and ask for proof of insurance to protect your investment.


## NOTICE

### CLOSE THE A/C SEACOCK

**Before removing your boat from the water be sure to close the A/C seacock. Failure to do so will cause an air lock in the line when the boat is returned to the water. The A/C system will then have to be primed before it will operate properly.**

- Ensure that fishboxes and bilge are pumped out prior to lifting.
- Use a wide, flat, belt sling for lifting to minimize stress on the gunwales.
- Careful location of the sling is required. **DO NOT place slings where contact with underwater fittings will occur.**
- When secured on land, pull the garboard drain, ensure that motorwell drains and deck drains are free flowing and position the boat with the bow slightly higher than the stern so that any water which is allowed to accumulate in the cockpit, motorwell or bilge can easily drain from the boat.

Proper Lifting  
Figure 2.31.1



- ① WIDE, FLAT BELT SLING
- ② "SLING" LABEL LOCATED ON HULL (P&S)



### Yacht Tender Package (Option)

If equipped, the yacht tender package consists of the following components (see Figure 2.32.1):

- Clam shell covers over thru hull outlets.
- Ball valves on port and starboard fish box outlets.
- High water float switch (Original equipment).
- Trumpet horn on hardtop (Original equipment).
- Strobe light added to hardtop.
- On/Off tow system switch.

The system is activated by tow system switch located behind the access panel shown in Figure 2.32.1.

### Preparing Yacht Tender Package

1. Close the fishbox pump outlet ball valves in the aft bilge on both port and starboard side


between the pumps and hull sides.

2. Turn OFF all battery switches.

NOTE: The house battery switch can remain off while towing except in conditions where vessel navigation lights are needed.

3. Turn on *TOW SYSTEM SWITCH* (Figure 2.32.1).

The *TOW SYSTEM SWITCH* must be in the on position while towing. This provides power to the horn and the emergency strobe light on the hardtop. Both are activated by the high water float switch in the aft bilge located inside the mechanical access hatch (see Figure 2.32.1) and provides power to the horn and emergency strobe light on the hardtop. If the high-water float switch is triggered, the horn and strobe light will activate to notify crew of a potential issue.



### Operating with Tender in Tow

Before operating with a tender in tow seek professional advice and/or training to master towing fundamentals (USCG Auxiliary, US Power Squadrons, Boat U.S. expert advice). While operating with a tender in tow there are several regulations and guidelines that must be followed:

- Display the proper markings and navigation lights on the towing craft and tender.
- Verify that all procedures outlined under Preparing the Yacht Tender Package were completed.
- Ensure that all tow lines / bridle are adequately sized and in good condition.
- Only secure tow lines to strong points designated for towing. The designated strong point on your vessel is the bow tow eye.
- Designate experienced crew to monitor, identify, and manage risks.
- Always monitor Whaler Watch (if equipped) for battery status and bilge pump activity while towing.
- While underway be prepared to adjust tow line length and speed to meet current conditions.

### Out of Water storage

If it becomes necessary to store the boat out of the water it is imperative that the boat is supported in a manner which will not damage the hull nor the keel.

Boston Whaler recommends that the hull be supported by a minimum of three keel stands. In addition, by a minimum of four side stands, two placed at port and two placed at starboard.

Specifications for keel stands (Figure 2.41.1) which meet the Boston Whaler requirements for support of your boats keel can be obtained by contacting your dealer or Boston Whaler.

In the event that required keel stands are not available see figure 2.41.2 for optional wood block support .



### CAUTION


**In addition to keel stands or wood blocks, use a minimum of four side stands, two placed at port and two placed at starboard. The side stands are for stability only and are not intended to be load bearing.**

**Use ONLY the keel stands required by Boston Whaler to support the boat out of water.**

**Specifications for the keel stands can be obtained from your dealer or Boston Whaler.**


## Keel Stands (Recommended)

Figure 2.34.1



## Wood Blocks (Option)

Figure 2.34.2



### Theft Deterrent with 1st Mate and Remote Connectivity System (Whaler Watch) (Option)

Whaler Watch is a remote-monitoring system that provides a snapshot of the boat's key components, operating systems, as well as alarm notifications.

Subscribing to Whaler Watch allows use of the app and Web portal to monitor the following:

- 1st Mate safety and security system – Anti theft feature immobilizes engines.
- GPS tracking system with geofence notifications.
- Remote monitoring and notification of high-water bilge alarm, tank levels, batteries, shore power connections, and propulsion system information.
- Remote control of courtesy and underwater lights.

\*A limited subscription to Whaler Watch is included and thereafter the service is subscription based. To access the system remotely visit whalerwatch.net.

For more information, see the owner's packet or contact an authorized Boston Whaler dealer.

### Starting the Engines

#### CAUTION

Never start or operate your outboard (even momentarily) without water circulating through all the cooling water intake holes in the gear case to prevent damage to the water pump (running dry) or overheating of the engine.

#### ATTENTION

Shift controls into neutral before starting engine. Shift only when engine is at idle. Reversing at high speeds can cause flooding/swamping due to water being pushed over the transom.

### Pre-start Checklist

1. Ensure lower units of engines are in water and engine emergency stop switch is in run position. Refer to *Chapter 1 Safety, Engine Emergency Stop Switch*.

2. If equipped with 1st Mate theft deterrent system, Press the power button on the captain's fob. A single beep indicates the captain's fob is connected and the boat is ready for operation. For more information on 1st Mate refer to *Chapter 1 Safety, 1st Mate Safety and Security System*.

### Start-up Procedure

1. On helm controls, ensure throttle and shift levers are in the neutral position. Check to ensure throttle and shift lever's neutral indicator light is illuminated (see Figure 3.3.1).
2. On the *BATTERY SWITCH CONTROL* panel located midship under starboard gunwale, press and release each of the *ENGINES* battery switches (see Figure 3.2.1).
3. Rotate keys in the *IGNITION SWITCHES* to the *ON* position (see Figure 3.2.1).
4. On shift and throttle control, press *START ALL ENGINES* button.

#### ATTENTION

Wind and sea currents can change how this vessel responds while in motion. Understanding this vessel and its reactions at speed will make boating safer and more enjoyable.

#### ATTENTION

Ensure continuous visibility of other boats, swimmers and obstacles during bow-up transition to planing. Adjust engine to an intermediate trim as soon as boat is on plane to avoid possible ejection due to boat spinout. Do not attempt to turn boat when the engine is trimmed extremely down, under or in.


### Parallel Switching

In the event the battery for a particular engine is not sufficiently charged to start the engine, depress the *PARALLEL TO HOUSE* switch for the particular engine to connect to the house battery switch and initiate ignition (see Figure 3.2.1).

#### CAUTION

Start remaining engines before initiating parallel switching.

Battery Switch Control Panel and Ignition Switch Panel  
Figure 3.2.1



## Engine(s) Warm Up

The *THROTTLE ONLY* button on the throttle and shift control allows the operator to increase engine RPMs for warm-up without being in gear. To operate:

1. Ensure throttle and shift levers are in neutral.
2. Press and hold *THROTTLE ONLY* button while moving port throttle and shift lever forward.
3. Hold in *THROTTLE ONLY* button until

an audible signal sounds twice and neutral lights start flashing. Flashing lights indicate *THROTTLE ONLY* program is engaged.


4. Advance port throttle and shift lever to increase engine RPMs; RPMs are limited to prevent engine damage.
5. To disengage *THROTTLE ONLY*, return port throttle and shift lever back to neutral position.

### Stopping the Engines

1. Ensure throttle and shift levers are in neutral.
2. Press *START ALL ENGINES STOP* button.
3. Turn all ignition key switches off.
4. Turn off the engine batteries. On the *BATTERY SWITCH CONTROL* panel, press and release each of the *ENGINES* switches (see Figure 3.2.1).

### Throttle and Shift Control

The throttle and shift control is used to manage both the shifting mechanism and the throttle (see Figure 3.3.1). This control regulates engine RPMs, which controls the speed of the boat. Moving the levers forward shifts the engine into forward gear. Continuing to move the lever forward progressively increases the forward speed of the boat. Moving the lever backwards shifts the engine into reverse gear, and continuing to move the lever back progressively increases the reverse speed of the boat. The levers must be in the neutral position to start the engine(s). When in neutral, otherwise known as the idle position, the propeller is not engaged. A green neutral indicator light is illuminated atop the throttle and shift lever when in neutral.



### Buttons and Switches

Basic button/switch use on the throttle and shift control are detailed below (see Figure 3.3.1).

#### Neutral Indicator

Illuminates when engines are in neutral gear position.

#### Trim All Engines

Raises and lowers all engines.

#### Start All Engines Stop

Starts or stops all engines sequentially from port to starboard.

#### Start/Stop Individual Engines

Starts or stops an individual engine.

#### Display Screen (Optional)

Shows pop-ups for advanced features as well as system information and faults.

#### Trim Individual Engines

Raises and lowers individual engines.

#### Brightness

Increases and decreases brightness on control unit.

#### 1 Lever

Enables throttle and shift functions of all engines to be controlled by the port lever.

#### Transfer

Transfer boat control to a different helm.

#### Throttle Only

Increase engine RPMs without shifting into gear.

#### Active Trim

Turns the Active Trim feature on or off.

#### Profile

Changes the selected Active Trim profile.

REFER TO THE OWNER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

### Engine Trim

Engine trim, also referred to as power trim, allows the operator to raise and lower the engines for trailering, launching, beaching, and the bow up transition to planing. Use the power trim switch to obtain ideal

boat angle (in relation to the water surface) for a given load and water condition. In most cases the best all-around performance is obtained when the boat runs at an angle between a 3 to 5 degrees. Engine trim can be done manually by pressing rocker switches located on the throttle and shift control. See *THROTTLE AND SHIFT CONTROL* earlier in this chapter.



### CAUTION

#### AVOID DAMAGE

**Be aware that the port engine cowl can hit the livewell if the engine is turned to the port and trimmed fully UP.**

### ATTENTION

**Ensure continuous visibility of other boats, swimmers and obstacles during bow-up transition to planing. Adjust engine to an intermediate trim as soon as boat is on plane.**

### Active Trim

Engine trim can also be controlled automatically using Active Trim, a GPS, speed-based engine trim system that adjusts engine trim based on changes in boat speed and maneuvers to improve performance, fuel economy, and ease of operation. Active Trim switches, located on the side of the throttle and shift control, have several selectable trim profiles that allow the operator to compensate for changes in boat load, operator preference, and weather conditions.

REFER TO OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.



### Dynamic Running Surface™ (Trim Tabs)

### ATTENTION

**Visibility from the helm station is limited, use of trim tabs is necessary to maintain adequate visibility in some running conditions. Avoid serious injury or death from collisions. Maintain a lookout as required by USCG navigation rules.**

The electric trim tabs on this vessel are of a unique design which further enhances the ride and handling (see Figure 3.4.1 and Figure 3.14.1). Trim tabs are located on the port and starboard

bottom of the hull at the transom and are used to assist in leveling the vessel caused by uneven weight distribution or strong cross winds.




### Operation

## NOTICE

**Ensure continuous visibility of other boats, swimmers and obstacles during bow-up transition to planing. Adjust engine to an intermediate trim as soon as boat is on plane to avoid possible ejection due to boat spinout. Do not attempt to turn boat when the engine is trimmed extremely down, under or in.**

The trim tabs are controlled by rocker switches (see Figure 3.5.3) located at the helm. Short momentary bursts of the rockers will achieve proper attitude of the hull. The trim tab switch is marked bow up and bow down. Using the trim tabs can:

- Level the boat; fore and aft, port and starboard
- Reduce resistance in the steering system
- Increase speed
- Reduce strain on the engines
- Provide a smoother, more stable ride



### Maintenance

The trim tabs units are sealed, waterproof and maintenance free. General cleaning is recommended, and marine growth should be removed when the boat is out of the water. Also inspect the sacrificial anodes regularly and replace as necessary, refer to *Chapter 5, Care & Maintenance* for additional information.

REFER TO THE OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.

### Electrolytic Corrosion & Sacrificial Anodes

Zinc sacrificial anodes are installed on the trim tabs to protect them. Electrolytic corrosion of metals on power boats can result in serious deterioration. Be aware of the possibility of electrolysis and/or galvanic corrosion (the deterioration of metals due to dissimilar characteristics when placed in salt water).

For more information on sacrificial anodes, see *Sacrificial Anodes, Chapter 5, Care and Maintenance*




### Joystick Piloting

Joystick piloting technology provides effortless maneuverability and replaces the traditional bow thruster set up. Joystick piloting provides 360 degrees of movement in any direction, including sideways, diagonally or spinning on its own axis with a push or twist of the joystick. The throttle, shifting and steering are controlled with one hand. The joystick working in conjunction with the independently steered engines move the boat in the desired direction. If equipped, the joystick, (see Figure 3.6.1) is located at the helm. A second joystick is included with the optional upper helm station.

To use the joystick the active throttle and shift control levers must be in the neutral position.

REFER TO OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.



#### Helm to Upper Helm Station Transfer

### ! WARNING

**Avoid serious injury or death from loss of boat control. Boat operator should never leave the active station while the engines are in gear. Helm transfer should only be attempted while both stations are manned. One person helm transfer is not recommended**

If equipped with an upper station, full helm control is transferred including the joystick. To transfer:

1. Ensure all the engine remote battery switches on *BATTERY SWITCH CONTROL* panel, located midship under starboard gunwale, are on.
2. Turn on all ignition switches located under the *BATTERY SWITCH CONTROL* panel.
3. Ensure helm and upper station shift and throttle control levers are in neutral.

NOTE: If control levers are not in neutral, the *Neutral LED* will flash (see Figure 3.3.1.)

4. On the active control press *TRANSFER* button once (see Figure 3.3.1.). The indicator on the transfer button will illuminate and a single audible sound confirming the impending transfer.
5. When both the transfer light and neutral light are on press the transfer button a second time. A second audible sound confirms the transfer is complete.

NOTE: Transfer will fail if not completed within ten seconds.

#### Transfer Upper Station to Helm

The steps for transfer of control from the upper station back to the helm are the same as helm to upper station transfer.

### ! WARNING

**Avoid serious injury or death from loss of boat control. The boat operator should NEVER LEAVE THE ACTIVE STATION while the engines are in gear. Helm transfer should only be attempted while both stations are manned. One person helm transfer should only be attempted while engines are in neutral.**

REFER TO OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.

#### Skyhook® (Digital Anchor)

Skyhook pinpoints the boat's position using a GPS satellite antenna. The engines move independently to maintain the position and heading. It's ideal for holding a boat over a fishing spot, waiting for a

drawbridge to open or maintaining position waiting to refuel at a marina, (see Figure 3.6.1).

### Integrated Autopilot

Auto heading and way point sequencing make navigating to a destination simple and efficient. A built-in digital compass set on auto heading maintains course and makes precise corrections with the touch of a finger. One-degree heading adjustments are made with a tap on the joystick. Plot trips with multiple stops between a starting point and a final destination with way point sequencing.

NOTE: Helm transfer disengages auto pilot. Any required inputs need to be entered at the active helm.

### VesselView

This vessel is equipped with VesselView software which can be accessed via the helm display *Engine App*. VesselView allows the operator to receive critical operational information, displayed clearly and instantly. The system continuously monitors and reports information ranging from basic operating data to detailed vessel environmental information.

### System Calibration

Boston Whaler or your dealer has calibrated VesselView to the boat's equipment. If equipment is added, the system must be recalibrated. Contact your dealer for service if recalibrating is required.

REFER TO OWNER'S PACKET. FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.

### VesselView Mobile (Option)

If equipped, VesselView Mobile connects the data network to your iPhone or android mobile device. With VesselView Mobile you can connect on your mobile device with all the digital data your engine supports plus new features such as maintenance reminders, mapping, performance summary, and fault code diagnostics.

### Bow Thruster (Option)

If equipped, the bow thruster gives the operator more maneuverability of the bow when docking or maneuvering the vessel in narrow channels or where space is limited (see Figure 3.8.3).

The bow thruster is controlled with a joystick located on the console starboard of the helm (see

Figure 3.7.1). The system includes a 24V/DC bow thruster, two 12V batteries, a remote battery switch, and a 24V battery charger which can be accessed through a hatch in the forward storage area in the cabin (see Figure 3.8.1). The *REMOTE BATTERY SWITCH* (see Figure 3.8.1) is operated by pressing the *THRUSTER* switch located on the *BATTERY SWITCH CONTROL* panel midship under the gunwale (see Figure 3.2.1).


## ! WARNING

**Be sure you thoroughly understand the operation and safety requirements of the thruster before using. The thruster should not be operated in close proximity to swimmers, as a powerful suction is created when in use.**

### Bow Thruster Operation

1. Turn on *THRUSTER* battery switch (see Figure 3.8.1).
2. Press and hold the joystick on/off button for 1 second (see Figure 3.7.1). A green power indicator illuminates.
3. Push the joystick in the desired travel direction and release (see Figure 3.8.4).

Bow Thruster Joystick  
Figure 3.7.1



- 1 ON/OFF BUTTON
- 2 POWER INDICATOR

## NOTICE


**Bow thruster is deleted w/ joystick piloting option.**

The bow thruster motor is equipped with an internal thermal breaker. If the thermal breaker trips allow the unit to cool down before continuing operation to avoid damage,


## ▲ DANGER

**Do not operate thruster out of water, even for a few seconds. The motor will over speed by 300%, causing damage to unit; propeller will also damage whatever it contacts. In addition, this action will void the warranty.**


Bow Thruster  
Figure 3.8.3



Bow Thruster Remote Battery Switch  
Figure 3.8.1




Bow Thruster  
Figure 3.8.2



- ① BOW THRUSTER
- ② ISOLATION TRANSFORMER
- ③ FUSE BLOCK
- ④ HOUSE BATTERY BANK
- ⑤ THRUSTER REMOTE BATTERY SWITCH
- ⑥ HOUSE REMOTE BATTERY SWITCH
- ⑦ BATTERY CHARGER

Bow Thruster Movement  
Figure 3.8.4



REFER TO OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.

## Bilge Pumps


Your boat is equipped with three automatic bilge pumps, one forward (1100 GPH - 4,164), one aft (2000 GPH - 7,571 LPH) and one high water emergency pump (2000 GPH - 7,571 LPH).

Each pump is activated automatically by an electric switch when the water in the bilge reaches a predetermined level.

By pressing and holding the switch on the port helm switch panel labeled *FWD BILGE*, *AFT BILGE* or *AUX BILGE* the operator can energize the pumps manually.


The aft pump discharges water overboard by way of a thru-hull fitting on the aft port hull. The high water pump discharges water overboard by way of a thru-hull fitting on the aft starboard hull. The forward pump discharges water overboard by way of a thru-hull fitting on the midship port hull (See figure 3.9.1).

Bilge Pumps & Float Switch  
Figure 3.9.2



- 1 FORWARD PUMP 1100 GPH (4164 LPH)
- 2 AFT PUMPS (2) 2000 GPH (7571 LPH)
- 3 WATER OUTLET
- 4 LOCK TAB
- 5 WATER INLET
- 6 FLOAT SWITCH

Bilge Pump Locations  
Figure 3.9.1



- 1 AFT BILGE PUMP (2000 GPH/7571 LPH)
- 2 FLOAT SWITCH
- 3 EMERGENCY HIGH WATER FLOAT SWITCH
- 4 EMERGENCY HIGH WATER BILGE PUMP (2000 GPH/7571 LPH)
- 5 TO THRU HULL DRAIN (SEE PAGE 2-7)
- 6 FORWARD BILGE PUMP (1100 GPH/4164 LPH)
- 7 SHOWER SUMP

### Access to the Pumps

The aft pump and high water pump can be accessed through the equipment hatch in the aft cockpit floor. The forward pump can be accessed through a hatch in the floor of the cabin.

### Maintenance

To clean the pump strainer, depress the lock tabs on both sides of the pump and lift the pump motor (Figure 3.9.2).

If water does not come out of the discharge hose:

1. Remove the motor module to see if the impeller rotates with the power on.
2. Remove any debris that may have accumulated in the impeller section or strainer base.
3. Check hose and connection on hull side for debris and proper connections.

### NOTICE

**Inspect the bilge pump intakes frequently and keep them free of dirt or material which may impede the flow of water through the pump.**

### Bilge Pump Maintenance

### NOTICE

**Inspect the bilge pump intakes frequently and keep them free of dirt or material which may impede the flow of water through the pump.**

### Float Switch

Frequently inspect the area under or around the float switches to ensure they are free from debris and gummy bilge oil.

### To clean:

- Soak in heavy duty bilge cleaner for 10 minutes, agitating several times.
- Check to ensure float operation is unrestricted.
- Repeat cleaning procedure if necessary.

### Emergency High Water Bilge Pump

In the event that water has risen in the bilge sufficiently to activate the high water float switch, the emergency high water bilge pump will automatically begin to pump water out of the bilge. An audible alarm (loud buzzer) will sound at the helm and the “HIGH WATER” indicator light on the port helm switch panel will be on. Reference *Helm Switch Panel, Chapter 2, General information*.

### Take immediate action:

- Switch all bilge pumps ON.
- Use your radio to broadcast a PAN-PAN distress call. *Reference Chapter 1, Safety.*
- Turn OFF all AC and DC breakers before stepping into the water in the bilge.
- Determine the problem and take necessary action to stop the inflow of water.
- If after you determine your situation no longer requires assistance, you must cancel the PAN-PAN call.

### NOTICE

**After using the shower, run a gallon of clean water through the shower drain to flush out any soap residue.**


### Fuel & Oil Spillage

Regulations prohibit discharging fuel or oily waste in navigable waters. Discharge is defined as any action which causes a film, sheen or discoloration on the water surface, or causes a sludge or emulsion beneath the water surface. A common violation is bilge discharge.

Use rags or sponges to soak up fuel or oily waste, then dispose of them properly ashore. If there is a large quantity of fuel or oil in the bilge, contact a knowledgeable marine service to remove it. Never pump contaminated bilge discharge overboard.

Fill fuel tank less than rated capacity. Allow for fuel expansion.

GRAY WATER SUMP  
FIGURE 3.11.1



- ① CABIN ENTRY STEPS
- ② SUMP ACCESS HATCH
- ③ SHOWER SUMP
- ④ SUMP PUMP (500 GPH/ 1893 LPH)
- ⑤ FROM SHOWER/VANITY DRAIN
- ⑥ FROM A/C, FREEZER PLATES CONDENSATION (OPTION)
- ⑦ THRU HULL DRAIN (SEE PAGE 2-7)
- FROM A/C, FREEZER PLATE COMPRESSOR DRAIN

### Gray Water Sump

Your boat is equipped with a gray water sump located under a hatch on the floor of the cabin (see Figure 3.11.1).

Gray water from the shower & vanity, water from the water heater drain, optional a/c and freezer plate condensation collect in the sump.

The sump contains its own automatic pump. When there is enough water in the sump to raise the float switch and start the pump the water is discharged through the thru hull drain.

### Maintenance

Periodically remove the clear cover and check the pump and float switch for proper working order. Clean out any obstructions which may inhibit the pump from performing correctly.

## Fuel System

### CAUTION

- Oil and fuel spills can be dangerous and can subject offenders to severe penalties
- Leaking fuel is a fire and explosion hazard, inspect the system regularly. Examine fuel tanks and exposed lines for leaks and corrosion.

This system has been designed to meet the EPA regulations using certified components to limit the fuel vapor emissions.

Your fuel system provides the following benefits:

- Automotive style refueling, automatic nozzle shut-off, fuel nozzle retention. This


system sends a signal to the pump nozzle to shut off before there is any spit-back or well-back through the fill opening.

- Overfill protection is included with each system, reducing the possibility of accidental fuel spills.
- Reduce hydrocarbon emissions through the use of a specially designed fuel fill. This fuel fill has a permanently attached cap with a positive closure mechanism with an audible click to inform you when sealed.

## Fuel Tank

Your boat is equipped with a low permeation aluminum fuel tank with a usable fuel capacity of 445 gallon (1684.5 L). The usable capacity of the fuel tank is different from the tank capacity marked on the tank from the manufacturer. The difference is the non-usable portion of the tank which results

Fuel Tank  
Figure 3.12.1



### CAUTION

**Use of improper fuel can seriously damage your engine. Engine damage resulting from use of improper fuel is considered misuse of engine and will void the warranty. Follow engine manufacturer's recommendations regarding the types of fuel and oil to use.**

### NOTICE

**It is your responsibility to read and understand the engine manufacturer's manual in your owner's manual packet for complete fuel and fueling information and warnings.**

from the fuel in the tank that is below the pickup tube and the ullage area that has been incorporated into your tank. It is recommended that you follow all instructions regarding the filling of fuel tanks. **Please take time to read and understand all the fuel related information and warnings regarding gasoline and your boat, in the engine owner's packet.** Fuel tanks with levels less than 1/4 full can cause engine stalling problems due to fuel starvation or by allowing sediment and dirt to enter the fuel supply lines. Keep the tank full and monitor the fuel level often to prevent this from happening.

#### Fuel Vent

The fuel tank vent is integrated into the fuel fill deck fitting. The VaporTec fuel pressure management system, (fuel fill deck fitting, integrated check valve, fill limit vent valve, grade valve), ensures that the fuel system constantly maintains proper vapor pressure in all situations. This eliminates any unintended pressure which can seriously damage a boat or engine. The vent serves as an over pressure/vacuum release with anti-surge and flame/spark arresting protection. The fuel vent system also plays an important role in controlling the "FULL" level of fuel with the use of the FLVV (Fill Limit Vent Valve). Grade Valves have been added to the tank which allows proper ventilation of the tank when the boat is stored, or trailered, on a moderate incline, without fuel seepage.

#### Fuel Distribution System

The fuel is delivered to the engine through the Fuel Demand Valve (FDV), anti-siphon valve, and the fuel line. The FDV prevents the built up pressure inside

the tank from being transferred to the engine while still allowing fuel to flow as the engine requires it for operation. The anti-siphon valve is a safety feature designed to prevent the fuel from siphoning out of the tank if the fuel line were to be cut or broken below the level of the fuel in the tank. In this case, some fuel would leak from the line, but would not allow the entire contents of the tank to siphon into the boat.

#### Filling the Tank

### WARNING

**The fuel system on this vessel complies with all applicable ABYC standards. Fueling station pump flow rates that exceed 18 gallons (68 liters) per minute may damage system components and cause fuel leakage into the vessel.**

This fuel system is designed to automatically shut off the fuel nozzle when the tank is full, similar to an automotive fuel system. The tank is filled when the fuel fill nozzle has shut itself off the second time. The SecureStop automatic fuel shut off system (Fuel Fill Deck Fitting, Integrated Check Valve, Fill Limit Vent Valve), guarantees the boater a clean a trouble-free fill -up. Attempting to fill the tank past this point may cause some of the components to not function properly, or malfunction.

### WARNING

**The use of a portable fuel tank to fill your boat's tank can result in overfilling and circumvent the safety features designed into your tank.**

### WARNING

**The modification of any of fuel system components or replacement of these components with unauthorized parts may result in over-pressurization of fuel system and circumvent safety features designed into tank.**

### NOTICE

**Keep records of the fuel capacity and consumption of your boat. Drastic changes in consumption and mileage may indicate a problem.**

REFER TO THE ENGINE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.



### Static Electricity and the Fuel System

There is a danger that static electricity can ignite gasoline vapors that have not been ventilated outside an enclosed area. Use extreme caution when fueling your boat from a source outside the regular venues, (e.g. marinas, fuel service stations).

Your boat's bonding system protects it from creating and discharging static electricity. Your boat must be in contact with the water or a land-based grounding system while fueling.

Your boat has safety features that can be circumvented by not adhering to standard fueling practices. The following suggestions will help keep you safe from static electricity while refueling your boat.

- **NEVER** fuel your boat in unsafe conditions such as suspended on a sling or in a situation that increases the likelihood of static discharge.
  - **NEVER** use homemade containers to fill your fuel tanks.
  - Fuel carried on-board outside of a fixed fuel system should be stored in an approved container or in a portable tank such as provided for outboard engines and be stowed safely outside of the engine or living compartment(s).
- **NEVER** use homemade containers to fill your fuel tanks.
  - Fuel carried on-board outside of a fixed fuel system should be stored in an approved container or in a portable tank such as provided for outboard engines and be stowed safely outside of the engine or living compartment(s).
  - **NEVER** use homemade containers to fill your fuel tanks.
  - Fuel carried on-board outside of a fixed fuel system should be stored in an approved container or in a portable tank such as provided for outboard engines and be stowed safely outside of the engine or living compartment(s).
  - Shut down the engine, motors and fans prior to taking on fuel. Any ignition sources should be extinguished before filling the fuel tanks.
  - Close all ports, windows, doors and hatches.
  - Fueling should never be done at night except in well-lighted areas.
  - Always keep the fuel nozzle in contact with the fuel fill plate or the edge of the fuel tank opening throughout the filling process.
  - Allow areas where gasoline vapors could collect to be ventilated before starting the engine.
  - Wipe any spillage completely and dispose of rags or waste on shore.
  - Secure the fuel cap tightly.
  - Portable tanks should only be filled while on the ground, never on board the boat.

There is a danger that static electricity can ignite gasoline vapors that have not been ventilated outside an enclosed area. Use extreme caution when fueling your boat from a source outside the regular venues, (e.g. marinas, fuel service stations).

Your boat's bonding system protects it from creating and discharging static electricity. Your boat must be in contact with the water or a land-based grounding system while fueling.

Your boat has safety features that can be circumvented by not adhering to standard fueling practices. The following suggestions will help keep you safe from static electricity while refueling your boat.

- **NEVER** fuel your boat in unsafe conditions such as suspended on a sling or in a situation that increases the likelihood of static discharge.

### **DANGER**

**Static electricity can ignite gasoline vapors causing serious injury/death and/or destruction of property.**

**Check for leaks in tubing, connections and hoses. Correct the cause of any leaks and ventilate the area to insure that no fumes remain, prior to energizing any electrical equipment and/or starting the engines.**

REFER TO YOUR OWNER'S MANUAL PACKET FOR MORE INFORMATION.

### Ethanol-Blended Fuels

Ethanol is an oxygenated hydrocarbon compound that has a high octane rating and therefore is useful in increasing the octane level of unleaded gasoline.

#### NOTICE

**The use of improper gasoline or additives can damage your fuel system and is considered misuse of the system. Damaged caused by improper gasoline or additives WILL NOT be covered under warranty.**

The fuel-system components of your Mercury engine(s) have been tested to perform with the maximum level of ethanol-blended gasoline (10% ethanol) currently allowed by the EPA in the United States.

Special precautions should be considered with the use of fuel containing ethanol in your system. Fuels with ethanol can attack some fuel-system components, such as tanks and lines, if they are not made from acceptable ethanol-compatible materials. This can lead to operational problems or safety issues such as clogged filters, leaks or engine damage.

Your boat was manufactured, and shipped from the factory, with ethanol-compatible materials. Before introducing gasoline with ethanol into your fuel tank, ask your dealer if any components have been added or replaced that are not recommended by Boston Whaler, Mercury or may not be ethanol-compatible.

### Filling The Tank

It is best to maintain a full tank of fuel when the engine is not in use. This will reduce air flow in and out of the tank due to changes in temperature as well as limiting exposure of the ethanol in the fuel to humidity and condensation.

### Phase Separation

Humidity and condensation create water in your fuel tank which can adversely effect the ethanol blended fuel. A condition called phase separation can occur if water is drawn into the fuel beyond the saturation

point. The presence of water in the fuel beyond the saturation level will cause most of the ethanol in the fuel to separate from the bulk fuel and drop to the bottom of the tank, significantly reducing the level of ethanol in the fuel mixture in the upper level (phase). If the lower level (phase), consisting of water and ethanol, is deep enough to reach the fuel inlet, it could be pumped directly to the engine(s) and cause significant problems. Engine problems can also result from the reduced ethanol/fuel mixture left in the upper phase of the tank.

### Additives

There is no practical additive known that can prevent or correct phase separation. The only solution is to keep water from accumulating in the tank.

If phase separation does occur, your only remedy is to drain the fuel, clean and dry the tank completely and refill with a fresh, dry load of fuel.

### Fuel Filters

Mercury already provides the appropriate level of filtration to protect the engine from debris. The addition of another *in-line* filter to the system will create a possible flow restriction that can starve the engine(s) of fuel.

### Fuel/water Separator

The fuel/water separator has been determined to be within Mercury specifications and will not restrict the flow of adequate fuel to the engine(s).


### Maintenance

Periodically inspect for the presence of water in the fuel tank. If any is found, all water must be removed and the tank completely dried before refilling the tank with any fuel containing ethanol.

### Storage

Long periods of storage and/or non-use, common to boats, create unique problems. When preparing to store a boat for extended periods, of two months or more, it is best to completely remove all fuel from the tank. If it is not possible to remove the fuel,

Example of Phase Separation  
Figure 3.16.1



- ① CONDENSATION
- ② UPPER PHASE (WATER+FUEL+ETHANOL)
- ③ LOWER PHASE (WATER+ETHANOL)
- ④ FUEL INLET TO ENGINE

## ⚠ CAUTION

**The use of fuels containing ethanol higher than 10 percent (E-10) can damage your engine and/or fuel system and will void the warranty.**

**E85 FUELS COULD SERIOUSLY DAMAGE YOUR ENGINES AND MUST NEVER BE USED.**

maintaining a full tank of fuel with a fuel stabilizer added to provide fuel stability and corrosion protection is recommended.


- Add fuel stabilizer/treatment at manufacturers recommended dosage.
- Run engine(s) for 10 minutes.
- Shut OFF fuel valve.
- Allow engine to run until it stops.
- Top off fuel tank, leaving space for expansion. DO NOT fill to point of overflow.
- DO NOT cap the tank vent.

A partially full tank is not recommended because the void above the fuel allows air movement that can bring in water through condensation as the air temperature moves up and down. This condensation could potentially become a problem.

REFER TO THE ENGINE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

## Power Steering

The Verado four-stroke engines use an enclosed hydraulic pump unit. The pump is electrically operated to provide hydraulic pressure to the steering system. The pump is located in the aft of the bilge and can be accessed by removing the access hatch behind the aft bench seat.




## Filling & Maintenance

The system is virtually maintenance free, aside from regular fluid checks and visually inspecting the outside of the unit for signs of leaks or damage.


## NOTICE

**Ensure that cover is properly seated to prevent intrusion of water into the pump enclosure.**

- Remove the pump cover by pulling up and out on the locking tabs on the sides of the unit.



- Unscrew the cap and check the fluid level in the reservoir, fill **ONLY** with SAE 0W-30 Full Synthetic Power Steering Fluid if necessary.
- Replace cap and cover.



Make a habit of checking the fluid level before each trip. Proper maintenance of this system will ensure worry-free usage for the life of your boat. Steering system integrity is imperative when engaging in recreational water activities. Special care and

attention must be taken to ensure proper performance of the steering system and should include the following:


- After the first few hours of operation and at regular intervals, check all fasteners and the complete steering system for security and integrity.
- Inspect for corrosion. Any part affected by corrosion must be replaced.
- When replacing parts, self locking hardware must be used.
- Check the fluid level in the helm pump unit.
- Lubricate slides on the engine cylinders.

All steering systems whether mechanical or hydraulic require regular inspections, periodic adjustment and occasional replacement may be necessary.

### ATTENTION

**Optional Mercury V12 engines do not have external power steering pumps and instead use a built-in, electro-hydraulic steering motor. Steering commands between helm/joystick and engine are digital.**

Power Steering Joystick Piloting  
Figure 3.17.2




- ① STARBOARD ENGINE STEERING MODULE
- ② CENTER ENGINE STEERING MODULE
- ③ PORT ENGINE STEERING MODULE
- ④ POWER STEERING PUMP
- ⑤ THRUST VECTOR MODULE
- ⑥ ELECTRONICS BOARD\*

\* Behind console dash

REFER TO THE ENGINE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

Power Steering  
Figure 3.17.1



- ① HELM
- ② HYDRAULIC LINES
- ③ AUTOPILOT PUMP
- ④ PORT ENGINE FITTINGS
- ⑤ STARBOARD ENGINE FITTINGS
- ⑥ POWER STEERING PUMP

*NOTE: When equipped with optional joystick piloting and/or V12 engines, power steering configuration varies.*

### Fresh Water System

The freshwater system on your boat includes: one pump, a 60 gal (227 L) fresh water tank and plumbing connections for water service to the head, vanity sink, bait prep station sink, transom shower, dive door shower and anchor locker.

### Filling the Tank

The water tank can be filled through the water fill deck plate located midship on the starboard gunwale.

Fill the tank only from a source known to provide safe, pure drinking water. Use only a plastic hose to fill the water tank. Using a rubber hose can give the water a disagreeable taste. The hose should be dedicated to filling use only and should be stored in a clean, dry place. It is a good practice to cover the ends of the hose to ensure the inside stays clean.

Before you fill the freshwater system it is vital that

## NOTICE


- **Be sure to fill the water tank from a source known to provide safe, pure drinking water.**
- **If you do not use the freshwater system for long periods of time or only use it seasonally it is recommended that you follow the disinfecting practice before using it.**

it be properly disinfected. Ask your dealer if this has been done.

The following procedure is recommended to disinfect the freshwater system:


1. Flush the entire system thoroughly by allowing potable water to flow through it.

Fresh Water System  
Figure 3.18.1



- |   |   |
|---|---|
| <p>① 60 GAL (227 L) FRESH WATER TANK</p> <p>② AFT COCKPIT WASHDOWN</p> <p>③ 6 GAL (22.7 L) WATER HEATER</p> <p>④ ANCHOR LOCKER WASHDOWN</p> <p>⑤ WINDSHIELD WASHER</p> <p>⑥ FRESH WATER DECK FILL</p> <p>⑦ HEAD VANITY SINK &amp; SHOWER (HOT &amp; COLD)</p> | <p>⑧ PREP STATION SINK (OPTION)</p> <p>⑨ DIVE DOOR SHOWER (HOT &amp; COLD)</p> <p>⑩ FRESH WATER MANIFOLD</p> <p>⑪ FRESH WATER PUMP</p> <p>⑫ DOCKSIDE WATER INLET</p> <p>⑬ TRANSOM SHOWER (HOT &amp; COLD)</p> |
|---|---|

Fresh Water Manifold  
Figure 3.19.1




2. Drain the system completely.
3. Fill the entire system with an approved disinfecting solution (check with your dealer for recommendations) and follow the method prescribed by the manufacturer.
4. After disinfecting, drain the entire system.
5. Flush the entire system thoroughly several more times with potable water.
6. Now the system is ready for use, fill with potable water.

This should be done annually or before using the system if it has been laid up for an extended amount of time.

### Freshwater Pump

Your boat has a fresh water pump located in the port side bilge area aft of the battery trays. To access the pump, lift the equipment hatch in the aft cockpit deck.



To operate the system, turn ON the “FRESH WATER” breaker located on the DC Breaker Panel located on the starboard gunnel. This will energize the fresh water pump (See figure 3.18.1).

When activated, the freshwater pump draws water from the water tank and provides pressure to the entire freshwater system.

Periodically check the hoses and connections for leaks and/or loose fittings. A loss of pressure will result in low water flow.


### Deck Showers

The 380 Outrage is equipped with two deck showers, one is located on the starboard side, aft of the transom door and the other is located forward of the dive door on the port side of the cockpit.

The showers are supplied by the fresh water system and have a hose which extends approximately 6' (1.82M).


The shower unit is pressurized by the fresh water pumps and the spray head is activated by twisting the center of the unit.

Transom Shower  
Figure 3.20.1



- 1 TRANSOM SHOWER (HOT&COLD)
- 2 TRANSOM

Dive Door Shower  
Figure 3.20.2




- 1 TRANSOM SHOWER (HOT&COLD)
- 2 DIVE DOOR

### Anchor Locker Washdown

For your convenience, there is a fitting located at the bow in the anchor locker which allows for the connection of a common garden hose. This connection allows for the use of fresh water at the bow of your boat. It is important that the cap which is tethered to the connection be screwed onto the fitting when it is not being used.

The “FRESH WATER” switch located on the DC distribution panel must be ON to operate the anchor locker freshwater washdown.

Anchor Locker Washdown  
Figure 3.20.3



- 1 ANCHOR LOCKER
- 2 FRESH WATER FITTING

### Water Heater

## NOTICE

**Make sure the fresh water tank is full before operating the water heater. Operating the water heater empty will cause damage to the system.**

### Operation

Make sure the “FRESH WATER” switch located on the DC distribution panel on the starboard gunnel is “ON” before energizing the water heater.

Turn “ON” the “WATER HEATER” switch located on the AC Main Distribution Panel in the aft port cabin. Once both the “FRESH WATER” switch and the “WATER HEATER” switches are “ON” the system can be utilized.

**NOTE:** If the water heater has not been used for some time it will take approximately 20 minutes for the water to heat.

## NOTICE

**The water heater is equipped with a temperature and pressure relief valve that complies with the standard for Relief Valves & Automatic Gas Shut off Devices for Hot Water Systems, ANSI Z 21.22**

## ! WARNING

**Hydrogen gas may form in the tank if the system has not been used for more than two weeks. DO NOT smoke or have any flame near an open faucet.**

### CAUTION


**SCALDING INJURY - Turn OFF water heater and wait for water in the storage tank to cool before opening the drain valve to flush the tank.**

#### Maintenance

The water heater connections will need to be inspected regularly. Access to the water heater can be made through the back wall of the hanging closet in the forward console. If you notice any leaks around the water heater call your dealer. Manually operate the pressure relief valve at least once a year. This must be done when the water in the storage tank is cool. The system must be flushed several times per year; which will prolong the life of the system. There may be times that you will notice an odor coming from the water system. There is a protective cladding in the tank that protects it from corrosion. The electro-galvanic action of the cladding material releases hydrogen from the water. If sulfur or any of its combinations are present in the water the two will combine and produce hydrogen sulfide. This compound will produce a rotten egg odor. Hydrogen sulfide can also be present in your freshwater supply. It is the product of the decay of animal matter and as little as 1 mg/liter can cause a perceptible odor.

#### Water Heater (Option)

Figure 3.14.1



- ① 11 GAL (41.64 L) WATER HEATER
- ② RELIEF VALVE
- ③ WATER INLET (FROM WATER TANK)
- ④ DRAIN
- ⑤ COLD WATER LINE
- ⑥ HOT WATER LINE
- ⑦ TEMPERING (MIXING) VALVE
- ⑧ WATER OUTLET (TO HOT WATER LINES)


Make certain that the system is completely drained before laying up for the winter season. The freshwater tank will have to be drained and flushed with a non-toxic anti-freeze before winter storage.

#### Tempering Valve

A tempering valve is installed on the hot water outlet of the water heater to reduce the risk of scalding. The valve is set at it's lowest temperature (100°F) at the factory. The water temperature can be adjusted up to a maximum of 130°F by turning the valve counterclockwise until the water temperature reaches your desired limit.

#### Fresh Water System Maintenance

Very little maintenance is required for the fresh water system, other than annual disinfecting and winterizing. Periodically check the entire system to assure that the hose connections, tube fittings, electrical connections and mounting bolts are properly secured, and free of chafing.



Periodically check the in-line strainer attached to the pump, and clean if necessary.

The system should be run at least every other month to maintain the pump's impellers in a stable operating condition.

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.



## Raw Water System

The Raw water system includes a pump, a seacock with auxiliary pump, a 60 gal (227 L) livewell located at the center of the transom and a washdown hose connection.

The seacock must be set in the OPEN position (Figure 3.22.1) for the raw water system to function. The seacock, livewell pump and raw water pump can be accessed through the equipment hatch in the aft cockpit deck.

Make sure that the hull seacock is set in the open position and turn ON The “RAW WATER” switch on the DC distribution panel. The raw water pump will be activated and the system will become functional.

## Full-Fill Livewells


Your boat is equipped with a 60 gallon Full-Fill livewell located at the center of the transom.

You can regulate the amount of water in the livewell by inserting the second drain plug (supplied) into the mid overflow drain, thus raising the level of water to the upper overflow drain. This Full-Fill design provides a stable environment to reduce fatigue on your baitfish resulting in a more active and longer lasting product.

## Full-Fill Livewell Operation

- Make sure that the hull seacocks are in the open position.
- Insert a drain plug (supplied) into the mid overflow drain and fill the livewell completely. The upper overflow drain

Livewells  
Figure 3.22.1



will allow the water to rise to just below the lid before starting to drain. Maintaining this water level enhances the stability of the water in the tank.

- Open the livewell flow control valves. The flow control valve for the transom livewell can be accessed through the hatch behind the aft bench seat.
- Fill the aft livewell by pressing the switch marked “AFT L/W” on the port helm switch panel.

### ATTENTION

The seacock **MUST** be in the **OPEN** position when livewell is in use. Running the pump dry may damage the unit.

The livewell has three drains to regulate the amount of water in the unit. The bottom drain is used to empty the livewell of water completely. By utilizing the drain plug (supplied) between the two overflow drains in the side of the livewell you can adjust the level of water in the unit. A drain tube with strainer connects to the livewell overflow drains and will direct overflow/excess water to the thru-hull drains.

### Leaning Post Livewell (Option)

If equipped, the leaning post livewell (Figure 3.23.1) includes a pump, a seacock with auxiliary pump, and a 30 gallon livewell located in aft facing couch and can be accessed by lifting the seat.

The hull seacock must be set in the OPEN position (Figure 3.23.1) for the livewell system to function.


### Maintenance

Maintenance of the livewell system requires periodic inspection of the raw water intake strainer and all fittings and hoses for system integrity to prevent leaks.

Clean away debris and/or tighten hose connections as required. The system should be run at least every other month to keep the pumps impellers in good condition.

### Leaning Post Livewell (Option)

Figure 3.23.1



- 1 AFT FACING COUCH
- 2 30 GAL (113.55 L) AERATED, FULL-FILL
- 3 LEANING POST LIVEWELL (OPTION)
- 4 FLOW CONTROL VALVE
- 5 UPPER LEVEL OVERFLOW DRAIN
- 6 MID LEVEL OVERFLOW DRAIN
- 7 BOTTOM DRAIN
- 8 LIVEWELL FILL INLET
- 9 SEACOCK W/AUXILIARY PUMP

### Raw Water Washdown


The raw water washdown hose connection is located in the port aft cockpit (Figure 3.24.2). The fitting allows for connection of a common garden hose. The raw water washdown is supplied by a pump activated by the *RAW WATER* switch on the DC distribution panel.

### Maintenance

Maintenance of the raw water system requires periodic inspection of the raw water intake strainer and all fittings and hoses for system integrity to prevent leaks.

Clean away debris and/or tighten hose connections as required. The system should be run at least every other month to keep the pumps impellers in good condition.

Raw Water Washdown  
Figure 3.24.1



- ① RAW WATER WASHDOWN
- ② AUTOMATIC ENGINE FLUSH (OPTION)
- ③ DIVE DOOR GRAB RAIL
- ④ 120V/30A RECEPTACLE

## ATTENTION

**The seacock MUST be in the OPEN position when washdown is in use. Running the pump dry may damage the unit.**

### Head System

#### Environmental Considerations

The Environmental Protection Agency (EPA) standards state that in freshwater lakes, reservoirs, impoundments whose inlets or outlets are such as to prevent the ingress or egress by vessel traffic subject to this regulation, or in rivers not capable of navigation by interstate traffic subject to this regulation, marine sanitation certified by the United States Coast Guard (U.S.C.G.) installed on vessels shall be designed and operated to prevent the overboard discharge of sewage, treated or untreated or any other waste derived from sewage.

The EPA standards further state that this shall not be construed to prohibit the carriage of Coast Guard certified flow through treatment devices which have been secured so as to prevent such discharges. They also state that the waters where a Coast Guard certified marine sanitation device permitting discharge is allowed include: Coastal waters, Estuaries, The Great Lakes and Intercoastal waterways, Freshwater lakes and Impoundments accessible through locks and other flowing waters that are navigable interstate by vessels subject to this regulation. (40CFR 140.3)

#### NOTICE

**This boat is equipped with a direct overboard discharge valve. Discharging of sewage directly overboard is for use where approved only. Damage to the system could occur if the discharge seacock is not open during operation.**

#### NOTICE

**Severe state and federal penalties are levied for discharging raw sewage and solid waste in waters where it is not permitted.**

**Demonstrating that you have disabled the macerator by locking the system and/or removing the seacock handle may avoid a fine.**


**It is illegal for any vessel to dump plastic trash anywhere in the ocean or navigable waters of the United States.**

The 380 Outrage is equipped with a waste disposal system located in the head in the cabin. The system is protected by the “HEAD” breaker on the DC Breaker Panel on the starboard gunnel, midship. The breaker must be ON for the system to function.

The waste system includes a VacuFlush® toilet, a 10 gallon holding tank with vacuum pump and a thru-hull vent.

#### VacuFlush® Head

The foot pedal at the base of the toilet opens a mechanical seal which allows a vacuum to force waste through the opening in the bowl to the vacuum generator, through the vacuum pump and then to the holding tank.



#### Operation

If there is no water in the bowl, lift the foot pedal up to add sufficient water.

Make sure the *HOUSE BATTERY SWITCH* is ON. See *Battery Switch Control Panel* earlier in this chapter.


- Ensure the “FRESH WATER” switch located on the DC distribution panel is ON.
- Turn the “VACUUM PUMP” switch ON (See figure 3.26.2)
- To flush, depress the foot pedal until bowl is clear.

Waste from the head is directed into the holding tank located in the bilge. A holding tank fluid level indicator is located on the overboard discharge panel (See figure 3.26.2) which is located on the aft wall of the head. When the “TANK FULL” light is on, the holding tank must be emptied before the head can be reused. However, it would be a good practice to empty the tank before the light is on to avoid damage to the system.

Head System  
Figure 3.26.1


## NOTICE

**NEVER use residential tissue paper in your marine waste system.**



- 1 VACUFLUSH® TOILET
- 2 LOCKING PLATE
- 3 LOCKABLE DISCHARGE SEACOCK
- 4 MACERATOR
- 5 VENT FILTER
- 6 VENT HOSE
- 7 DOCKSIDE PUMPOUT DECK PLATE
- 8 DOCKSIDE PUMPOUT HOSE
- 9 10 GAL ( 37.8 L )WASTE HOLDING TANK W/VACUUM PUMP
- 10 FROM VACUFLUSH TOILET

Vacuflush/Overboard Discharge Panel  
Figure 3.26.2



- 1 OVERHEAD LIGHT BREAKER
- 2 OVERBOARD DISCHARGE PUMP BREAKER
- 3 VACUUM PUMP BREAKER
- 4 VACUUM PUMP SWITCH
- 5 TANK FULL INDICATOR LIGHT
- 6 OVERBOARD DISCHARGE PUMP KEYSWITCH

### Macerator & Dockside Discharge

The system can be emptied by means of dockside pumpout (preferred) through the “Waste” deck plate on the port transom (see Figure 3.26.1).

The system also provides for overboard discharge by way of a macerator & lockable discharge seacock.

## NOTICE

**Severe state and federal penalties are levied for discharging raw sewage and solid waste in waters where it is not permitted.**

## ! WARNING

**The discharge seacock should always be in the closed position when the toilet is not in use. Failure to do so could result in flooding or property damage.**

### Overboard Discharge

The macerator discharge pump draws solid and liquid waste from the holding tank and processes it prior to discharging it overboard through the discharge seacock located in the aft bilge.

There is a control panel located on the aft wall of the head. If the “TANK FULL” light is on you **MUST** empty the holding tank before the system will function properly.

- Ensure that the *HOUSE BATTERY SWITCH* located on the DC Breaker Panel is on.
- Make sure discharge seacock is open.
- Insert the overboard discharge key, which is included in your owners manual packet, into the panel located in the head (see Figure 3.26.2).
- De-energize the vacuum pump by depressing the bottom of the rocker switch (see Figure 3.26.2).
- Depress the lever on the toilet to deplete the vacuum (see Figure 3.26.1).
- Turn key clockwise to ON and hold it there.
- When you are satisfied that the tank has been emptied, return the key to the upright position.
- Energize the system by depressing the top of the rocker switch.

### NOTICE

**The rocker switch must remain ON for the system to function properly.**

### Maintenance

After long periods of non-use, the macerator pump may not turn freely. Regular use of the system will reduce the chances of this occurring. If the system does require maintenance contact your nearest dealer. Because your waste system is a low water use device, use special paper to prevent clogs.

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

### Dockside Pump-Out

### NOTICE

**Dockside discharge is the preferred method of waste disposal.**

To empty the holding tank, the services of a dockside pump-out station is required. Follow instructions at the station and make sure the pump out hose is inserted into the deck plate marked *WASTE*, located on the port transom.

Access is gained by use of a special key that is included in the owners manual packet.

The dockside facility will have a connection to fit your boat.

**NOTE:** Prior to using either method of discharging sewage:

- De-energize the vacuum pump by depressing the bottom of the rocker switch (see Figure 3.19.2).
- Depress the lever on the toilet to deplete the vacuum.
- After completion of the discharge, energize the vacuum pump by returning the switch to the ON position (see Figure 3.19.2).

**Avoid overflowing the holding tank.** If the “FULL” light is lit on the Vacuflush/Overboard discharge panel located in the head, you **MUST** empty the holding tank before the system will function properly.

### Waste System Vent

The waste system vents odors associated with waste operations through the port transom thru hull fitting.

### NOTICE

**Replace vent at beginning of each boating season for most effective odor control.**

### NOTICE

**If holding tank overflow occurs and vent filter becomes fouled, replace vent filter immediately.**

The vent filter is located in front of the holding tank in the bilge (see Figure 3.26.1) and can be accessed through the mechanical hatch in the aft cockpit deck.

- Unscrew vent hose fittings from old vent filter.
- Remove old filter from bracket, seal open ends with tape or wrap inside plastic bag, and discard.
- Install new vent filter in bracket and attach to vent hose fittings.

### Air Conditioning

The reverse-cycle air conditioning system consists of an air handler (12000 BTU), a seawater pump with seacock and strainer and a control unit so that the water pump will be activated by demand when the AC unit comes on.

The unit can be accessed through the panel on the port side, bottom of the console interior.

### Operation

The air conditioning/heating system is controlled by a touch display unit located on the aft port wall of the cabin.

The display allows the operator to preset the temperature for the cabin. The air unit will activate automatically when the temperature of the cabin is not consistent with the preset temperature. When the air handler is activated, seawater is pumped into the system by way of a seacock and strainer, passes through the compressor cooling the condensing coils, and then flows overboard through the thru-hull drain

### Starting the System


- Make sure the seacock is OPEN.
- Turn ON the “A/C PUMP” breaker on the “SHORE POWER 1” panel located on the port aft wall of the console interior.
- Set the display to the desired temperature.

### Maintenance

The air conditioning unit requires very simple maintenance. Periodically check and clean the raw water intake on the exterior of the hull, the water strainer at the pump and the air filter.

If need be, access to the A/C unit can be achieved by removing the panel on the starboard wall of the console interior behind the step.

A/C Touch Display Control panel  
Figure 3.28.1



REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

### Helm deck Air Conditioning (Option)\*

If equipped, the reverse-cycle helm deck air conditioning system consists of an air handler (18000 BTU), a seawater pump with seacock and strainer and a control unit so that the water pump will be activated by demand when the AC unit comes on.


The unit can be accessed through a panel on the port side, bottom of the Summer Kitchen.

### NOTICE

**Helm deck A/C not intended to cool helm deck area with enclosure up.**

\* Includes a 10K Generator upgrade.

A/C System  
Figure 3.29.1




- ① 12,000 BTU AIR HANDLER
- ② CABIN AIR DUCT
- ③ CONDENSATION DRAIN
- ④ HEAD AIR DUCT
- ⑤ CONSOLE AIR DUCT
- ⑥ LEANING POST VENT
- ⑦ 18,000 BTU AIR HANDLER (OPTION)\*
- ⑧ HELM SEATING AIR VENT
- ⑨ FISHBOX FREEZER PLATE (OPTION)
- ⑩ INTAKE SEACOCK/WATER STRAINER
- ⑪ AC PUMP
- ⑫ FISHBOX FREEZER PLATE COMPRESSOR (OPTION)

\* Includes a 10K Generator upgrade.



Automatic Engine Flushing System (Option)  
Figure 3.30.1



## Automatic Engine Flushing System (Option)

If equipped, the engine flushing system is fully automatic and flushes salt and minerals from the internal components of marine engines more effectively and conveniently than conventional methods.

### Operation

- Attach a water hose to the hose fitting located on the port side of the transom (Figure 3.30.1),
- Activate the system by depressing the button on the panel located on the aft port gunnel (Figure 3.30.1) for a full or half cycle

### Full Cycle (15 minutes)

- Push the start button (Figure 3.30.1) ONCE. The system will cycle for 15 minutes per engine.
- Push the start button TWICE to stop in the middle of cycle if desired.

### Half Cycle (7.5 minutes)

- Push the start button (Figure 3.30.1) TWICE. The system will cycle for 7.5 minutes per engine.
- Push the start button ONCE to stop in the middle of cycle if desired.

## Generator

**It is recommended that you read and understand the information in the manufacturers owners manual before operating the generator.**

Your boat's AC electrical system operates on 120V/60Hz or 220V/50Hz from the generator and/or shore power. The low CO gas powered generator (7.5kW) is driven by a self contained engine and provides connections to the AC electrical system through cables connected to the slide selector switch on the AC distribution panel. The generator has a built in cooling pump which draws cooling water through a seacock located in the aft machinery compartment. This water passes through a strainer before entering the engine cooling manifold.

The generator draws fuel from the main fuel tank and is designed to run out of fuel with about 1/4 tank of fuel remaining, leaving a reserve of fuel for the

propulsion engines. **DO NOT** run the generator set out of fuel because the fuel lines will draw in air and necessitate bleeding the system before restarting the unit. The generator should be shut off before the fuel

### ! WARNING


**CARBON MONOXIDE** can cause severe NAUSEA, FAINTING or DEATH. The exhaust system must be leakproof and routinely inspected.

**FIRE** Can cause SEVERE INJURY or DEATH. Do not smoke or permit flames or sparks near fuels or the fuel system.

**EXPLOSIVE FUEL VAPORS** Can cause SEVERE INJURY or DEATH. Use extreme care when handling, storing and using fuels.

**MOVING PARTS** Can cause SEVERE INJURY or DEATH. Operate the generator set only when all guards, screens and covers are in place.

Generator, Gas  
Figure 3.24.1



- ① LOW CO GAS 7.5 KW GENERATOR\*
- ② RAW WATER INTAKE SEACOCK
- ③ OUTLET TO GENERATOR
- ④ WATER STRAINER
- ⑤ FUEL TANK
- ⑥ GENERATOR FUEL DEMAND VALVE (FDV)
- ⑦ MUFFLER

### NOTICE

**The generator should be shut off before the fuel level reaches the 1/4 tank level where it is designed to run out of fuel.**


\* 10KW with gyro option

level reaches the 1/4 tank level where it is designed to run out of fuel. The operations manual included in the owners packet will have complete instructions on bleeding the fuel system should it be needed.

The exhaust from the generator passes through a high efficiency marine lift type water cooled muffler and is discharged by a flexible hose via a through hull fitting. The generator has a housing which acts as protection and a sound shield. It can be removed by pulling latches located on the housing.

### Starting the Generator

The remote generator operation panel is located inside the cabinet door shown in Figure 3.32.1.




## ATTENTION


**Ensure generator seacock is open before starting. Close seacock when generator is not in use to prevent generator damage while underway.**

Be sure to read the generator manual in your owner's manual packet before operating the generator. Several key points are indicated below:


- Operate the blower for 4 minutes and manually check the bilge for fuel vapor.
- Refer to the Manufacturers Operations Manual for a Pre-Start Checklist.




- OPEN generator seacock.



- Generator breaker must be turned OFF to start.
- Check for water in strainer.




- Press START button until generator starts.




**DO NOT press the button more than once.** Allow for a 60 second cool down period between cranking attempts. If the generator fails to start after the first attempt, check fuel flow, if OK, attempt start sequence again. If the unit fails to start after 3 attempts, contact an authorized dealer/distributor for service.

## Stopping Generator

- Make sure that ALL breakers on the AC panel are switched OFF.



- To STOP the generator, press STOP button.



## Maintenance

### ! WARNING

Accidental starting can cause severe injury or death. Disconnect the battery cables before working on the generator set. Disconnect the negative, (-) cable first when removing and reconnect it last when replacing.

The generator manual has a maintenance schedule that must be followed to keep generator in peak operating condition. Inspect the parts often and perform required service at the prescribed intervals. Maintenance work must be performed by appropriately skilled and suitably trained maintenance personnel familiar with generator set operation and service.

### Operation in EU Member Countries

This generator set is specifically intended and approved for operation below the deck in the engine compartment. Operation above the deck and/or outdoors would constitute a violation of European Union Directive 2000/14/EC noise emission standard.


REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

### Raw Water Strainer Maintenance

Periodically check the raw water strainer for debris and clean as necessary (see Figure 3.34.1).

1. Ensure generator is not running.
2. Remove the cap.
3. Remove the strainer and clean it of debris.
4. Replace the strainer.
5. Replace the cap.

Raw Water Strainer  
Figure 3.34.1



- 1 STRAINER
- 2 REMOVABLE CAP
- 3 OUTLET
- 4 CLEAR BODY
- 5 INTAKE SEACOCK

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

## Diesel Generator (Option)

Your boat's AC electrical system operates on 120V/60Hz or 220V/50Hz from the generator and/or shore power.

**It is recommended that you read and understand the information in the manufacturer's owners manual before operating the generator.**

If equipped, the Fischer Panda 12KW diesel generator powers your boat's electrical system through the AC Main Breaker Panel. Connections to the AC electrical system are made through the slide selector switch on the AC panel. There is a remote operation panel also located on the 120V AC main distribution panel on the port side of the cabin.

The generator has a built in cooling pump which draws cooling water through a seacock located in the aft machinery compartment. The raw water passes through a strainer before entering the engine cooling manifold. The seacock **MUST** be open in order for the generator to function. **Inspect the strainer frequently and clean if necessary.**


### Fuel

Use a clean, good quality diesel fuel with a cetane number of 45 or greater. Clean fuel prevents the fuel injectors and pumps from clogging. Avoid storing the fuel for more than a month. Take care to keep

## NOTICE

**Fuel Recommendation  
# 2 Diesel**

Generator Control Panel  
Figure 3.35.1



## ! WARNING

**CARBON MONOXIDE** can cause severe NAUSEA, FAINTING or DEATH. The exhaust system must be leakproof and routinely inspected.

**FIRE** Can cause SEVERE INJURY or DEATH. Do not smoke or permit flames or sparks near fuels or the fuel system.

**EXPLOSIVE FUEL VAPORS** Can cause SEVERE INJURY or DEATH. Use extreme care when handling, storing and using fuels.

**MOVING PARTS** Can cause SEVERE INJURY or DEATH. Operate the generator set only when all guards, screens and covers are in place.

all dirt, water and other contaminants out of the fuel to prevent the growth of microbes. Microbes form slime that clogs the fuel filter and lines.

The generator draws fuel from its own tank located on the starboard aft side of the machinery compartment. The fuel system has its own fuel and water separating filters.

The exhaust from the generator passes through a high efficiency marine lift type water cooled muffler and is discharged by a flexible hose via an aft starboard through hull fitting.

The generator cover acts as protection and a sound shield. It can be removed by pulling latches located on the bottom of the housing.

## NOTICE

**NEVER store diesel fuel in galvanized containers; the galvanized coating reacts chemically to produce flaking that quickly clogs filters or causes fuel pump or injector failure.**

## Starting the Diesel Generator

### ATTENTION


Ensure generator seacock is open before starting. Close seacock when generator is not in use to prevent generator damage while underway.

### CAUTION

**DO NOT start the generator if water has accumulated beneath the generator.**


Your owner's manual packet will have the complete operations manual for your generator. Be sure to read the manual before operating the generator. Several key points are indicated below:

- Locate the blower switch on the AC Breaker Panel and operate the blower for four (4) minutes. Manually check the bilge for fuel or fuel vapor.




**NOTE:** ALWAYS run the blower when operating below cruising speed.


- Refer to the Manufacturers Operations Manual for a Pre-Start Checklist.
- OPEN the generator seacock.



- Make sure that ALL breakers on the AC Panel are switched OFF.



- Slide the selector on the AC Panel to expose the GENERATOR & BRIDGE switches.




Switch the line breakers ON.


### WARNING

**Under no circumstances override the source select system.**

- Press the On/Off button on the remote start panel. The indicator light will illuminate and the fuel gauge will be activated.



- Press and release the START button ONLY ONCE. The light will begin blinking and the generator will start.




**DO NOT press the button more than once.** Allow for a 60 second cool down period between cranking attempts.

If the generator fails to start after the first attempt, check fuel flow, if ok, attempt start sequence again.

If the unit fails to start after 3 attempts, contact an authorized dealer/distributor for service.

- After a successful start, breakers can be switched ON.




### NOTICE

**DO NOT run the generator set out of fuel because the fuel lines will draw in air and necessitate bleeding the system before restarting the unit. The operations manual included in the owners packet will have complete instructions on bleeding the fuel system should it be needed.**

## Stopping the Diesel Generator


- Make sure that ALL breakers on the AC Panel are switched OFF.




## NOTICE

**If the electrical load has been operating at more than 70 percent or if the ambient temperature is higher than 77° the generator temperatures should be stabilized by turning OFF the breakers at the AC panel and letting the generator run for a minimum of 5 minutes before shutting down.**


- To STOP the generator, press the Start/Stop button.



- Press the On/Off button to de-activate the panel.



- Close the seacock.



## Maintenance

### ! WARNING

Accidental starting can cause severe injury or death. Disconnect the battery cables before working on the generator set. Disconnect the negative, (-) cable first when removing and reconnect it last when replacing.

Your Fischer Panda operations manual will have a complete maintenance schedule that will need to be followed to keep your generator in peak operating condition.

Inspect the parts often and perform required service at the prescribed intervals (See NOTICE below). Maintenance work must be performed by appropriately skilled and suitably trained maintenance personnel familiar with generator set operation and service.

## NOTICE


**Your first maintenance is required at 35 hours, by a qualified technician, at which time a maintenance checklist must be completed.**

**Failure to comply will invalidate the generator warranty.**

### Generator Fuel Filter

A fuel filter located on the starboard wall of the bilge, forward of the diesel fuel tank provides clean fuel to the generator.

A major cause of poor starting or power loss is the result of a clogged filter element or a fuel system air leak.





### Fuel Filter Maintenance

#### Replacing the Filter

Replace the filter according to manufacturers recommendations or if a power loss is detected.

1. Ensure engine is not running
2. Remove bottom casing.
3. Remove the filter by slowly pulling upward with a twisting motion.
4. Insert the new filter with a slow downward twisting motion.
5. Fill the filter with clean fuel.
6. Replace the bottom casing. **DO NOT** overtighten.

### NOTICE

**It is recommended that spare filters are carried aboard as contaminated fuel can easily clog a filter.**


### Raw Water Strainer Maintenance

Periodically check the raw water strainer for debris and clean as necessary (see Figure 3.38.1).

1. Ensure generator is not running.
2. Remove the lid.
3. Remove the strainer and clean it of debris.
4. Replace the strainer.
5. Replace the lid.

Raw Water Strainer

Figure 3.38.1



- 1 OUTLET TO GENERATOR
- 2 STRAINER
- 3 INTAKE SEACOCK

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

### Operating Generator in EU Member Countries

This generator set is specifically intended and approved for operation below the deck in the engine compartment. Operation above the deck and/or outdoors would constitute a violation of European Union Directive 2000/14/EC noise emission standard.

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.


### Shore Power

If equipped the shore power system provides dockside power to operate all of your boat's electrical system and charge your batteries.

Use the supplied 50 ft. power cord to connect your boat to a dockside power source. The on board receptacles are located under the aft starboard gunwale. The AC Main Breaker panel for the shore power system is located on the aft wall of the console interior.

Shore Power hookups

Figure 3.39.1



- ① SHORE POWER INTERMEDIATE BREAKER
- ② ELCI (EQUIPMENT LEAKAGE CIRCUIT INTERRUPTER)
- ③ SHORE POWER RECEPTACLE
- ④ LINE 2 SHORE POWER INTERMEDIATE BREAKER
- ⑤ LINE 2 ELCI (EQUIPMENT LEAKAGE CIRCUIT INTERRUPTER)
- ⑥ AFT STARBOARD COCKPIT
- ⑦ LINE 2 SHORE POWER RECEPTACLE

### ⚠ DANGER

**EXTREME HAZARD** - Swimming near a boat operating on an AC electrical system can lead to severe shock and/or death. Never swim or allow swimming when AC system is in use.

### ELCI (Equipment Leakage Circuit Interrupter)

The shore power system on your boat includes an ELCI (Equipment Leakage Circuit Interrupter) located on the aft starboard freeboard (See figure 3.39.1).

The ELCI is designed to protect people from line-to-ground shock hazards which may occur from defective, misused or neglected electrical equipment. The ELCI will not prevent line-to-ground electric shock, but does limit the time of exposure to a period considered safe for normal healthy persons. If an imbalance of current is sensed, the ELCI will trip when the ground fault exceeds 0.030 amps. This tripping action will occur within a fraction of a second to prevent serious injury.

### ⚠ DANGER

**The receptacle will not protect against line-to-line or line-to-neutral faults, short circuits or overloads.**

#### TESTING & TROUBLESHOOTING TEST BEFORE EACH USE

**NORMAL OPERATING STATE** - Sensing device GREEN LED is ON and circuit breaker is at ON position.

**Step 1** - Press TEST button. GREEN LED should go OUT and RED LED should come ON and circuit breaker should trigger to OFF position.

**Step 2** - If sensing device LED or breaker does not trip or change state DO NOT USE. Consult an electrician for assistance.

**Step 3** - Press RESET button. The RED LED should turn OFF and the GREEN LED should turn ON.

**Step 4** - Manually reset (switch) circuit breaker to ON position to restore circuit power.

### WARNING

IF ABOVE TESTS FAIL, **DO NOT USE.**  
CONSULT A QUALIFIED ELECTRICIAN FOR  
REPAIR OR REPLACEMENT.


## ⚠ CAUTION

- Be certain that the shore power main switch is turned OFF before connecting the power cord cordset.
- Connect the cordset to the boat inlet first, then to the shore inlet.
- NEVER alter the cordset connectors.

### Shore Power Operation


Before making shore power connections make sure your boat is properly moored.

- Slide the covers on the shore power 1 & shore power 2 panels to expose the “MAIN” breakers.




- Make sure the breakers are OFF.

- Assure that ALL component breakers are OFF.




- Using the shore cords, (supplied) connect the female plug to the boat receptacle first.



## ⚠ CAUTION


Shore power cords should be secured or routed to avoid laying or falling into water and to avoid stress on shore power plug and inlet.

- Next connect the male plug to the dockside panel.




- Turn dockside panel breakers ON.


- Switch the boat side shore power breaker(s) ON.



- Switch the shore power main breaker(s) ON.



- It is now safe to turn on component breaker.



## ⚠ CAUTION

The use of extension power cords is not recommended. Excessive power cord extensions can cause a voltage drop and may prevent some electronic devices from operating properly.

## ⚠ CAUTION


It is imperative that the shore power outlet is dry before plugging into the dock power outlet.

# Chapter 3 • Overview & Operation

## Single Cord Shore Power


In some cases you may be limited to operating your boat's equipment utilizing only a single shore power cord. The following procedure will provide the most efficient power to the boat.

- Slide the covers on the panel to expose the GENERATOR & shore power 2 MAIN breaker.




- Make sure the breakers are OFF.


- Assure that ALL component breakers are OFF.



- Using the shore cords, connect the female plug to the boat receptacle first.




- Next connect the male plug to the dockside panel.




- Turn dockside panel breakers ON.


- Switch the boat side shore power breaker(s) ON.



- Switch the GENERATOR & shore power 2 MAIN breakers ON.




- It is now safe to turn on component breaker.



The single cord shore power scenario described in the previous column utilizes the generator to supplement power. Although this setup provides maximum voltage to your boat, you may find at times that the generator noise is too interruptive. You can still power your boat sufficiently by utilizing the breakers as follows:

- Slide the covers on the panel to expose the SHORE POWER #1 & BRIDGE breakers.



- Make sure ALL breakers are OFF.

- Proceed with setup as described above.

### Battery Charging

In addition to supplying AC power to your boat, shore power hookup gives you the ability to charge your batteries without running the engines.

The system is automatic and little or no maintenance is required. The aft battery charger (engine batteries) can be accessed through the equipment hatch in the aft cockpit deck.

The forward battery charger (house batteries) can be accessed by lifting the forward bunk base in the cabin.

### Shore Power Load Management

Your boat is equipped with many devices that require AC power for their operation. While many of these devices are continuous use items, others are not.

The design of the electrical system has been optimized to support the most commonly used equipment. However, there may be situations where the operator will need to power off certain appliances based on load requirements, shore power connections and/or generator operation.

To obtain the most power for your appliances, it is best to use the “GENERATOR” and “SHORE POWER 2” combination which will deliver a higher load capability.

### Isolation Transformer

Your boat is equipped with isolation transformers which blocks low voltage DC on the shore power ground wire.

The isolation transformers prevent dockside electrolytic voltages from damaging the metal parts of your boat which come in contact with the water. Additionally, the isolation transformers will safely conduct high currents (above 1.5 volts) to ground in the event of a short circuit or power leakage on your boat.

### Maintenance

The isolation transformers on your boat are highly reliable. They should, however, be tested once per season, and re-tested after a condition that may have influenced them, such as a lightning strike in the

vicinity, or on-board electrical short that either caused a circuit breaker or fuse to blow.

### CAUTION

**Under normal conditions the zincs on your boat should last at least one year, much longer if no problems occur. If abnormal deterioration of the zincs occur a problem exists and should be corrected immediately.**

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

### Fire Suppression System

### NOTICE

**The fire extinguishant contained in this unit is CHLOROTETRAFLUORATHANE, None of the components in this material is listed by major health associations as a carcinogen. Toxic by-products are produced when this agent extinguishes fire. Avoid breathing these fumes.**

Your boat has a USCG approved automatic fire suppression system. The Extinguisher is located in the port side of the machinery access compartment. The system will activate when the temperature in the enclosed area reaches 165°F (74°C).

### DANGER

**DO NOT handle the actuator. The fire suppression system is under pressure (195 psi.). Accidental discharge may result in death or serious injury.**

When activated there will be a bang, (similar to small arms fire) followed by a rushing air sound. Once activated the engine and blower will shut down automatically.

A small panel located at the console will indicate that discharge of the suppression system has occurred

Fire Suppression Indicator  
Figure 3.43.1



### In The Event of Discharge:

- Shut down all electrical systems, engines and extinguish all smoking materials.
- Allow the agent to “soak” the compartment for at least 15 minutes.
- DO NOT open the machinery access compartment hatch.
- DO NOT breathe the fumes or vapors caused by fire as they are hazardous and toxic.
- When opening the hatch, have a portable fire extinguisher at hand and ready for use.
- High concentrations of the agent may cause DEATH without warning. The vapor reduces available oxygen for breathing.
- If possible; allow the compartments vapor to dissipate before opening the hatch.

## ⚠ DANGER

Inhalation of high concentrates of the contents of the fire suppression tank may cause sudden death without warning.

Skin contact will require flushing of the area with water for at least 15 minutes. Seek immediate medical assistance.

## ⚠ CAUTION

NEVER attempt to modify or disassemble any components of this system. If the system has been discharged, have a qualified technician replace it.

The automatic fire extinguisher can be activated manually by pulling the manual override handle located on the starboard freeboard midship.


Early detection and use of the manual override system will reduce fire damage by eliminating the time necessary for heat in the bilge to rise sufficiently to activate the automatic fire system.

### Manual Override System

#### To Operate

1. Remove pin securing the handle.
2. Pull red FIRE handle quickly and briskly.

Fire Suppression Panel  
Figure 3.43.2



- 1 MANUAL AUTOMATIC FIRE SUPPRESSION SYSTEM
- 2 ACTIVATION HANDLE
- 3 HANDLE SECURING PIN
- 4 STARBOARD GUNNEL

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.


## Dive Door

The innovative design of the 380 Outrage includes a port side door for ease of transition to and from the water or dock. The door opens wide and features a fold away grab handle to assist persons entering or exiting the water.

To use the grab handle, lift up and swivel into place.

The stainless steel deck bracket accommodates a removable ladder which is stowed in the base of the aft bench seat when not in use (Figure 3.44.2).

Dive/Boarding Door  
Figure 3.44.1



- ① PORT SIDE FIBERGLASS DIVE DOOR
- ② STAINLESS STEEL DECK BRACKET
- ③ SWIVEL GRAB HANDLE
- ④ STAINLESS STEEL LATCH

### **⚠ DANGER**

**Ensure that door is closed and securely latched when boat is underway.**

## Dive Ladder

### **⚠ DANGER**


**The dive ladder should NEVER be deployed when boat is in motion or the engines are running.**

**To avoid risk of injury or death, shut off engines when using the dive door to enter or exit the water.**

The installation of the dive ladder is quick and easy.

- Remove the ladder from its stowed position on the base of the aft bench seat.
- Rotate the brace at the top of the ladder so that it is perpendicular to the shaft.

Dive Ladder Installation  
Figure 3.44.2



- ① DIVE LADDER (STOWED)
- ② LOCKING PIN RELEASE RING
- ③ DIVE LADDER BRACE
- ④ LOCKING PIN
- ⑤ DECK BRACKET

- Insert the two pegs on the brace into the deck bracket.
- Secure ladder into place by pushing brace outboard until it seats firmly into bracket and locking pin has snapped into place.


## Collapsible Swim Ladder

The unique swim ladder can be folded and stowed into the transom cavity.

### Using the Swim Ladder:

- Pull UP on the latch cord to release the ladder
- Pull the ladder completely out of the transom
- Rotate ladder downward
- Pull individual steps out of stowed position and rotate completely until seated firmly.


Swim Ladder  
Figure 3.44.3



- ① TRANSOM BRACKET
- ② SWIM LADDER
- ③ COLLAPSIBLE STEPS

To remove the dive ladder from the dive door bracket:

- Pull up and hold the release ring.
- Pull dive ladder brace inboard and lift up out of the deck bracket.



- Secure the ladder into place on the aft bench seat (see Figure 3.44.2).

## NOTICE


**ALWAYS use bungee straps to secure the dive ladder in the aft bench seat brackets (see Figure 3.44.2).**

### Fishboxes with Pump Out Discharge

The 380 Outrage has three deep well, insulated fishboxes. One each located port and starboard in the cockpit and one in the forward deck. The boxes have gasket sealed lids and draw latches for a secure seal. The fishboxes utilize an electrical pump system to discharge water overboard by way of thru-hull fittings port and starboard.

The cockpit discharge pumps are located in the bilge and can be accessed through the hatch in the aft cockpit deck. The forward discharge pump can be accessed through a hatch under the bunk in the forward cabin.


The cockpit pumps are independently activated by switches on the starboard helm switch panel and are protected by breakers located on the DC distribution panel located midship on the starboard gunnel.



The forward fishbox pump is activated by a switch located on a panel on the bow starboard gunnel. If a problem arises with the pumps failing to activate when the switches are depressed, check these breakers first and reset.

### Fishboxes

Figure 3.45



- 1 AFT COCKPIT FISHBOX\*
- 2 FORWARD FISHBOX
- 3 FORWARD FISHBOX DISCHARGE PUMP
- 4 FORWARD FISHBOX DISCHARGE SWITCH

\* Port side shown, starboard typical.

## NOTICE

**Water from the forward cockpit fishbox drains into the shower sump where it is then discharged through the thru hull fitting.**

### Cockpit Fishbox Freezer Plates (Option)

The optional freezer plates are available as a single unit for the aft starboard cockpit fishbox or as a dual installation utilizing both the aft port and starboard fishboxes.


If equipped, the optional fishbox freezer plates transform the cockpit fishboxes into a deep cold cooler.



The compressor for the freezer plate(s) is located behind an access panel on the lower starboard side of the console interior behind the vanity.

The system utilizes the A/C intake seacock to provide the raw water necessary for the plate(s) to function. The water is discharged through a thru hull fitting on the starboard side of the hull.

The temperature of the fishboxes can be regulated from the temperature control panel located below the AC distribution panel in the upper cabinet on the port aft of the cabin.



### Electric Downrigger Receptacles (Option)

If equipped, the two (2) 12V/30 amp electrical receptacles for powering electric downriggers, or any electrical equipment aptly rated, are located inside the cockpit on the aft section of the port and starboard gunwales. The plugs are supplied in the owners packet when this option is purchased.

Push the plug into the receptacle and turn clockwise to secure the connection.

The receptacles are protected by 30 amp in-line fuses located in the transom and can be accessed through the hatches behind the aft stern seat. The receptacles are active when the battery switches are ON.

The receptacles are protected by a weatherproof cover. There are areas on the gunwales that are designed specifically for downrigger mounting bases. See *Wood Location Diagram, Chapter 5, Care & Maintenance*.

There are downrigger weight cradles located in the port and starboard cockpit to store your downrigger weights when not in use.


Consult with your Boston Whaler dealer for details on selecting and mounting the downriggers that will best suit your application.

### CAUTION

The location for mounting of the downrigger base is important, refer to the wood location diagram in *Chapter 5 Care & Maintenance* for areas on the gunwales that are specifically designed for withstanding the stress generated by a downrigger.

There are a variety of downrigger mounting base plates that can be used, it is important that you consult with your salesperson to find the mounting base that will best suit your application.

12V/30 Amp Receptacles (option)  
Figure 3.46.1



- ① 12V/30A RECEPTACLE (P&S)
- ② PLUG (SUPPLIED)

NOTE: Port side shown, Starboard side typical


REFER TO THE DOWNRIGGER MANUFACTURER'S MANUAL FOR COMPLETE INSTRUCTIONS AND WARRANTY.

## Foldaway Trolling Seats (Option)

### ! CAUTION

Trolling seats are for use **ONLY** when your boat is stopped or at slow trolling speed. **DO NOT** use the trolling seats above trolling speeds as injury can occur.

Unique trolling seats are located on the port and starboard walkways opposite the console. The seat is folded away into the freeboard when not in use but can be dropped down to provide stable additional seating when necessary.




Simply lift up on the seat using the molded hand hold and pull away from the freeboard to drop down in a seated position.


## Foldaway Aft Bench Seat

When the aft bench is not in use it can be folded flush into the transom. To use the seat; raise the bolster, then, using the handle lift the seat up and out toward you and push down.

Aft Bench Seat  
Figure 3.47.1



Starboard Cockpit Bench Seat  
Figure 3.47.2




## Foldaway Cockpit Bench Seat (option)

If equipped, the starboard bench (Figure 3.47.2) can be folded flush into the gunnel when not in use. To use the seat; raise the bolster, then, using the handle lift the seat up and out toward you and push down.

## Stowable Cockpit Tables (Option)

Your boat can be equipped with a tables for entertaining in the cockpit. The tables are removable and stowable. If equipped, the tables and pedestals are stowed in the underside of the mechanical hatch in the aft cockpit deck.

Cockpit Tables (Option)  
Figure 3.47.3



- 1 TABLE LATCH
- 2 TABLES (STOWED)
- 3 MECHANICAL ACCESS HATCH
- 4 PEDESTALS (STOWED)

## To set up the tables:

- Remove the table top from the underside of the mechanical access hatch by pulling the knob on each of the corner latches and rotating it away from the stowed table.
- Set tables aside in the cockpit.
- Remove the pedestals from the storage clips and place them upright in the receiver plates located on the top of the mechanical hatch in the cockpit.
- Place the tables on the top of the pedestals and assure that they are securely seated on the pedestals.

## Bow Table (Option)


### ATTENTION

Cover table with the included cover when not in use. Refer to Teak care instructions in Chapter 5.

The optional bow table is electrically actuated, powered by the house batteries. The switch to raise and lower the table is located on a panel on the starboard bow gunnel (Figure 3.48.1).

Fully raised, the table can be used for entertaining in the bow. When completely lowered the table becomes a stable surface for the optional cushion which expands the lounge surface of the bow.

Bow Table (Option)  
Figure 3.48.1



- ① BOW TABLE SWITCH
- ② BOW TABLE W/CUSHION

## Leaning Post Refrigerator/Freezer

The 12V/120V refrigerator/freezer is located on the port side of the Leaning post.

The refrigerator/freezer is powered by shore power, if connected or generator. The "PORT REFRIG" breaker on the AC Main Distribution Panel (See page 4-8) must be ON to operate the refrigerator.


The refrigerator/freezer can also be powered by the house batteries. The "P REFRIG" breaker located on the DC distribution panel (See page 4-6) must be ON to operate the refrigerator with battery power.

### NOTICE

To avoid draining the batteries, the refrigerator and/or battery switch must be turned OFF.

## Leaning Post Refrigerators

Figure 3.48.2



- ① 12V/12V REFRIGERATOR/FREEZER
- ② AFT FACING COUCH
- ③ SUMMER KITCHEN
- ④ STBD REFRIGERATOR (OPTION)\*

### Leaning Post Refrigerator/Freezer (Option)

The optional 12V/120V refrigerator/freezer is located on the starboard side of the Leaning post.

The refrigerator/freezer is powered by shore power, if connected or generator. The “STBD REFRIG” breaker on the AC Main Distribution Panel (See page 4-8) must be ON to operate the refrigerator.

The starboard refrigerator/freezer can also be powered by the house batteries. The “S REFRIG” breaker located on the DC distribution panel must be ON to operate the refrigerator with battery power.

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

### Electric Grill (Option)

#### **WARNING**

**Please read and understand the safety precautions found in the Kenyon® Custom Electric Grill owner's manual located in your owner's packet.**

If equipped, the electric grill provides a safe method of grilling without the hazard of open flames associated with propane gas or charcoal grills.


The grill is powered by shore power, if connected or generator (option). The “GRILL” breaker on the AC Main Distribution Panel must be ON to operate the grill.

A concealed electric element eliminates grease flare-ups and a reusable grease pan located under the heating element collects all the fat and juices associated with grilling. **The grease pan must be emptied after each use.**

**To remove the grease pan (see Figure 3.49.1):**

- Remove the grate.
- Lift the heating element.
- Remove the grease pan.

Electric Grill (Option)  
Figure 3.49.1



- ① ELECTRIC GRILL
- ② REMOVABLE GREASE PAN

When replacing the pan, assure that it is completely contained within the grill and that the side of the pan does not extend outside of the grill sides.

#### **NOTICE**

**To prevent the contents of the grease pan from smoking, place 1 cup of water in the grease pan before cooking.**

#### **Automatic Shut-Off**

There is an automatic shut-off switch located at the back of the grill. When the leaning post cover is closed the shut-off switch is engaged and power to the grill will be turned off. Do not under any circumstances override the automatic shut-off switch.

#### **CAUTION**


#### **Electric grill is dangerously hot.**

**Depending on the level of heat used for cooking, the grill will automatically shut off 60-90 minutes after ignition. However, it is good practice to close the lid when not in use. This action will engage the automatic shut-off switch and cut power to the grill.**


REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

## Fold Down Visibility Platform

The innovative design of the helm incorporates a foldaway platform which can be lowered to provide improved visibility for shorter operators or when conditions mandate.



Radial Outriggers (Option)  
Figure 3.50.2



- ① HARDTOP
- ② ROTATION ADJUSTMENT HANDLES
- ③ POWER CRANK HANDLE
- ④ LOWER UNIT
- ⑤ UPPER UNIT
- ⑥ SHAFT LOCK
- ⑦ EXTENDABLE SHAFT


## Radial Outriggers (Option)

If equipped, there are two radial outriggers. One each located on the port and starboard side of the hardtop. The outriggers are adjustable to provide ease of operation and convenient ready-to-use storage.

### Operation

#### Extending Outriggers:


Starting with the outboard section, extend each section out until the locking button snaps into place.



#### To position the outriggers:


#### Raising or lowering:

Extend the power crank handle out and lock into place. To raise, turn handle clockwise. To lower, turn handle counterclockwise




#### Rotating Outriggers:

Pull down on the lower unit handle and rotate to the desired position. When released the handle will hold the outrigger shaft into position.



## Retrieving Outriggers:

Starting with the inboard most section, Push in the locking button on each succeeding section and insert sections into the shaft until all sections are completely seated in the stowed position.



## Maintenance

When at port, extend the outriggers and clean with a mild, non-abrasive soap and fresh water, wipe with a dry cloth and allow to air dry. When dry, collapse the outriggers to the stowed position. Periodically lightly lubricate the cam and the shaft of the cam knob.


## Gemlux® Radial Outriggers (Option)

If equipped, there are two radial outriggers. One each located on the port and starboard side of the hardtop. The outriggers are adjustable to provide ease of operation and convenient ready-to-use storage. The outriggers use the same handle for raising, lowering, and swinging the outriggers.

## Operation


### To Raise and/or Lower the Outriggers:

With the handle in the “down” position use the knob for grip and rotate the handle clockwise to raise or lower the outrigger in the desired position.




### To Swing the Outriggers in and/or out:

Once the desired height is reached, flip the handle to the “up” position. Grab firmly on the handle, and rotate the handle to position the outrigger to the desired fishing position.



Leaving the base in the down position will keep the base from rotating while fishing and running.


Gemlux Radial Outriggers (Option)  
Figure 3.51.1



- ① ROTATION ADJUSTMENT HANDLE
- ② LOWER UNIT
- ③ UPPER UNIT
- ④ HARDTOP


### To extend the outriggers:

Starting with the outboard section, extend each section out until the locking button snaps into place.



### To retrieve the outriggers:

Starting with the inboard most section, Push in the locking button on each succeeding section and insert sections into the shaft until all sections are completely seated in the stowed position.



## ATTENTION

The outriggers have an operable angle (up and down) of 65 degrees to 10 degrees. Please keep this in mind when making adjustments to your outriggers.

## Maintenance

With very little care your equipment will maintain its appearance and operate trouble free. When at port, extend the outriggers and flush with fresh water, wipe with a dry cloth and allow to air dry. When dry collapse the outriggers to the stowed position.

### CAUTION

**Always ensure clearance of bridges, lights, power lines, etc. while operating your vessel.**

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.


## Hardtop Access

A hatch on the port side of the hardtop and the unique ladder-like design of the hardtop frame provide easy access the surface of the hardtop, if necessary, for maintenance or repair of hardtop mounted equipment.

### DANGER

**To avoid risk of injury or death, DO NOT occupy hardtop while boat is in motion.**


Hardtop Hatch  
Figure 3.52.1




## Spotlight (Option)

If equipped, the optional spotlight is mounted forward on the hardtop.

The spotlight with Directional Flexibility is controlled by a wireless remote located at the helm station which gives the operator a full 360° horizontal rotation and vertical tilt with fingertip control.



Spotlight Control  
Figure 3.52.2



REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS.


## Thermal Night Vision (Option)

If equipped, the fixed mount thermal night vision camera (Figure 3.52.3) gives the operator the ability to detect floating objects, navigation aids, other vessels and even people in the water at night using thermal imaging technology.

The camera is controlled remotely from the IR camera application on the helm display.

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

Thermal Night Vision (Option)  
Figure 3.52.3



## Electric Windshield Vent

The windshield vent at the top of the windshield is electrically actuated. A switch labeled “VENT” is located on the port helm switch panel (see Figure 2.53.1).

By depressing the top of the switch you can open the vent. To close the vent depress the bottom of the switch. The vent switch is a momentary switch which means that it must be depressed and held in position for the vent to open or close completely.

## Windshield Wiper/Washer


The windshield wiper is controlled by a toggle switch labeled “WIPER” on the port helm switch panel (Figure 3.53.1). The switch is protected by a reset breaker located on the DC Main distribution panel located on the starboard freeboard, midship .

The windshield washer is activated depressing the switch labeled “WSHR” located on the port helm switch panel (Figure 3.53.1)

### NOTICE

**Recommended Blade replacement:  
ANCO wiper blades - 28 inches**

Windshield Vent  
Figure 3.53.1



- ① WINDSHIELD VENT SWITCH
- ② WINDSHIELD WASHER SWITCH
- ③ WINDSHIELD WIPER SWITCH
- ④ ELECTRIC WINDSHIELD VENT

## Electric Sun Shade (Option)


If equipped, the electrically actuated cockpit sun shade can be deployed or retracted by depressing the “SHADE” switch located on the port helm switch panel (see Figure 2.53.1).

The sun shade is protected by a breaker located on the DC Main distribution panel located on the starboard freeboard, midship. Follow the canvas care instructions in chapter 5 of this manual to keep the sun shade fabric clean.

### NOTICE

**A reset functionality has been incorporated into the sun shade controller to enable a service technician to quickly reset the shade position. In the event the shade does not operate at either the fully extended or fully retracted position, contact a Boston Whaler dealer for details.**

Electric Sun Shade  
Figure 3.53.2



- ① SUN SHADE SWITCH
- ② ELECTRIC SUN SHADE

### CAUTION

**In rough seas the sunshade should be stowed to prevent damage to the rails and or curtain.**



## Entertainment System

### Stereo

The AM/FM stereo is Sirius XM™ ready, iPhone and Android phone compatible. The stereo system is automatically provided power when the house battery switch is turned on.

The control knob on the helm along with the forward port and starboard remotes control the deck speakers. A remote receiver installed inside the cabin starboard side access panel is networked into all three controls and provides the radio signal. Cabin speakers are not connected this system. The speakers inside the cabin are controlled from a separate *Stereo Control Head* located in the port cabinet.


Provisions for controlling the stereo system:

- *MediaMaster* app on the helm display (see Figure 3.54.1).
- Volume/mute *Stereo Control Knob* located on the console to the starboard of the helm (see Figure 3.54.2).
- *Stereo Control Head* inside the cabin cabinet (see Figure 3.55.2).
- *Stereo Control Bow Starboard* located under the forward starboard gunwale (see Figure 3.55.1).


- There are three stereo remote controls. One located loose inside the owner's packet. One located under the forward port gunwale (see Figure 3.55.3). One located on the leaning post starboard side (see Figure 3.39.4).

REFER TO OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.


Stereo Control Knob  
Figure 2.54.2



Helm Display  
Figure 3.54.1




Stereo Control, Forward Starboard Side  
Figure 3.55.1




- ① STEREO CONTROL HEAD
- ② FWD FISH BOX SWITCH
- ③ BOW TABLE SWITCH
- ④ 12V OUTLET


Stereo Remote Control Bow Port  
Figure 3.55.3



Stereo Remote Control Leaning Post Port  
Figure 3.55.4



Stereo Control Head, Cabin Port Side  
Figure 3.55.2



## Cockpit Lighting

Blue rope lighting is placed throughout the cockpit, forward and aft. There are also four courtesy lights (white) in the mechanical bilge, three courtesy lights (blue) in the bow storage compartments, one courtesy light (white) in the anchor locker, and three courtesy lights (white) in the console storage garage.

The lights are controlled by the “CTSY LTS” switch on the port helm switch panel. They are protected by the “DECK CTSY LIGHTS” breaker on the DC distribution panel located on the starboard midship gunnel.

The switch on the helm switch panel is a three position switch which allows for blue or white lighting selection (Figure 3.56.1).

## Hardtop Lighting

The hardtop of the 380 Outrage has six blue aesthetic lights, one dual lamp (red & white) map light, one bow area flood light and two aft cockpit flood lights (Figure 3.56.2).


The blue lights are located around the underside perimeter of the hardtop. They are powered by the “DECK CTSY LIGHTS” switch on the helm switch panel.

## Map Lights

The dual lamp (red & white) map light directly above the console is powered by the “MAP LTS” switch on the helm switch panel and are protected by the “MAP LIGHTS” breaker on the DC distribution panel located on the starboard midship gunnel. The switch on the helm switch panel is a three position switch which allows for red or white lighting selection (Figure 3.56.3).

## Hardtop Lighting


Figure 3.56.2



- ① BLUE AESTHETIC LIGHTING
- ② DUAL LAMP (RED/WHITE) MAP LIGHT
- ③ FORWARD BOW FLOOD LIGHT
- ④ AFT COCKPIT FLOOD LIGHTS

## Map Lights Switch

Figure 3.56.3




## Flood Lights

The flood lights are powered by the “FLOOD LTS” switch (see Figure 3.56.4) on the port helm switch panel. They are protected by the “FLOOD LIGHTS” breaker on the DC distribution panel located on the starboard midship gunwale. The switch on the helm switch panel is a three position switch which allows for forward or aft lighting selection.


## Courtesy Lights Switch

Figure 3.56.1



## Flood Lights Switch

Figure 3.56.4



## Cabin Lights

There are LED diffused (blue) lighting throughout the cabin along with four overhead lights (white) which are controlled by a switch on the aft, port entry wall of the cabin.


## Underwater Lights (Option)

If equipped, there are four blue underwater lights located on the transom just below the surface of the water and two lights, one each port and starboard in the trim pocket of the hull. When lit the lights illuminate the water in a translucent blue glow which enhances the after dark experience of being on the water and in addition may on occasion attract a myriad of marine life.

The underwater lights are powered by the “U/W LIGHTS” switch on the port helm switch panel. The lights are protected by the “U/W LIGHTS” breaker on the DC distribution panel located on the starboard midship gunwale.

### Underwater Lights

Figure 3.57.1



- 1 TRANSOM UNDERWATER LIGHTS
- 2 TRIM POCKET UNDERWATER LIGHTS

### CAUTION

Underwater lights are not to be used when navigational lights are in use as this may interfere with the effectiveness of the navigational lights.

## Sun Lounge Storage Garage


Under the console sun lounge there is a large, lockable, lighted area for storage of equipment and personal items. Two five gallon buckets, and a 36 quart cooler are included. There is a 120V outlet located on the port side of the storage area.

## Dive Tank Racks (option)

If optional dive tank racks are chosen there are four racks included in the storage garage


### Sun Lounge Storage Garage

Figure 3.57.2



- 1 SUN LOUNGE STORAGE GARAGE
- 2 DUAL USB CHARGING DOCK
- 3 ADJUSTABLE ARMREST (P&S)
- 4 CUP HOLDERS
- 5 TWO (2) 5-GAL BUCKETS
- 6 36 QUART (34 L) COOLER
- 7 DIVE TANK RACKS (OPTION)

Gyro Stabilizer (Option)  
Figure 3.58.1



- ① SEAKEEPER GYRO STABILIZER
- ② WATER STRAINER W/ INTAKE SEACOCK
- ③ SEAWATER PUMP TO GYRO

## Seakeeper Gyro Stabilizer (Option)

### NOTICE

**The generator must be ON in order for the gyro stabilizer to function.**

If equipped, the innovative gyro stabilizer is located above the fuel tank in the center of the cockpit.

The stabilizer uses gyroscopic principals to reduce boat roll motions in waves and wakes independent of boat speed. The stabilizer eliminates the risk of motion sickness and safely walking around the deck in rough water.

Spool-up Time to Rated Speed - **50 minutes**


Spool-up Time to Stabilization - **35 minutes**

Full speed to zero RPM - **approx 2 hours**

In addition to the gyro assembly a remote display unit is located at the control console.

REFER TO THE MANUFACTURER'S MANUAL IN YOUR OWNER'S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

Gyro Stabilizer Remote Display (Option)  
Figure 3.58.2



- ① ON/OFF AND FAULT RESET
- ② GYRO LOCK/UNLOCK
- ③ DISPLAY BRIGHTNESS (DAY/NIGHT)
- ④ SCREEN VIEWS (TOGGLE)
- ⑤ SETTINGS

### ! WARNING

**Gyro cover panels are provided to prevent personnel or equipment from contacting the gyro while it is in operation. These covers should not be stood on, or have anything placed on top. The covers should always be in place during operation. If it is ever necessary to touch the gyro while the flywheel is spinning, the gyro must be locked at the display to stop the gyro from precessing (tilting). Gyro maintenance should not be attempted unless the gyro is locked and the flywheel has stopped spinning.**

### Propeller

#### NOTICE

- **It is advised that you always carry a spare propeller, propeller hardware and propeller wrench on board. Should your propeller become damaged it can then be easily replaced.**
- **Under no circumstance should you use a propeller which allows the engine to operate at a higher than recommended RPM.**

The engines on your 380 Outrage have been equipped with propellers which our tests have shown to be best suited for general use under normal conditions and load. Your boat has been propped to achieve maximum RPMs which meet Mercury requirements.

### Trimming the Engines

When trimmed correctly, your boat will achieve maximum RPMs, minimize steering effort, allow for more stability and increased performance.

Trimming the engines IN full will drive the bow down causing the boat to plow through the water and will prevent the engines from achieving maximum RPMs.

Trimming the engines OUT will push the stern down and raise the bow. If OUT to far the maximum engine RPMs cannot be achieved.

A properly trimmed boat will have the bow slightly UP while running at full speed.


Different seas or operating conditions will necessitate running the boat in different trim positions. The operator will need to use his/her best judgement while boating in different conditions.

### Changing Propellers

In some situations you may wish to change the propeller to give your boat slightly different performance characteristics.

In general, changing to a lower pitch propeller will increase acceleration and load pulling capability, with

Propeller Assembly  
Figure 3.59.1




- ① ENGINE SHAFT
- ② FORWARD THRUST WASHER
- ③ DRIVE SLEEVE
- ④ INNER HUB
- ⑤ BLADE BACK
- ⑥ OUTER HUB
- ⑦ EXHAUST PASSAGE
- ⑧ DIFFUSER RING
- ⑨ PROP NUT
- ⑩ LOCK RING
- ⑪ DRIVE SLEEVE ADAPTER
- ⑫ BLADE TIP
- ⑬ LEADING EDGE
- ⑭ TRAILING EDGE
- ⑮ BLADE FACE

a slight decrease in top end speed. If you choose to change propellers, the type should be discussed with your Boston Whaler® dealer. All propellers are designed to provide maximum forward thrust, consequently, the reverse thrust of the propeller will not be as efficient. Propellers have two basic characteristics, diameter and pitch.

**Diameter** is that distance measured across the propeller hub from the outer edge of the 360° that is made by the propeller's blade during a single rotation.

**Pitch** is that distance in inches that a propeller will travel if rotated one revolution without any slippage.

Propeller Pitch & Diameter  
Figure 3.60.1



- 1 PITCH
- 2 DIAMETER

## ⚠ DANGER

Disconnect power by moving the battery switch to the "OFF" position prior to removing the propeller.


### Anchor Windlass

## ⚠ DANGER

Use the windlass switch on the helm whenever possible. Use care when operating the anchor windlass with the hand-held remote.

The anchor windlass located at the bow gives you a mechanical means of raising and lowering the anchor.

Windlass Switches  
Figure 3.60.2



- 1 HELM SWITCH PANEL
- 2 WINDLASS POWER SWITCH
- 3 WINDLASS OPERATION SWITCH

The anchor windlass is controlled by switches located on the port helm switch panel or by a hand held remote located in the bow locker (see Figure 3.60.2).


The "WINDLASS" switch on the port helm switch panel controls power to the windlass.

The operation switch is a momentary type switch which means that there must be constant pressure applied to the switch to operate the anchor windlass.

When not in use, the remote can be stored in a receptacle located on the aft bulkhead of the bow locker. The power source for the remote is located on the starboard side of the locker.

There is also an emergency handle which can be used to raise and lower the anchor manually in case the power to the anchor windlass is lost.

Windlass  
Figure 3.56.3



- 1 WINDLASS
- 2 ANCHOR CLEAT
- 3 CHAIN RODE
- 4 EMERGENCY HANDLE
- 5 WINDLASS REMOTE
- 6 FRESH WATER FITTING

Be sure to attach the anchor lanyard when the anchor is stowed in the bow pulpit.

## NOTICE

**ALWAYS SECURE THE LANYARD WHEN UNDERWAY**  
Failure to do so may allow accidental deployment of the anchor.

The windlass is protected by a 100 amp circuit breaker located on the DC distribution panel. If there is a loss of power to the windlass, check the “WINDLASS” circuit breaker. If the breaker is tripped, reset the breaker.

If the breaker continues to trip, have the anchor windlass system checked by a qualified marine electrician.

### Operation

#### NOTICE

**Before operating the windlass be sure that the anchor lanyard is removed from the anchor and is clear of the rode as it pays out or is retrieved.**

### Operating From the Helm

**LOWERING-** Pushing the top part of the switch down will power the anchor windlass DOWN. Make certain that the safety lanyard is detached from the chain and is clear of any moving parts of the anchor windlass.

**RAISING-** Pushing the lower part of the switch will power the anchor windlass UP. Once the anchor and rode is secure in the UP position, the safety lanyard can be re-attached to the rode.

### Operating From the Bow


The anchor windlass can be operated from the bow with the use of the windlass remote which is stowed in the bow locker.

#### ! WARNING

**Keep hands, feet, hair and loose clothing clear of moving parts. Entanglement may cause severe bodily injury (i.e. lose of fingers or toes).**

Windlass Remote

Figure 3.61.1




- ① HAND HELD REMOTE
- ② POWER SOURCE

#### ! DANGER

**Use the anchor windlass switch on the helm when possible. Use care when operating the anchor windlass with the hand-held remote.**

Anchor Windlass Remote

Figure 3.61.2




- ① WINDLASS REMOTE CONTROL
- ② “DOWN” BUTTON
- ③ “UP” BUTTON


The windlass remote is protected by a 10 amp manual reset breaker located on the battery switch panel. If there is a loss of power to the windlass remote, check the “WINDLASS CONTROL” breaker. If the breaker is tripped, reset the breaker.




- Plug the power cable into the power receptacle on the aft of the bow locker.




- Turn the forward portion of the plug clockwise to lock.



- **To raise** the anchor, press and hold on the “UP” button of the remote.



- **To lower** the anchor, press and hold on the “DOWN” button on the remote.




REFER TO THE MANUFACTURER’S MANUAL IN YOUR OWNER’S MANUAL PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY.

### Operating The Windlass Manually

In the event that there is a loss of power to the windlass the anchor can be raised and/or lowered manually by using the emergency handle located in the bow locker.

Windlass Manual/Emergency Operation  
Figure 3.62.1



There are two star sockets on the top of the windlass used for manual deployment of the anchor. Inserting the emergency handle into the center socket and turning it counter-clockwise will loosen the anchor windlass chainwheel. The star socket located off-center is used for retrieving and lowering the anchor. Turning the handle counterclockwise will allow you to lower the anchor, while turning it clockwise will raise it.

When operation is complete, insert the handle into the center star socket and tighten the windlass chainwheel by rotating the handle clockwise. Be sure to attach the anchor lanyard when the anchor is stowed in the anchor davit.

### Anchoring

The 380 Outrage is equipped with a windlass, anchor, rode and an anchor roller davit. Stow the anchor in the davit when not in use.

**NOTE:** Before using the anchor, be sure the anchor lanyard is removed and the anchor is secured to the windlass chain.

To anchor, bring the bow into the wind or current and put the engines in neutral. When the vessel comes to a stop, lower the anchor from the bow.

### Considerations

- Wind and sea conditions can affect the boat.
- Because the boat is not moving through the water, there is no control.
- Be sure that the anchor will hold under all circumstances if you are leaving the boat.
- Understand the principles of rode and scope and their effect on anchor performance.

Proper anchoring requires knowledge of RODE and SCOPE and understanding the relationship between rode, scope and anchor performance.

**The rode** is the line connecting the anchor to the boat. Nylon line is ideal because it is light, strong and stretches, it also can be stored wet and is easy to handle. Add a length of chain between the anchor and the nylon line to prevent abrasion of the line.

**The scope** is technically defined as the ratio of rode length to the vertical distance from the bow to the sea floor. Scope also depends on the type of anchor, tides, winds, sea conditions and type of sea floor the anchor is in. Since you want to know how much rode to use when anchoring, use this common formula:

**Rode length** = (bow height + water depth) X Scope

The minimum is 5:1 for calm conditions; normal is 7:1, and severe conditions may require a 10:1.

### Example:

Rode length = (3 feet + 10 feet) X 7\*

Rode length = 13 feet X 7\*

Rode length = 91 feet

\* Scope may range from 5 to 10 or more. However, less than 5, the anchor will break out too easily.

### Lowering The Anchor

- Be sure there is adequate rode.
- Secure rode to both the anchor and the boat.
- Stop the boat completely before lowering the anchor.
- Keep feet clear of lines.
- Turn on the anchor light when at anchor or drifting (not under power) at night or in low visibility.

**NOTE:** If using the windlass, refer to the windlass operator's manual for anchoring instructions


### Setting the Anchor

There is no best way to set an anchor. Experiment to see how it performs. One method is to turn the rode around a bit or a cleat and slowly pay out as the boat backs from the anchor site. When the proper scope has been reached snub the rode quickly, causing the anchor to dig in to the sea bottom.

- Reverse the engine slowly to drive the anchor in and to prevent it from dragging.
- Secure the rode to the bit or cleat.

### Weighing the Anchor

To weigh (or retrieve) the anchor, start the boat and run slowly up to the anchor, taking up the rode as you go. The anchor will usually break out when the rode becomes vertical. Coil lines to let them dry before stowing.



## Electrical Systems

### DC Electrical System

Your boat is equipped with an electrical system powered by a series of batteries. The batteries are charged by running the generator or when the engines are running or can be charged by shore power when the engines and generator are off.

The electrical system utilizes selector switches to control the delivery of power to the following:

- Engine Ignition.
- Engine tilt trim system
- Helm switch panel & helm instrument panel
- Lighting/Navigation systems
- Livewell system
- Add-on accessories and electronics

### Batteries

#### **⚠ DANGER**

**Batteries contain sulfuric acid which is dangerous and can cause serious injury. AVOID contact with skin, eyes and clothing. If contact occurs, immediately flush the affected area with large quantities of water and call for medical assistance.**

#### **⚠ CAUTION**

- **Never use an open flame in the battery storage area.**
- **Avoid striking sparks near the battery.**
- **A battery will explode if a flame or spark ignites the free hydrogen given off during charging.**
- **The battery should always be disconnected before doing any work or maintenance on the electrical system.**
- **If equipped with a battery switch, you will need to stop the engine before moving the switch to the "OFF" position.**

## NOTICE

**REFER TO YOUR ENGINE OWNER'S MANUAL FOR EXACT BATTERY REQUIREMENTS.**

The chart below is provided for reference purposes only. **Use only AGM batteries with Verado engines.**

Application	Group	Volts	MCA*	RC 25	Qty.
USA (SAE)	31	12	800	135 min	5


\* Marine Cranking Amps

Application	Group	Volts	CCA*	Reserve	Qty.
Int'l (EN)	31	12	975	65Ah	5

\* Cold Cranking Amps

## NOTICE


**Ensure that your batteries meet Mercury's AGM & CCA requirements**



### Battery Trays

The battery trays, located in the forward starboard corner of the bilge, house and secure the batteries. Batteries should always be secured in the battery trays provided and secured in place by the retaining brackets. The trays will ensure that while underway the batteries will not move around, thus causing damage to components fitted in the same area.

Battery Trays  
Figure 4.2.1



- 1 AFT BATTERY CHARGER
- 2 PORT ENGINE BATTERY TRAY
- 3 CENTER ENGINE BATTERY TRAY
- 4 STARBOARD ENGINE BATTERY TRAY
- 5 BATTERY REMOTE SWITCH
- 6 AUTOMATIC CHARGING RELAYS (ACR)
- 7 BATTERY TRAY\*
- 8 FORWARD BATTERY CHARGER

\*BATTERIES ARE IN PARALLEL, PROVIDING 12VDC POWER FOR HOUSE LOAD, THRUSTER & GENSET.

*NOTE: When equipped with optional V12 engines, battery configuration varies.*

The batteries can be removed from the trays by first removing the negative wires from the terminal posts followed by removing the positive wires then removing the retaining lid on the battery tray.

## NOTICE

**Always store the batteries in the battery trays. Tighten the knobs on the top of the trays to keep the batteries secure.**

### Battery Charger

Your boat is equipped with an aft battery charger and a forward battery charger (see Figure 4.2.1). The aft charger maintains the engine batteries. The forward charger maintains the house batteries. The battery chargers automatically increase current output when there is a drop in battery voltage. When the batteries are charged, the chargers maintain a small current flow to keep the batteries fully charged and ready for service without overcharging.

### Charge Rate

The battery charger has selectable profiles that affect the charge rate. The charge rate profile is pre-set at the factory to AGM to match the battery type installed in your vessel. Matching the charge rate to the battery type extends battery life and maximizes battery performance.

### Overload Protection

If an electrical short or overload occurs in the electrical system the chargers will reduce output voltage to avoid internal damage. When an electrical short occurs, the red LED on the front panel of the unit will be illuminated. The overload or short must be removed in order for the charger to resume charging characteristics.

### Maintenance

The charger is fully automatic and requires no maintenance. However, the battery terminals should be cleaned periodically with baking soda and all connections tightened to provide trouble free operation.

### Battery Switches

#### Engine Battery Switches

Your boat uses battery switches (one for each engine) to control delivery of DC power from the batteries. These battery switches are advanced electric relay switches located on the forward port bulkhead in the bilge (see Figure. 4.3.1) and are actuated via a rocker switch on the DC distribution panel.

The DC distribution panel is located behind an access door under the starboard gunwale opposite the helm station.

## CAUTION

**You must stop the engine(s) before moving the battery switch(es) to the "OFF" position.**

When the engines are shut down or not providing a charge, the boats systems will draw power from the house battery bank. This will allow you to run all the boats functions without affecting the port or starboard batteries.

## Remote Battery Switches

Each engine battery switch on the panel (see Figure 4.6.1) is wired to a remote battery switch located on the forward bulkhead in the aft bilge (see Figure 4.3.1).

## Automatic Charging Relays (ACR)


The engine batteries on your boat are automatically connected in parallel through the use of automatic charging relays when a sufficient charging source is present. The battery banks are automatically separated when the charging source falls below a certain voltage level for a predetermined amount of time. The use of automatic charging relays eliminates the need for the operator to monitor battery voltage and decide whether or not to parallel the battery banks. It also eliminates the chance of a dead

battery bank if a paralleling switch were left in the “Combined” position without a sufficient charging source present. In an emergency, the operation of the automatic charging relays can be manually overridden by use of the knob on the top of the automatic charging relay.

REFER TO THE MANUFACTURER’S MANUAL IN YOUR OWNER’S MANUAL PACKET FOR COMPLETE INSTRUCTIONS, WARRANTY AND SAFETY INFORMATION.


## Manual Control Override

Each of the remote battery switches and ACR units have a manual override knob on the top of the unit as an added level of safety that allows manual ON-OFF control with or without power and provides LOCK OFF for servicing the electrical system (see Figure 4.4.1).



## Remote Battery Switch (RBS)/Automatic Charging Relay (ACR)

Figure 4.4.1



- 1 MANUAL OVERRIDE KNOB
- 2 REMOTE BATTERY SWITCH/  
AUTOMATIC CHARGING RELAY
- 3 CABLE TIE KNOB SLOT

<b>To combine battery banks</b>	With override knob in <i>REMOTE</i> position, push knob down until latched.
<b>To isolate battery banks that are connected</b>	To unlatch, rotate override knob to right (knob pops up); rotate knob back to <i>REMOTE</i> position.
<b>To prevent remote operation</b>	Rotate knob to <i>LOCK OFF</i> position.
<b>To secure for servicing</b>	With knob in <i>LOCK OFF</i> position, pass cable tie through knob slot.

## House/ Thruster battery switches

The remote battery switch for the house battery bank is located on the port side of the forward bilge opposite the water heater.


The bow thruster remote battery switch is located on the starboard side of the forward bilge opposite the water heater.

These remote battery switches are advanced electric relay switches and are actuated via a rocker switch on the battery switch control panel located under the starboard gunwale.

The DC distribution panel is located behind an access door on the starboard freeboard opposite the control station.

## Bow Batteries

There are battery trays, for the two batteries which provide the 12 volts necessary to operate the bow thruster, along with a battery switch and battery charger. Access to the bow thruster, batteries, battery charger and battery switch can be made through the base of the cabin bunk.



## Battery Maintenance

Before use, check each battery and the charging system for loose connections or wiring. Normal maintenance should include:

- Coat the terminals with dielectric grease
- Keep the batteries dry
- Remove the batteries from the boat during cold weather or long term storage.

The most life shortening experience for the battery is to be drained to zero charge before recharging.

When a battery discharges, the active material on both positive and negative plates converts to lead sulfate, causing the plates to become more alike in an electrical charge. The electricity conducting battery acid becomes weaker and the voltage drops. As the battery remains discharged, the process continues until recharging the battery becomes impossible.


If the battery does become run down be sure to recharge it as soon as possible. Over charging the battery can be just as detrimental to its life as running it down too far.

## 12 Volt Outlet

### NOTICE

**DO NOT insert a cigarette lighter into the 12V outlet. Damage to the unit and system will occur.**


The 380 Outrage is equipped with two 12 volt receptacles (see Figure 4.5.1). One receptacle is located on the top of the console, the other is located on the starboard bow gunnel.



The receptacles are made of corrosion resistant marine grade materials and have a moisture proof cap. The receptacles are protected by a 10 amp breaker on the DC distribution breaker panel.



Be sure to use accessories that **DO NOT EXCEED** the rated capacity of the circuit, (10 amps).




## 120V Volt Receptacles

This boat is equipped with three 120 volt receptacles. There is a receptacle located on the starboard side of the leaning post another is located on the forward wall of the vanity in the cabin and a the third is located on the port wall of the storage garage..

The receptacles can be used while the generator is running or while connected to shore power (See chapter 3, Overview & Operation.

The outlets are protected by an accessory breaker on the 120V AC Distribution Panel located in the cabin (see Figure 4.11.1).



# Chapter 4 • Electrical System


## DC Distribution Panel

Your boat's DC electrical system operates on 12V power supplied by the house and engine batteries.


The DC distribution panel is located on the starboard side midship gunnel.

DC Distribution Panel


Figure. 4.7.1



Battery Switch Control



Engine Key Switches



DC Distribution Panel

NOTE: When equipped with optional V12 engines, panel configuration varies.

## DC Distribution Panel

Figure 4.8.1

1	CONSOLE FUSE BLOCK.....	150 AMPS
2	ELECTRONICS FUSE BLOCK.....	40 AMPS
3	HOUSE BATTERY SWITCH	
4	HOUSE/THRUSTER BATTERY VOLTAGE METER	
5	THRUSTER BATTERY SWITCH	
6	PORT BATTERY SWITCH	
7	CENTER BATTERY SWITCH	
8	STARBOARD BATTERY SWITCH	
9	PORT BATTERY PARALLEL SWITCH	
10	CENTER BATTERY PARALLEL SWITCH	
11	STARBOARD BATTERY PARALLEL SWITCH	
12	PORT ENGINE IGNITION	
13	CENTER ENGINE IGNITION	
14	STARBOARD ENGINE IGNITION	
15	BLOWER.....	7 AMPS
16	CO MONITOR.....	5 AMPS
17	DEFROSTER.....	15 AMPS
18	SHOWER SUMP.....	3 AMPS
19	UNDERWATER LIGHTS.....	30 AMPS
20	HELM SEAT.....	10 AMPS
21	SPOTLIGHT.....	10 AMPS
22	DECK OUTLET.....	15 AMPS
23	CABIN OUTLET.....	15 AMPS
24	NAV/ANC LIGHTS.....	10 AMPS
25	HORN.....	10 AMPS
26	FLOOD LIGHTS.....	10 AMPS
27	MAP LIGHTS.....	10 AMPS
28	WINDLASS CONTROL.....	10 AMPS
29	TRIM TABS.....	20 AMPS
30	STEREO.....	15 AMPS
31	SHADE CONTROL.....	5 AMPS
32	SHADE.....	15 AMPS
33	DECK CTSY LIGHTS.....	15 AMPS
34	CABIN CTSY LIGHTS.....	15 AMPS
35	WINDSHIELD WIPER.....	10 AMPS
36	WINDSHIELD VENT.....	10 AMPS
37	PORT F/B PUMP.....	10 AMPS
38	STBD F/B PUMP.....	10 AMPS
39	FWD F/B PUMP.....	10 AMPS
40	LIVWELL PUMP AFT.....	15 AMPS
41	LIVWELL PUMP L/P.....	6 AMPS
42	HEAD.....	40 AMPS
43	BOW TABLE.....	15 AMPS

## DC Distribution Panel (Cont'd)

Figure 4.8.2


44	ACC 1/PORT 30A.....	30 AMPS
45	ACC 2/STBD 30A.....	30 AMPS
46	ACC 3/GYRO.....	15 AMPS
47	ACC 4/ENG FLUSH.....	15 AMPS
48	ACC 5.....	10 AMPS
49	ACC 6.....	10 AMPS
50	FRESH WATER.....	15 AMPS
51	RAW WATER.....	15 AMPS
52	P REFRIG.....	15 AMPS
53	ACC 7/S REFRIG.....	15 AMPS
54	FORWARD BILGE PUMP.....	6 AMPS
55	AFT BILGE PUMP.....	12 AMPS
56	AUX BILGE PUMP.....	12 AMPS
57	BATT SW ACR CONTROL.....	10 AMPS

## Main DC Breaker Panel

The main DC breaker panel is located next to the house batteries (see Figure 2.12.1) and can be accessed through the base of the cabin bunk.

## Main DC Breaker Panel


Figure 4.8.3



1	MAIN.....	150 AMPS
2	UNSWITCHED MAIN.....	40 AMPS
3	24 HR.....	3 AMPS
4	GENERATOR.....	100 AMPS
5	AMP 1.....	60 AMPS
6	AMP 2.....	60 AMPS
7	AMP 3.....	60 AMPS
8	WINDLASS.....	100 AMPS

## DC Distribution Panel w/Joystick Piloting

DC Distribution Panel w/Joystick Piloting  
Figure 4.9.1



NOTE: When equipped with optional V12 engines, panel configuration varies.

DC Distribution Panel  
Figure 4.10.1

1	CONSOLE FUSE BLOCK . . . . .	150 AMPS	29	STEREO . . . . .	15 AMPS
2	ELECTRONICS FUSE BLOCK . . . . .	40 AMPS	30	SHADE CONTROL . . . . .	5 AMPS
3	HOUSE BATTERY SWITCH		31	SHADE . . . . .	15 AMPS
4	BATTERY VOLTAGE METER		32	DECK CTSY LIGHTS . . . . .	15 AMPS
5	PORT BATTERY SWITCH		33	CABIN CTSY LIGHTS . . . . .	15 AMPS
6	CENTER BATTERY SWITCH		34	WINDSHIELD WIPER . . . . .	10 AMPS
7	STARBOARD BATTERY SWITCH		35	WINDSHIELD VENT . . . . .	10 AMPS
8	PORT BATTERY PARALLEL SWITCH		36	PORT F/B PUMP . . . . .	10 AMPS
9	CENTER BATTERY PARALLEL SWITCH		37	STBD F/B PUMP . . . . .	10 AMPS
10	STARBOARD BATTERY PARALLEL SWITCH		38	FWD F/B PUMP . . . . .	10 AMPS
11	PORT ENGINE IGNITION		39	LIVEWELL PUMP AFT . . . . .	15 AMPS
12	CENTER ENGINE IGNITION		40	LIVEWELL PUMP L/P . . . . .	6 AMPS
13	STARBOARD ENGINE IGNITION		41	HEAD . . . . .	40 AMPS
14	BLOWER . . . . .	7 AMPS	42	BOW TABLE . . . . .	15 AMPS
15	CO MONITOR . . . . .	5 AMPS	43	ACC 1/PORT 30A . . . . .	30 AMPS
16	DEFROSTER . . . . .	15 AMPS	44	ACC 2/STBD 30A . . . . .	30 AMPS
17	SHOWER SUMP . . . . .	3 AMPS	45	ACC 3/GYRO . . . . .	15 AMPS
18	UNDERWATER LIGHTS . . . . .	30 AMPS	46	ACC 4/ENG FLUSH . . . . .	15 AMPS
19	HELM SEAT . . . . .	10 AMPS	47	ACC 5 . . . . .	10 AMPS
20	SPOTLIGHT . . . . .	10 AMPS	48	ACC 6 . . . . .	10 AMPS
21	DECK OUTLET . . . . .	15 AMPS	49	FRESH WATER . . . . .	15 AMPS
22	CABIN OUTLET . . . . .	15 AMPS	50	RAW WATER . . . . .	15 AMPS
23	NAV/ANC LIGHTS . . . . .	10 AMPS	51	P REFRIG. . . . .	15 AMPS
24	HORN . . . . .	10 AMPS	52	ACC 7/S REFRIG. . . . .	15 AMPS
25	FLOOD LIGHTS . . . . .	10 AMPS	53	FORWARD BILGE PUMP . . . . .	6 AMPS
26	MAP LIGHTS . . . . .	10 AMPS	54	AFT BILGE PUMP . . . . .	12 AMPS
27	WINDLASS CONTROL . . . . .	10 AMPS	55	AUX BILGE PUMP . . . . .	12 AMPS
28	TRIM TABS . . . . .	20 AMPS	56	BATT SWITCH ACR CONTROL . . . . .	10 AMPS

## WARNING

**Use of higher amperage fuses or breakers is a fire hazard.**

### AC Electrical System

Your boat's AC electrical system operates on 120/30A power from the generator or shore power. See Chapter 3 for information regarding the operation of your generator and shore power system. The AC distribution panel is located in a cabinet on the aft port wall of the cabin.

### Component Breakers

Your boat utilizes manual reset breakers for the various components throughout the boat. The breakers can be found on AC and DC panels as shown on figures 4.8.1 thru 4.12.1.

If a component breaker trips, determine and correct

the problem before resetting the breaker. Should a circuit breaker trip repeatedly, have a qualified marine electrician determine and correct the cause of the trip.


In the event it is necessary to replace a breaker, use only the same amperage as the original. If a breaker is replaced with one of lower amperage, it will not be sufficient to carry the electrical load of the equipment it is connected to and will cause nuisance breaker tripping.

Conversely, if a breaker is replaced with one of higher amperage, it will not provide adequate protection against an electrical malfunction and will create a fire hazard.

## Main AC Breaker Panel

AC Distribution Panel (120V)


Figure 4.11.1



- |   |  |
|---|--|
| 1 GENERATOR CONTROL PANEL               | 13 MICROWAVE . . . . . 15 AMPS               |
| 2 BLOWER SWITCH                         | 14 ACCESSORY 1 . . . . . 10 AMPS             |
| 3 SHORE POWER 1 VOLTAGE METER           | 15 DECK A/C PUMP . . . . . 20 AMPS           |
| 4 REVERSE POLARITY INDICATOR LIGHT      | 16 CABIN A/C PUMP . . . . . 20 AMPS          |
| 5 SHORE POWER 2 VOLTAGE METER           | 17 PORT REFRIGERATOR . . . . . 15 AMPS       |
| 6 LINE 1 SOURCE SELECTOR                | 18 STARBOARD REFRIG (OPTION) . . . . 15 AMPS |
| 7 LINE 2 SOURCE SELECTOR                | 19 STARBOARD REFRIG INDICATOR LIGHT          |
| 8 FWD BATTERY CHARGER . . . . . 15 AMPS | 20 PORT REFRIGERATOR INDICATOR LIGHT         |
| 9 AFT BATTERY CHARGER . . . . . 15 AMPS | 21 DECK A/C (OPTION) . . . . . 20 AMPS       |
| 10 WATER HEATER . . . . . 15 AMPS       | 22 FREEZER PLATE (OPTION) . . . . . 15 AMPS  |
| 11 OUTLETS . . . . . 15 AMPS            | 23 GRILL (OPTION) . . . . . 15 AMPS          |
| 12 GYRO (OPTION) . . . . . 25 AMPS      |  |

## Main AC Breaker Panel (230V) (Option)

AC Distribution Panel (230V) (Option)  
Figure 4.12.1



- |   |   |
|---|---|
| ① GENERATOR CONTROL PANEL               | ⑬ MICROWAVE . . . . . 5 AMPS                |
| ② BLOWER SWITCH                         | ⑭ ACCESSORY 1 . . . . . 10 AMPS             |
| ③ SHORE POWER 1 VOLTAGE METER           | ⑮ A/C PUMP . . . . . 2 AMPS                 |
| ④ REVERSE POLARITY INDICATOR LIGHT      | ⑯ CABIN A/C . . . . . 10 AMPS               |
| ⑤ SHORE POWER 2 VOLTAGE METER           | ⑰ PORT REFRIG . . . . . 10 AMPS             |
| ⑥ LINE 1 SOURCE SELECTOR                | ⑱ STARBOARD REFRIG (OPTION) . . . . 10 AMPS |
| ⑦ LINE 2 SOURCE SELECTOR                | ⑲ STARBOARD REFRIG INDICATOR LIGHT          |
| ⑧ FWD BATTERY CHARGER . . . . . 10 AMPS | ⑳ PORT REFRIG INDICATOR LIGHT               |
| ⑨ AFT BATTERY CHARGER . . . . . 10 AMPS | ㉑ DECK A/C (OPTION) . . . . . 15 AMPS       |
| ⑩ WATER HEATER . . . . . 10 AMPS        | ㉒ FREEZER PLATE (OPTION) . . . . . 10 AMPS  |
| ⑪ OUTLETS . . . . . 10 AMPS             | ㉓ GRILL (OPTION) . . . . . 10 AMPS          |
| ⑫ GYRO (OPTION) . . . . . .20 AMPS      |   |

### Fuse Blocks


#### WARNING

**Use of higher amperage fuses or breakers is a fire hazard.**


**Use fuses and breakers having the same amperage rating as the original or as specified.**

Your boat is equipped with three (3) fuse blocks.

1. Located behind the console. Accessed through a panel on the aft wall of the head.
2. Located on the starboard wall of the electronics box above the console.



3. A heavy duty fuse box is located in bilge and can be accessed by rising the mechanical hatch in the aft cockpit deck.



### Ground Fault Interrupter Receptacle (GFI)

The boat is equipped with three ground fault interrupter receptacles. One is located on the aft wall of the console interior and the other is on the starboard side of the deluxe leaning post and a third on the aft starboard wall of the storage garage.


The ground fault interrupter receptacle is designed to protect people from the line-to-ground shock hazards which could occur from defective tools or appliances operating from the receptacle, or from down-line outlets protected by it.

The ground fault interrupter will not prevent line-to-ground electric shock, but does limit the time of exposure to a period considered safe for normally healthy persons. The receptacle will not protect people against line-to-line or line-to-neutral faults, short circuits or overloads

Please read and understand the WARNING below regarding ground fault interrupter receptacles.

### Testing

The GFI outlet has a TEST and RESET button that you can use to regularly test the outlet for proper operation. Before testing the outlet, push the RESET button in. Plug an appliance into the outlet (such as a lamp) and turn it on. Push the TEST button, the appliance should shut OFF. If it does, the circuit was interrupted and it is working properly. Push the RESET button to return the power to the outlet. If the power to the appliance was not interrupted, have a qualified marine electrician check the system to find the problem.



#### WARNING

**Persons with heart problems or other conditions which may make them susceptible to electric shock may still be injured by ground faults on circuits protected by the GFI receptacle. No safety devices yet designed will protect against all hazards or carelessly handled or misused electrical equipment or wiring.**

### Helm Display

The helm display affords the operator monitoring of various boat systems including navigation, power status, fuel/freshwater/waste levels and more. Monitoring functions are done using the display apps.

### Display Apps


Tap on the various display apps to access functions. The Boston Whaler app is detailed in the next section. For more display information go online to [Simrad-yachting.com](http://Simrad-yachting.com).



## Boston Whaler App

Tap on the *Boston Whaler* app to access power status, fluid levels and alarms (see Figure 4.14.1).


Figure 4.14.1



## Fluid Levels

The defaults to the fluids screen, which displays *FUEL*, *FRESH WATER*, and *WASTE TANK* levels. Tap on the *FLUIDS* button to view the fluid levels (see Figure 4.14.2).


Figure 4.14.2



## Electrical

Tap on the *ELECTRICAL* button to view battery bank state of charge, shore power, and generator status (see Figure 4.15.1).


Figure 4.15.1



## Low Fuel

When the fuel level runs low, a fuel pump symbol appears in the upper right corner of the screen indicating low fuel. Tap on the symbol to transfer to the *FLUIDS* display to view the fuel tank level (see Figure 4.15.2).

Figure 4.15.2



## Alarms


An audible alarm will sound and a warning symbol, (see Figure 4.16.1) appears on screen for the following systems:

- Fuel or freshwater levels are low
- Waste tank level is high.
- Electrical power systems, Battery (DC), Generator (AC), and shore power (AC) are running below or above standard operating levels.



Tap the warning symbol to see a highlighted description of the specific issue that triggered the alarm. Red line item indicates *Alarm*, immediate attention required. Yellow indicates *Warning*, attention required soon. If an alarm sounds, silence it by tapping anywhere in the center field on the alarm tab screen. Tap on the *HOME* button to return to the previous screen.


Figure 4.16.1



## Transducer Mounting Location

Transducer Location

Figure 4.16.1




### Electrical Schematics

The following pages contain schematics pertaining to the electrical system in your boat. These images were generated by technicians in the Boston Whaler Engineering Department and are for reference and to be used by service technicians.

Boston Whaler does not recommend that you attempt to work on the electrical system yourself. Instead, we suggest that you take your boat to an authorized Boston Whaler dealer for service.

Boston Whaler reserves the right to change or update the electrical system on any model at any time without notice to the customer and is not obligated to make any updates to units built prior to the change. Contact customer service for current electrical schematics.


Electrical Schematic, Sheet 1) (Joystick Piloting)  
Figure 4.18.1



6020-07-401\_1\_AC

Electrical Schematic, Sheet 2 (Joystick Piloting)  
Figure 4.19.1


## BATTERY SWITCHES & BATTERY ACR CONTROL JOYSTICK



6020-07-401\_2\_AC

Electrical Schematic  
Figure 4.20.1

## DC MAIN PANEL JPO DC BRANCH PANEL




6020-07-401\_3\_AC





Electrical Schematic  
Figure 4.22.1


## BATTERY SWITCHES AND BATTERY ACR CONTROL (STD BOAT)



6020-07-401\_5\_AC


Electrical Schematic  
Figure 4.23.1

## GROUND BUSS CONNECTIONS




6020-07-401\_6\_AC

Electrical Schematic  
Figure 4.24.1



Electrical Schematic  
Figure 4.25.1

## LIGHTING GARAGE DECK




6020-07-401\_8\_AC





Electrical Schematic  
Figure 4.28.1


# LIGHTING BILGE



6020-07-401\_11\_AC

Electrical Schematic  
Figure 4.29.1

## LIGHTING CABIN



6020-07-401\_12\_AC








Electrical Schematic  
Figure 4.32.1


# HELM BLOWER



6020-07-401\_15\_AC


Electrical Schematic  
Figure 4.33.1

# SPOTLIGHT



Electrical Schematic  
Figure 4.34.1


# TRIM TABS AUTO GLIDE



6020-07-401\_17\_AC

Electrical Schematic  
Figure 4.35.1


## WINDLASS



6020-07-401\_18\_AC

Electrical Schematic (Option)  
Figure 4.36.1


# THRUSTER



6020-07-401\_19\_AC

Electrical Schematic  
Figure 4.37.1

## CTSY OUTLET / USB




6020-07-401\_20\_AC



Electrical Schematic  
Figure 4.38.1


## 30 AMP REELS



6020-07-401\_21\_AC

Electrical Schematic  
Figure 4.39.1


# GENERATOR BLOWER



6020-07-401\_22\_AC

Electrical Schematic  
Figure 4.40.1


## FUSE BLOCK'S AND ELECTRONICS®



Notes:  
 [C] Component wiring, included with component.  
 [R] Use 15A for dome and 20A for array.

Electrical Schematic  
Figure 4.41.1


## CONNECTIVITY - PORT BATT / STBD BATT / CENTER BATT / HIGH WATER



6020-07-401\_24\_AC

Electrical Schematic  
Figure 4.42.1


# CONNECTIVITY 1 - FUEL / FRESH WATER / WASTE TANK



6020-07-401\_25\_AC

Electrical Schematic  
Figure 4.43.1


# PORT / STBD REFRIGERATOR



6020-07-401\_26\_AC

Electrical Schematic  
Figure 4.44.1


# ENGINE FLUSH / CO MONITOR



6020-07-401\_27\_AC

Electrical Schematic  
Figure 4.45.1

## WIPER / WASHER




6020-07-401\_28\_AC



Electrical Schematic  
Figure 4.46.1


# BOW TABLE



6020-07-401\_29\_AC

Electrical Schematic  
Figure 4.47.1


## WASTE SYSTEM



6020-07-401\_30\_AC

Electrical Schematic  
Figure 4.48.1


# BONDING GYRO



6020-07-401\_31\_AC

Electrical Schematic  
Figure 4.49.1

# BONDING STD




6020-07-401\_32\_AC


Electrical Schematic  
Figure 4.50.1

# CONNECTIVITY DEVICES

Signal Interface #02  
Addr 1000 1000  
Cabin - Port




Meter Interface #01  
Addr 0100 0000  
Cabin - Port



1 2 3 4 5 6 8

BEP ACVSEN-4





6020-07-401\_33\_AC

Electrical Schematic

Figure 4.51.1


## JOYSTICK BATTERY SWITCH / ACR, STD BATTERY SWITCH / ACR



6020-07-401\_34\_AC

Electrical Schematic  
Figure 4.52.1


# DC MAIN BREAKER PANEL FWD



6020-07-401\_35\_AC

Electrical Schematic  
Figure 4.53.1

# UPPERSTATION LIGHTING/ HORN




6020-07-401\_36\_AC




Electrical Schematic  
Figure 4.54.1

# UPPERSTATION LIGHTING/ HORN




6020-07-401\_37\_AC

Electrical Schematic  
Figure 4.55.1




6020-07-401\_38\_AC

Electrical Schematic  
Figure 4.56.1



6020-07-401\_39\_AC


Electrical Schematic  
Figure 4.57.1



6020-07-401\_40\_AC

Electrical Schematic  
Figure 4.58.1


# AFT / AUX BILGE PUMP AUX ADAPTOR



6020-07-401\_41\_AC

Electrical Schematic  
Figure 4.59.1


## PUMP 2



6020-07-401\_42\_AC

Electrical Schematic  
Figure 4.60.1


PUMP 3



6020-07-401\_43\_AC

Electrical Schematic  
Figure 4.61.1

## PUMP 4



6020-07-401\_44\_AC




Electrical Schematic  
Figure 4.62.1

## PREMIUM AUDIO®

ELECTRONICS


DC FWD HARNESS



6020-07-401\_45\_AC

Electrical Schematic  
Figure 4.63.1


PREMIUM AUDIO W / UPPER STATION



6020-07-401\_46\_AC

Electrical Schematic  
Figure 4.64.1


## JPO BATTERY QUAD ENGINE



6020-07-401\_47\_AC


Electrical Schematic  
Figure 4.65.1

## BATTERY SWITCHES AND BATTERY ACR CONTROL JPO QUAD ENGINE



6020-07-401\_48\_AC


Electrical Schematic  
Figure 4.66.1




6020-07-401\_49\_AC

Electrical Schematic  
Figure 4.67.1

# BATTERY SWITCHES AND BATTERY ACR CONTROL STD QUAD ENGINE WITHRUSTER




Electrical Schematic  
Figure 4.68.1



6020-07-401\_51\_AC


Electrical Schematic  
Figure 4.69.1



6020-07-401\_52\_AC




Electrical Schematic  
Figure 4.70.1



6020-07-401\_53\_AC

Electrical Schematic  
Figure 4.71.1


## MAIN DC BREAKER PANEL STD QUAD ENGINE®



6020-07-401\_54\_AC

Electrical Schematic  
Figure 4.72.1


## DC BRANCH DISTRIBUTION PANEL STD QUAD ENGINE



6020-07-401\_55\_AC

Electrical Schematic  
Figure 4.73.1


## CONNECTIVITY QUAD ENGINE PORT BATT- PORT CENTER BATT- STBD CENTER BATT - STBD BATT- HIGH WATER



6020-07-401\_56\_AC

Electrical Schematic  
Figure 4.74.1


## BATTERY SWITCH / ACR INSTALLATION QUAD ENGINE



6020-07-401\_57\_AC

Electrical Schematic  
Figure 4.75.1


DUAL ENGINE BATTERY HARNESS JPO



6020-07-401\_58\_AC

Electrical Schematic  
Figure 4.76.1


## DUAL ENGINE BATTERY SWITCHES & BATTERY ACR CONTROL JOYSTICK



6020-07-401\_59\_AC

Electrical Schematic  
Figure 4.77.1

## CONNECTIVITY - AC METER 120V




6020-07-408\_1\_C



Electrical Schematic  
Figure 4.78.1


## SHORE POWER 120V



6020-07-408\_2\_C

Electrical Schematic  
Figure 4.79.1


# AC 120V MAIN BREAKER PANEL



6020-07-408\_3\_C


Electrical Schematic  
Figure 4.80.1

## AC 120V SHORE 1



Electrical Schematic  
Figure 4.81.1


## AC 120V SHORE 2



6020-07-408\_5\_C

Electrical Schematic  
Figure 4.82.1


# CABIN AIR CONDITIONING 120V/60HZ



6020-07-408\_6\_C

Electrical Schematic  
Figure 4.83.1


## CABIN AND DECK AIR CONDITIONING 120V/60HZ



6020-07-408\_7\_AC

Electrical Schematic  
Figure 4.84.1


# CABIN AIR CONDITIONING W/ SINGLE FREEZER PLATE 120V/60HZ & 230V/50HZ



6020-07-408\_8\_AC

Electrical Schematic  
Figure 4.85.1

## N AND DECK AIR CONDITIONING W/SINGLE FREEZER PLATE 120V/60HZ



6020-07-408\_9\_AC






Electrical Schematic  
Figure 4.87.1

## CABIN AND DECK AIR CONDITIONING W/DUAL FREEZER PLATE


120V/60HZ



6020-07-408\_11\_AC

Electrical Schematic  
Figure 4.88.1

# GYRO STABILIZER 120V




6020-07-408\_12\_AC


Electrical Schematic  
Figure 4.89.1

## GENERATOR 120V/60HZ

AC




DC



6020-07-408\_13\_AC

Electrical Schematic  
Figure 4.90.1


# VOLTAGE SENSE



6020-07-408\_14\_AC

Electrical Schematic  
Figure 4.91.1


## CONNECTIVITY - AC METER 220V



6020-07-408\_15\_AC

Electrical Schematic  
Figure 4.92.1


# SHORE POWER 230V/50HZ



6020-07-408\_16\_AC

Electrical Schematic  
Figure 4.93.1

# AC 230V MAIN BREAKER PANEL




6020-07-408\_17\_AC



Electrical Schematic  
Figure 4.94.1


## AC 230V/50HZ SHORE 1



6020-07-408\_18\_AC

Electrical Schematic  
Figure 4.95.1


## AC 230V/50HZ SHORE 2



6020-07-408\_19\_AC

Electrical Schematic  
Figure 4.96.1


## CABIN AIR CONDITIONING 230V/50HZ



6020-07-408\_20\_AC

Electrical Schematic  
Figure 4.97.1


## CABIN AND DECK AIR CONDITIONING 230V/50HZ



6020-07-408\_21\_AC

Electrical Schematic  
Figure 4.98.1

## CABIN AND DECK AIR CONDITIONING W/SINGLE FREEZER PLATE 230V/50HZ




6020-07-408\_22\_AC

Electrical Schematic  
Figure 4.99.1

## CABIN AND DECK AIR CONDITIONING W/DUAL FREEZER PLATE


230V/50HZ



6020-07-408\_23\_AC

Electrical Schematic  
Figure 4.100.1


# SEA KEEPER GYRO STABILIZER 230V/50HZ



6020-07-408\_24\_AC

Electrical Schematic  
Figure 4.101.1

# GENERATOR 230V/50HZ




6020-07-408\_25\_AC



Electrical Schematic  
Figure 4.102.1

# VOLTAGE SENSE




6020-07-408\_26\_AC



Electrical Schematic  
Figure 4.104.1


## DIESEL GENERATOR 220V



6020-07-408\_28\_AC


Electrical Schematic  
Figure 4.105.1

## AC 120V MAIN BREAKER PANEL (QUAD ENGINE)



6020-07-408\_29\_AC

Electrical Schematic  
Figure 4.106.1




6020-07-408\_30\_AC




Electrical Schematic  
Figure 4.108.1

AC 230V MAIN BREAKER PANEL  
(QUAD ENGINE)



6020-07-408\_32\_AC

Electrical Schematic  
Figure 4.109.1



SEE AIR  
CONDITIONING  
AND FREEZER  
PLATE OPTION  
DETAILS







THIS PAGE INTENTIONALLY LEFT BLANK

### Routine Care and Maintenance

#### NOTICE

**Refer to the individual manufacturers' manuals for important information regarding service, care and maintenance of your boat, equipment and components. Failure to do so may in some cases void the warranty.**

**Owner's manuals for your boat and each of the various components and equipment can be found in your owner's manual packet.**

#### ⚠ DANGER

**When using solvents read all information from the solvent manufacturer regarding safety and handling of the material.**

**Wear proper protective equipment to ensure your personal safety.**

**Only use solvents in a well ventilated area and keep all solvents away from open flame and any other forms of ignition.**

#### ⚠ WARNING

##### IMPORTANT

**Regularly inspect and test hardware, fittings, windshields, hatches, seams, etc. for proper seal. Reseal and/or readjust/tighten fittings, latches, etc. as needed.**

Routine inspection, service and maintenance of your boat, boat systems and components are vital to assure your safety, as well as prolonging the life of your boat. You should develop regular routines for inspecting and servicing your boat.

The interval between necessary service or maintenance is highly variable, depending on the environment in which your boat will be used. For example, corrosion of boat parts and components will occur far more rapidly in a salt water environment than on a boat which is used in fresh water.

This section provides only general guidelines for the care and cleaning of your boat. It is your responsibility to determine whether maintenance and care intervals need to be accelerated due to boat usage and/or operating environment.

### Hull

Fresh water, saltwater and water temperature can all affect the types of growth that you will find on your boat's hull.

Any growth will affect the boat's performance and overall look. If it has been a while between inspections you might notice algae or slime growth on the hull. This can be cleaned with a coarse towel or soft bristle brush. The growth should be cleaned immediately after the boat has been removed from the water. If the growth is allowed to dry it will be much harder to remove.

Compounding may be necessary to remove more stubborn stains and chalking from the surface of your boat. If compounding is necessary it must be done after a thorough washing and prior to waxing.

If the growth is more severe, you may need to enlist the services of a professional hull cleaning company.

Check with your Boston Whaler® dealer for recommendations on a compatible rubbing compound for your boat or a professional hull cleaning company in your area.

### Aquatic Invasive Species (AIS)

Aquatic invasive species (AIS) are plants and animals that occur in waters in which they are not native and whose introduction causes or is likely to cause economic or environmental damage or harm to human health. AIS have a negative impact on the waterway, its native species, and recreational and commercial uses of the waterway.

As responsible boaters and citizens, each boat owner should do their part to prevent the spread of these aquatic hitchhikers. In many cases, it is also required by law. Check local regulations for any waterway where you will boat.

After each boating trip, follow these three simple steps before you leave the water access to stop the spread of AIS: Clean, Drain, and Dry. This is the boater's way to help protect the environment from the damage that AIS can cause.

#### Clean

Inspect and remove all aquatic plants, animals, mud,

and debris from the boat, engine, trailer, anchor, and any watersports equipment.

Rinse, scrub or wash, as appropriate, away from storm drains, ditches, or waterways.

Rinse watercraft, trailer, and equipment with hot water, when possible.

Flush motor according to owner's manual.

### Drain

Completely drain all water from the boat and its compartments, including but not limited to the bilge, wells, lockers, ballast tanks or bags, bait containers, engines, and outdrives.

### Dry

Allow the boat to completely dry before visiting any other bodies of water.

NOTE: Some localities may require inspection or decontamination before and/or after launching. Check state and local laws and regulations for requirements prior to traveling to go boating.

### Waxing the Gel Coat Surfaces

## NOTICE

**Waxing of the exterior surfaces is recommended to be done at least twice a year to protect the gel coat of your boat.**

Waxing is necessary to provide added protection to the gel coat. A periodic good cleaning and waxing will also ensure that your boat will be protected and look good longer.

Do not wax over dirt. Make sure the surface of your boat has received a thorough washing and rinsing and is clean before waxing. If a rubbing compound has been necessary, make sure that any minor scratches or surface pitting is cleaned of compound residue. Use a good quality carnauba wax or a high quality wax designed for marine gel coat. Apply several coats.

### Hull Maintenance

If using a pressure washer to clean the hull and deck surfaces of your boat it is important that you use the wide fan nozzle only and move the spray head in a continuous motion. Do not concentrate

the high pressure on a small area of the boat surface and NEVER use the fine pinpoint nozzle as the concentrated stream can cause damage to the surface of your boat.

It is also recommended that you refrain from pressure washing the console as high pressure may compromise the integrity of the electronics and gauges as well as other equipment installed on your boat. Also avoid pressure washing all caulk seams.

When staining from build-up does occur, use only cleaning agents that are recommended for marine gel coat for use on those stubborn stains.

NEVER use an abrasive cleaner to wash your boat's hull.

NEVER use an abrasive pad to attempt to remove stubborn stains.

NEVER use strong solvents to clean.

NEVER apply tape or any other type of adhesives directly to the painted surfaces on your boat.

Use care when covering your boat's painted surfaces as tarps and other such covers can trap dirt and cause chafing. It is best to use a frame of either aluminum or wood to keep the cover up and allow air to circulate.

### Hull Blistering

Due to the quality of the materials used in the hulls of Boston Whalers, blistering is rarely ever seen. Blistering is caused by water soluble materials in the hull laminate. The fiberglass and resin structure of your boat is porous. However, intrusion of water into the gel coat will take some time. The effect of osmotic pressure allows water to impregnate below the gel coat and substrate thus forming a blister.

There have been extensive university studies funded by the United States Coast Guard regarding the cause and effect of blistering in the gel coat of fiberglass boats. Fiberglass blisters can form anywhere from near-surface layers of the gel coat to very deep into the fiberglass structure. The damage can range from cosmetic to catastrophic, (although the latter is a very rare occurrence). The studies seemed to point toward long term immersion of the hull in warm water as a primary cause of hull blisters. Stress cracks on

the hull below the waterline also contribute to the formation of hull blisters.

### Prevention

There are a variety of ways to prevent the formation of hull blistering. Epoxy coatings can be applied to the hull, followed by hull painting. An alkyd-urethane-silicone marine paint can also be used to aid in the prevention of hull blisters.

Reducing the amount of time that your boat stays in the water also helps prevent hull blisters from forming. Use of a trailer or boat lift will reduce the likelihood of hull blisters forming. Be sure to use a bunk type lift or trailer for storage of the boat out of water.

Contact your Boston Whaler dealer for more information on the prevention and treatment of hull blisters.

### Bottom Painting

#### **DANGER**

**There are risks and dangers inherent with the use of paints and solvents. Dispose properly of all rags, rollers and trays used for painting. Follow all the precautions and regulations listed by the manufacturer before and after painting your boats hull.**

#### **NOTICE**

**If blisters are present in the hull, they need to be properly cleaned and dried out before any barrier protection can be applied.**

#### **CAUTION**

**Some bottom paints contain metals that can cause corrosion of the outboard engine. Leave a minimum of 3/4" unpainted around all engine parts. Use only a paint specifically designed for aluminum engines as anti fouling protection.**

If your boat will spend most of its time in the water, painting the bottom of your boat's hull is a good way to slow the formation of hull blisters and to keep bottom growth (fouling) under control.

If you will be trailering the boat to and from the water, you might want to forgo the painting.

Following is an abbreviated section on painting your hull bottom. Your Boston Whaler® dealer should have information on properly painting your boat's hull or recommendations on businesses that will paint your hull for you.

### Sacrificial Anodes

#### **CAUTION**

**Do not paint over sacrificial anodes. This action will render them useless and lead to deterioration of the underwater metal parts.**

Sacrificial anodes, usually zinc buttons or plates, are installed on the transom, trim tabs, and engines of your boat to protect underwater hardware. Zinc, being less noble than copper based alloys and aluminum used in underwater fittings, will deteriorate first and protect the underwater fittings from deterioration.

Sacrificial anodes generally need replacement once a year in freshwater, every 6 months in a salt water environment.

The need to replace anodes more frequently may indicate a stray current problem within your boat or at the slip or mooring. If your anodes do not need replacement after one year, loose anodes or low-grade zinc may be the problem.

### Bottom Painting a Bare Hull

#### **WARNING**

**Proper ventilation and capture of the dust created by sanding is essential. The dust created by sanding is toxic and should not be inhaled. A proper fitting respirator must be used.**

**Do not use a paper filter mask.**

Since the boat has never been painted preparation is the key to successful hull painting. Take extra care and time in preparation before proceeding to paint.

Begin by scrubbing the surface thoroughly with a stiff brush using an all-purpose marine soap and water

to remove loose dirt and contamination. Flush with fresh water to remove all soap residue.

Dewax the gelcoat removing all the mold release wax before sanding can begin, otherwise the wax will be dragged into the scratches and will reduce the adhesion properties of the paint.

Remove any mold release wax that may be present using fiberglass surface prep solvent and a scrub pad. Scrub only a few square feet at a time. Flush with fresh water. If the water beads up or separates, continue scrubbing the surface. When the water sheets off, the wax contaminate has been removed.

After the wax is removed, application of a primer coat is recommended. Pay close attention to scratches, nicks and dings in the surface. If necessary, fill any repair areas with a watertight epoxy filler. After filler is cured, sand with 80 grit paper until smooth. Remove the sanding residue using a fiberglass solvent wash. The paint can be applied after sanding and cleaning is complete. Follow the paint manufacturer's recommendations for application.

### Bottom Painting a Pre-Painted Hull

#### **WARNING**

**Bottom paint is designed to resist algae growth which means it has chemicals embedded in the paint that are harmful if ingested. Take all necessary precautions required before painting or repainting your boat's hull.**

#### **NOTICE**

**Painting the hull will adversely affect the boat's speed and performance and may require re-propping if the maximum engine RPMs drop below the engine model/mfg recommended operating range.**

#### **NOTICE**

**Masking tape is NOT recommended for the types of paint you will be using.**

If the hull bottom is already painted, you must be sure to test the paint's adhesion to the already painted

surface. If the paints are incompatible, the new paint will not adhere to the hull bottom or the paint will "lift" the old paint. Never apply paint without first preparing the old painted surface following the paint manufacturer's recommendations.

Follow the paint manufacturer's recommendation for applying the paint. Humidity and weather will play a role in how and when the paint is applied. Several thin layers are better than one thick layer.

To determine the waterline, you will need to place the boat in water with a full load of fuel and gear. Mark the waterline and measure above the marked line 1 to 3 inches for placement of the tape line.

Make sure that there is enough paint left to cover areas that were not accessible, (slings, jack stands etc.) and paint accordingly. Follow the paint manufacturer's recommendation for do's and don'ts after the painting is complete.

### Rubrail Care

The rubrail on your boat is constructed of an injected high density PVC vinyl material which laboratory tests have proven to be highly resistant to staining, fading and cracking.

As resilient as this material is, you still need to follow some basic maintenance precautions.

General maintenance requires a thorough cleaning with mild soap & water. **DO NOT** use any cleaning agents which contain chemicals.

Although the outer shell is tough and durable, there is a chance that it can be breached. Use care when docking or exposing the rubrail to conditions which may cause damage such as docking against heavily barnacle-encrusted pilings.

Some tears (cleanly sliced) can be repaired with a super glue type product.

Thoroughly clean and dry the affected area. Apply glue and hold the surfaces together.

Areas which have been torn or are affected by heavy abrasion will have to have the damaged section replaced. Please see your Boston Whaler dealer for this type of repair.

### Cleaning Fiberglass and Non-Skid

To protect your deck and non-skid areas from the deteriorating affects of the sun, oxidation, water spots and pollution, use a good quality “fiberglass and non-skid deck” wax every two to three months.

When applied to your deck and non-skid areas, as recommended by the manufacturer, the wax forms a protective non-slick surface which will keep debris from sticking. Dirt, soot, bird droppings, and even fish blood will rinse right off.

#### NOTICE

NEVER use abrasive cleaners, detergents or soft scrub type cleaners to wash your boats surfaces.

NEVER use abrasive pads, brushes or sponges to attempt to remove stubborn stains.

NEVER use strong solvents or detergents which contain chlorine.

NEVER use silver cleaners.

### Stainless Steel Care

The cleaner stainless trim and fittings can be kept, the greater the assurance of optimum corrosion resistance. Without proper care even the best stainless steel will corrode.

Stainless steel is strong and corrosion resistant, but still requires maintenance to keep its appearance. Frequent routine cleaning of your stainless steel with a mild soap and water solution and coating with a good grade cleaning wax will help maintain the finish.

1. Wash with mild soap and cold or lukewarm water.
2. Dry thoroughly.
3. Apply cleaning wax with a soft, dry cloth.
4. Allow wax to dry, then polish and buff.

Even the finest cleaning powders can scratch or burnish a mill-rolled surface. On polished finishes, rubbing or wiping should be done in the direction of the polish lines, NOT across them.

Crevice corrosion, a brownish coloring which occurs

where two pieces of stainless hardware meet is caused by impurities in water and air. It can be easily cleaned with a good grade marine polish using a sponge, cloth or small bristled brush (for nooks and crannies).

### Teak Maintenance

The teak on this vessel requires some maintenance. Boston Whaler uses both natural teak and coated teak (pre-lacquered). Do not use a steel brush, steel wool, or a pressure washer on the wood. Do not use strong solvents or harsh cleaners on the caulking as these can damage or dissolve the caulk. Depending on the options selected for this vessel, different maintenance options apply:

#### Let-it-be (Natural Teak)

Left alone with the elements, teak changes to a silver-grey patina. To maintain, occasionally wash with soap and water. A light sanding every few years keeps the surface smooth; always sand with the wood grain.

#### Oiling

To retain or increase the darkness of the wood, apply a teak oil. There are numerous products on the market that provide a variety of different characteristics. Refer to the manufacturer’s instructions for proper application.

#### Lacquering

Applying lacquer to teak may decrease the amount of maintenance required and reduces the risk of mold. Lacquers can be tinted to change the color of the finish and can be mixed with paint thinner to reduce shine. Wood will likely darken when clear lacquer is applied. Carefully research product information to ensure it’s suitable for both teak and caulk. Refer to the manufacturer’s instructions for proper application.

#### Coated Teak (Pre-Lacquered)

If this vessel has a coated (pre-lacquered) table(s), keep covered when not in use. Be sure to allow for air flow between the table and the cover by inserting a non-marring object between the two. Refer to the manufacturer’s instructions for proper care.

#### Seats (Mechanical Parts)

Always wash metallic parts with soap and water and rinse thoroughly with fresh water. Once dry, apply



a light coating of lubricant to protect moving parts.

Check for loose or damaged hardware and tighten or replace as necessary.

### Aluminum Care

Preventative maintenance is essential to life of the metals on your boat. The presence of salt particles and moisture is the major cause of white spots, pitting and corrosion. The use of harsh chemicals can also cause deterioration. Manufacturers and applicators of protective coatings will not warrant protective coatings on metals in the marine environment. Proper owner maintenance is required to reduce deterioration which will result in most cases by failure to wash down and wipe dry after each use and/or the use of abrasive, acidic or other improper cleaners.

Wash completely using a soft cloth and mild detergent to remove salt particles. Hosing alone will not dislodge all particles. **DO NOT** allow soap to dry as it may cause stains on coated surfaces. Make sure to wash and dry the full circumference of aluminum parts.

Apply an aluminum protectant at least twice each year, more frequently as conditions warrant. Neglect will cause pitting of the surface which cannot be reversed.

Inspect and repair or replace all damaged nylon bushings, washers or other hardware designed to prevent contact with dissimilar metals.

Whenever electrical or electronic changes are made to the boat, a qualified marine technician should check aluminum parts for stray currents. Make sure all electronic equipment is properly grounded with adequate sized wire.

### Standard Vinyl Cushions

#### CAUTION

**Wear rubber gloves when using any solvents. Use caution when cleaning around buttons, stitching, and wooden or decorative trim as solvents could seriously damage such areas.**

Saltwater, salt residue, dirt and ultra-violet rays will take their toll on vinyl products causing them to lose

their luster and texture. To clean standard cushions:

- Remove ordinary dirt and smudges with a mild soap and water solution. Dry with a soft, lint-free cloth or towel.
- More difficult stains can be cleaned using rubbing alcohol. Rinse cleaned area with fresh water and dry with a clean, soft, cloth or towel.
- Seemingly permanent stains like ballpoint ink can be cleaned with active solvents such as nail polish remover when applied with a soft cloth or damp sponge and rubbed. Rinse cleaned area with fresh water and dry with a clean, soft, cloth or towel.

REFER TO THE OWNER'S PACKET FOR COMPLETE INSTRUCTIONS AND WARRANTY INFORMATION.

### Cool Technology Vinyl Cushions (Option)

If this vessel is equipped with cool technology vinyl seat cushions, clean this material per the manufacturer's instructions at <https://spradling.group/en-sm>.

### Water Exposure

Boat cushions are not waterproof and will absorb and hold water. Do not leave the cushions in standing water or exposed to heavy, prolonged rain. If cushions become waterlogged, remove the foam from the cushion, press out as much water as possible from the foam and allow to air dry. To prevent mildew, keep the vinyl dry and make sure that moisture does not accumulate between the cushions.

### Cleaning Your Instrument Gauges

When gauges are exposed to a saltwater environment, salt crystals may form on the bezel and plastic covers. Remove the salt crystals with a soft damp cloth. Clean with a mild household detergent or plastic cleaner.

Never use abrasives or rough, dirty cloths to clean plastic parts. A mild household detergent or plastic cleaner should be used. Wipe clean with a damp chamois.

FOR MORE INFORMATION, CONTACT MERCURY MARINE CUSTOMER SERVICE AT 920-929-5040.

### Powder Coated Surfaces

Your boat has been manufactured with a powder coating on the Hardtop frame.

While most powder coat finishes are tougher and much more flexible than conventional solvent based paints, they are about the same hardness as automotive paint, so they will scratch.

To clean a powder coated surface, gently wash with a clean, soft cloth and a mild detergent followed by a clear water rinse.

Even though most powder coatings are highly resistant, certain solvents can harm them and should be avoided. **DO NOT APPLY:**

- Nail polish remover
- Paint or lacquer thinner
- Motor oils
- Transmission or brake fluids
- Parts cleaning fluids

If any of the above should contact the powder coated surface, immediately wipe the area with a soft, clean cloth, and wash as described above.

### Powder Coating Touch-Up

#### NOTICE

**For the best results, use Orbit Industries touch-up paint, RAL 9010 Pure White.**

**Orbit Industries: 800-448-3885**

#### NOTICE

**The visual, mechanical, chemical as well as corrosion protective and weather resistance properties of repaired areas ARE NOT equal to those of the original powder coating and are not suitable for long term performance.**

#### NOTICE

**If painting over exposed or bare metal, a chemical pretreatment process and/or primer sealer is recommended.**

**Follow manufacturer's recommendations.**

#### NOTICE

**It is highly recommended that you DO NOT penetrate the powder coating on your boat by securing equipment or other objects onto the coated surface. If necessary, contact the manufacturer for repair recommendations.**

If it is necessary to apply touch-up paint on areas of the finish that have been scratched or damaged the powder material supplier should be contacted for their recommendation of the proper touch-up material to use.

Single component Acrylic Enamel (spray enamel) touch-up paint is commonly used for repair of minor damage in the powder coated finish. In some cases a two-component catalyzed paint system may be required to achieve the desired repair. In all cases, perform a color and adhesion test in an inconspicuous area of the finish to assure compatibility before applying the paint to the damaged area.

#### Touch-up Procedure

1. Clean surface of dirt, oil, grease, etc.
2. Sand lightly with 400 grit wet/dry abrasive paper.
3. Remove sanding dust with a lint-free cloth dampened with mineral spirits.
4. Temperature of surface and paint must be at room temperature (between 70 to 90 degrees is ideal).
5. Apply paint to minor scratches by spraying a small amount of paint into the container's cap. Using a small brush, carefully apply the paint sparingly to the properly prepared surface. **DO NOT APPLY A HEAVY COAT ALL AT ONCE.** Apply several light coats allowing the paint to dry until tacky between each coat.

FOR MORE INFORMATION, CONTACT APEX POWDER COATING, INC CUSTOMER SERVICE AT 864-288-2739.

### Canvas Care and Maintenance

#### NOTICE

**DO NOT use detergents, bleach or solvents to clean your canvas.**

To keep your canvas and metal parts in good working condition and in good appearance, you will need to keep them clean.

The fabric should be cleaned regularly before substances such as dirt, pollen, etc. are allowed to accumulate on and become embedded in the fabric. The canvas can be cleaned without being removed from the installation.

Chafing, fiber wear from dirt and grit and deterioration from ultraviolet light can cause your canvas to degrade over time.

### Maintaining a good appearance

After each use, especially if used in salt water areas, rinse the canvas completely with fresh cold water.

#### On a regular basis:

1. Brush off any loose dirt, pollen, etc.
2. Hose down with fresh cold water and clean with a mild solution of a natural soap in lukewarm water (maximum 100°F / 38°C).
3. Allow the canvas to soak. Do not allow the soap to dry.
4. Rinse thoroughly with fresh water.
5. Let the canvas dry completely. **Do not** store any of the canvas pieces while wet.

The effects of ultraviolet light can sometimes be reduced by chemical treatment of canvas items.

Consult your Boston Whaler® dealer or check your canvas manufacturer's manual **BEFORE** using any chemical treatments on your canvas.

### Maintaining Boat's Appearance

- After each use, especially if used in salt water areas, rinse the canvas completely with fresh cold water.

#### On a regular basis

- Brush off any loose dirt, pollen, etc.

### Cleaning Stubborn Stains

Soak fabric for approximately twenty minutes in a mild solution consisting of no more than 1/2 cup (4 oz.) of bleach and 1/4 cup (2 oz.) of natural soap per gallon of lukewarm water (not to exceed 100° F / 38° C).

**Rinse thoroughly** in cold water several times. Allow the fabric to air dry completely.

## NOTICE

**Failure to remove all of the soap solution can cause deterioration of seams and prevent fabric from proper retreating.**

Retreat the fabric using an air curing product such as 303 High Tech Fabric Guard to ensure water and stain repellency.

All canvas should be stored flat or rolled in a clean, dry space.

### Maintaining Zippers and Hardware

## NOTICE

**DO NOT use petroleum based products, such as petroleum jelly, on the zippers or fasteners.**

Lubricate zippers and fasteners periodically with a clear silicone spray. In the absence of silicone spray, a wax candle can be used to lubricate the zipper track.

Replace any missing fasteners or any fasteners showing signs of corrosion.

### Maintaining Your Vinyl Windows

## NOTICE

- **Never use regular window cleaners, detergents, abrasives, petroleum based products, or alcohol to clean your vinyl windows.**
- **Do not handle vinyl with sunscreen on your hands! Sunscreen will permanently cloud the vinyl where handled.**
- **Do not fold vinyl. Store flat or rolled with smooth paper or soft cloth (i.e. bed sheet) between layers when dry.**

The canvas on your boat may incorporate Eisenglass or Makrolon® polycarbonate windows. In either case, with a few care and cleaning steps your windows will provide lasting enjoyment. Regular cleaning, utilizing compatible cleaners, coupled with proper

maintenance techniques will significantly improve the vinyl's service life. Recommended procedure is:

1. Rinse vinyl thoroughly with clear water to remove any dust, dirt particles, salt water or environmental agents before applying cleaning products. This should be done frequently to avoid build up of salt water, dirt and other environmental contaminants.
2. Using a soft non-abrasive cloth, wash windows inside and out with a mild soap (Woolite, Joy, Palmolive, etc.) and water solution, do not use detergents. Rinse completely with cool water.
3. Use separate clean, soft cloths or sponges for application of cleaners and polishes (Use the manufacturer's recommended products).
4. Use a small amount of cleaner or streaking may occur.
5. If you get streaking or a leftover film, follow up the application with a water rinse.
6. Dry with a soft cloth or chamois to prevent water spots. Polish with a separate cloth.
7. Don't leave cleaners on for long periods; wash immediately.
8. Don't apply cleaners in direct sunlight or at elevated temperatures.
9. Don't use scrapers, squeegees, razors, brushes, or towels.

Using a soft non-abrasive cloth, wash the vinyl curtains inside and out with mild soap and water mixture. Rinse completely with cool water.

To minimize fine or hairline scratches apply a mild automotive polish (i.e. Johnson's Paste Wax) and remove with a soft, clean cloth. Do not use abrasive plastic polishes.

### Storing Clear Vinyl

The clear vinyl should never be folded or creased as cracking will result. The recommended method of storage is to roll or lay the panels down flat. To protect the clear vinyl from rubbing against itself while rolled or stored flat, place a piece of very soft, nonabrasive cloth between the pieces.

## NOTICE

**DO NOT use solvents such as acetone, silicone spray, benzine, carbon tetrachloride, fire extinguisher fluid, dry cleaning fluid, lacquer thinner, glass cleaning solution or harsh detergents on acrylic.**

**The above substances will also damage the surface of any vinyl.**

## NOTICE

**Never use a dry cloth or duster or glass cleaning solutions on or acrylic.**

### Cleaning Tempered Glass Windshield

## NOTICE

**DO NOT USE abrasives, harsh chemicals or metal scrapers on glass.**

## NOTICE

**For windshields with aluminum frames refer to "Aluminum Care" in this section.**

Use commercially available glass cleaners or a mixture of fresh water and vinegar to clean your glass windows, windshield or port lights. Dry with a soft terry cloth towel or chamois.

### Corian® Solid Surface Countertops

Corian® was developed for a lifetime of easy care. Following the simple guidelines below will keep your Corian® surface looking as new as the day it was installed.

#### Routine Care

Soapy water, ammonia-based cleaners or commercial solid surface cleaners, if used routinely, will remove most dirt and residue from the countertop.

#### Minor Cuts and Scratches

Rub the scratch in a straight line with a fine grit sand paper periodically switch rubbing direction 90° until

all of the scratch is removed. Rinse top with water. Select the next lighter grit paper and rub over a large area to blend in the sanding. Continue the process using successively finer grits until desired gloss level is achieved. Wipe surface with damp cloth and let dry.

### Heat Damage

Corian® has excellent heat resistant properties. However, as with all countertop materials, it is important to minimize direct exposure to intense heat. We recommend the use of trivets or hot pads when placing hot objects on the countertop.

### Other Damage

In most cases Corian® can be repaired if accidentally damaged. However, to prevent any permanent damage to your countertop avoid exposing the surface to strong chemicals, such as paint removers, oven cleaners, nail polish remover, etc. If contact occurs quickly flush the surface with water. Avoid cutting directly on the countertop.

### Refurbishing

Over time and use your countertop may acquire a patina, changing the appearance of the finish. Using a general countertop polish rub the entire surface in a circular motion, rinse with clear water and wipe dry.

### Long Term Storage and Winterization

Long periods of storage, winter lay-up and/or non-use, common to boats, create unique problems. When preparing to store a boat for extended periods of two months or more it is best to make sure that the boat and its systems are properly conditioned for such extended periods of non-usage.

The guidelines presented on the following pages give basic instructions on “winterizing” your boat and boat systems. If inexperienced with the process of winterization it is best to hire the services of a professional.

In addition, always consult the owner’s manuals of the various systems and equipment on your boat for the manufacturer’s recommendations on winterizing and long term storage.

### Engine



**Never start or run your outboard (even momentarily) without having water circulating through the cooling water intake holes in the gear case. This will prevent damage to the water pump (running dry) or overheating of the engine.**

Protecting your engine’s vital moving parts from corrosion and rust caused by freezing of trapped water or excessive condensation due to climatic changes is very important. Freezing water in the engine can cause extensive damage to the internal moving parts. Internal engine parts can also be affected by rust due to lack of proper lubrication

1. Replace the engine oil and filter, running the engine to drain out as much old oil as possible.
2. Flush the engine with fresh water using flush muffs or a similar device attached to the raw water pickup.
3. Let all water drain from the engine.
4. Fog the engine while it is running. Spray until it stalls.
5. Run fuel which has been treated with conditioner and stabilizer through the engine.
6. Replace lower unit gear oil. Check for moisture in old oil, a sign of deteriorating seals.
7. Remove the prop and grease the shaft and threads.
8. Treat all grease fittings with the recommended lubricant.
9. Lightly lubricate the exterior of the engine or polish with a good wax.
10. Check engine mount bolts. Ensure that they are torqued to 55 ft/lbs.

In addition, it is important that you follow all the recommendations set by the engine manufacturer’s operation manual.

### Fuel System

#### NOTICE

**Pay particular attention to the information provided in "Ethanol-Blended Fuel" in chapter 3 of this manual.**

Tank(s), hoses, and fuel pumps should be treated to help prevent the formation of varnish and gum.

Temperature extremes will cause condensation to accumulate in an empty or partially filled fuel tank leading to fuel contamination and/or premature wear of your system.

Fill the tank completely (100%) full and add fuel stabilizer and conditioner, following the manufacturer's recommendations, to provide fuel stability and corrosion protection.

### Battery

Engine and house electrical systems have become increasingly more complex and are reliant on a good source of power. The house source of power typically comes from a battery bank comprised of two or three batteries in parallel. The charging source for the batteries while away from the dock is the engines or if equipped, a generator and battery chargers. As the engines/generator are providing a charge output to the house bank through the automatic charging relays (ACRs), keep in mind the following battery recommendations.

#### Mixing Fresh/New and Used/Dead Batteries

The fresh battery will deliver current into a dead battery which has high resistance. This results in excessive heat in the used/dead battery, which can cause further damage, leakage, or rupture. A used battery will drain energy from the new one, reducing the total amount of battery power available.

#### Mixing Battery Types

Different battery types are designed for different purposes. Mixing an AGM battery with a lead-acid battery will not improve performance and instead may result in reduced performance, damaged equipment, or battery leakage or rupture.

### Mixing Battery Brands

Different battery brands may not have the same specifications like marine cranking amps (MCA) or cold cranking amps (CCA). This results in excessive heat, which may then cause damage, leakage or rupture in one of the batteries. We recommend using the same type of batteries throughout a boat.

### Battery Storage

#### NOTICE

**Follow the manufacturer's recommendations for long term storage of your battery(s).**

1. Disconnect the battery cables (negative cable first).
2. Remove the battery from the boat.
3. Clean the terminal ends of the cables and battery terminals with a solution of baking soda and water. Rinse thoroughly with clean water.
4. Apply a coat of grease on the terminal ends of the cables and the battery terminals.
5. Store the battery in a cool, dry area.
6. Use a trickle charger to keep the battery charged or charge the battery every 30-60 days.

### Livewell/Raw Water System

Drain the livewell. Ensure that all water is removed from the drain hose.

Remove the fill hose from the pump in the bilge and drain the water from the hose. Replace the hose on the pump and tighten the two clamps.

### Fresh Water System

If the water system will not be used for an extended amount of time it is recommended that it be drained.

1. Energize the freshwater pump switch on the instrument panel.
2. Open all faucets and wash-down connections. Activate any sprayers connected to the system.
3. Run the system until the fresh water tank is completely empty.
4. De-energize the freshwater pump switch on the instrument panel.
5. Add a non-toxic antifreeze to the water tank per manufacturer's recommendations.

6. Energize the freshwater pump switch on the instrument panel.
7. Run the system until antifreeze is seen running out of all faucets, wash-down connections and sprayers.
8. Close all faucets, wash-down connections and sprayers.
9. De-energize the freshwater pump switch on the instrument panel.

If a water heater is a part of the system, isolate the tank by disconnecting the in and out hoses and connecting them together. Make sure that the tank contains a sufficient amount of non-toxic antifreeze to avoid freezing and causing damage.

### After Long Term Storage

Before you fill the freshwater system it is vital that it be properly disinfected.

The following procedure is recommended to disinfect the freshwater system:

1. Flush the entire system thoroughly by allowing potable water to flow through it.
2. Drain the system completely.
3. Fill the entire system with an approved disinfecting solution (check with your dealer for recommendations) and follow the method prescribed by the manufacturer.
4. After disinfecting, drain the entire system.
5. Flush the entire system thoroughly several more times with potable water.
6. Fill with potable water.

This should be done annually or before using the system if it has been laid up for an extended amount of time.

### Head System

1. Pump out the holding tank at an approved facility.
2. Add fresh water to the bowl and flush several times while the holding tank is being pumped.
3. Use cleaning/sanitizing crystals or liquid, following manufacturer's recommendations, and let soak for a few minutes.
4. Add fresh water and flush several times while pumping out holding tank again.
5. Add antifreeze and flush/fill entire system.

### Air Handling System

Follow manufacturer's recommendations for winterization/long term storage. The manufacturer's owner's manual can be found in your owner's manual packet.

### Sump

1. Drain all water from sump.
2. Remove the top and using a rag, clean up any residual water.
3. Check all connections and tighten if necessary.
4. Spray all connections with an anti-corrosion spray.

### Electrical System

1. Check all connections and tighten if necessary.
2. Spray all connections with an anti-corrosion spray.

### Deck

Clean the deck with soap, hot water and a stiff brush to clean up any oil spills.

### Drainage

## NOTICE

**Ensure that ALL drain plugs are removed (i.e. fishboxes, garboard drain, livewells, etc.)**

It is important to raise the bow of the boat enough to allow for proper drainage of water from the deck and bilge area. Make sure all the drainage fittings are clear and free of debris. Store the engine in an upright position to promote adequate drainage of water.

### Avoid Loss

Remove any valuables or anything that can be easily removed from the boat such as electronics, lines, PFDs, fenders, cushions, etc. and store at home.

### Cover

## NOTICE

**DO NOT USE a bimini top in lieu of a cover. Damage and aging will occur while providing no protection for your boat.**

## Chapter 5 • Care & Maintenance

When covering the boat it is best to use a frame of either aluminum or wood to keep the cover up. This allows air to circulate and discourages water from pooling on the cover.

Vents along the entire length of the cover will allow condensation to escape. Placing a series of foam pads between the hull and cover will also aid in air circulation and reduce condensation.

To help keep your boat dry and mildew free, consider placing commercial odor and moisture absorbing products in the boat under the cover.

### Environment

Antifreeze and other winterizing fluids can be toxic to aquatic life and cause harmful effects to plant life.

Improper disposal of, or spillage of antifreeze and/or any winterization fluids can cause environmental problems when allowed to empty into waterways or on the ground. Furthermore, it is illegal, punishable at minimum by fines.

Used antifreeze or any winterization fluids, should not be disposed of into sanitary sewers or publicly owned treatment plants.

Persons who have any questions regarding recycling antifreeze or other toxic fluids should write or call their state's EPA office.

### Reinforcement Locations



**CAUTION**

**DO NOT attempt to secure equipment in any location other than those that are illustrated.**

Your boat has been manufactured with reinforcement in various locations throughout the deck.

In the event you wish to add equipment to your boat which requires you to penetrate the deck with fasteners, the diagram on the following page illustrates the size, location and type of the reinforcement available. The chart below provides a description of the material and recommended fasteners to secure your equipment.

Reinforcement	Construction	Equipment weight	Fastener Type*
Plywood	Standard boat building material	Light	Self-tapping screws
Trevira	Thick spunbound polyester fabric	Light	Sheet Metal screws
Sparalloy	High density plastic	Medium	Self-tapping screws
Phenolic**	Fiberglass reinforced composite board	Heavy	Drill & Tap

\* In all cases it is recommended to drill and countersink a pilot hole to prevent damage to the gelcoat surface.

\*\*Also known as Whaleboard



## Reinforcement Location Diagram

